

# MASTER RESIDENTIAL DESIGNING

Interior Designer's Handbook for Beautiful Living Spaces



**(2025 EDITION)**

# Acknowledgement

Writing this book, Master commercial Designing, has been an incredible journey, and it would not have been possible without the support, inspiration, and guidance of many individuals.

First and foremost, I express my heartfelt gratitude to my mentors and teachers in the field of interior design, whose insights and knowledge have shaped my understanding of aesthetics, functionality, and innovation in commercial spaces. Their teachings have been a guiding force in crafting this book.

I also extend my sincere appreciation to my family and friends for their unwavering encouragement and belief in my work. Their patience and support have been invaluable throughout this creative process.

A special thanks to my colleagues and industry professionals who have contributed their wisdom and experience, helping me refine my ideas and present a well-rounded approach to residential design. Your feedback and discussions have been instrumental in making this book comprehensive and insightful.

Lastly, I dedicate this book to aspiring designers, students, and professionals who are passionate about creating beautiful and functional living spaces. May this book serve as a valuable resource in your journey toward mastering commercial design.

To all my readers, thank you for placing your trust in this book. I hope it inspires and empowers you to transform spaces with creativity and confidence.

With gratitude,  
Infrac

# Copyright

Master Commercial Designing: Designer's Guide to Stylish & Functional Business Spaces. Copyright © 2025 Infrac All rights reserved.

No part of this book may be reproduced, stored in a retrieval system, or transmitted in any form or by any means—electronic, mechanical, photocopying, recording, or otherwise—without prior written permission from the author or publisher, except for brief quotations in reviews or articles.

This book is a work of the author's research, experience, and insights. While every effort has been made to ensure accuracy, the author and publisher assume no responsibility for errors, omissions, or the use or interpretation of the content within this book.

<https://infrac.in/>

For permissions, inquiries, or collaboration requests, please contact: [infrac.in@gmail.com](mailto:infrac.in@gmail.com)

Printed in India



# TABLE OF CONTENT

## 01

### **The First Sketches (05-13)**

- Understanding Preliminary Sketches
- Bubble Diagrams – Visualizing Space Flow
- Traffic Flow Principles
- From Sketch to Schematic Plan
- Zoning: Private vs. Public
- Common Early Layout Mistakes
- Key Takeaways

## 02

### **Understanding the Site (14-33)**

- Site Orientation & Sun Path
- Wind Flow & Natural Ventilation
- Noise, Privacy & Views
- Grading, Slope & Drainage
- Responding to Local Climate

## 03

### **Living Room Planning (34-49)**

- Living Room Types & Zones
- Seating Arrangement Rules
- Ideal Furniture Spacing
- View Planning & TV Position
- Lighting Principles in Living Area

## 04

### **Kitchen Design Essentials (50-76)**

- Work Triangle Explained
- Kitchen Layout Types
- Ventilation & Chimney Planning
- Storage Zones & Appliance Placement
- Compact vs. Modular Kitchens

# 05

## **Bedroom Layout & Privacy**

**(77-94)**

- Ideal Bedroom Placement
- Bed + Wardrobe + TV Layouts
- Natural Light & Cross Ventilation
- Workspace & Study Integration
- Guest vs. Master Bedroom

# 06

## **Bathroom Planning**

**(95-116)**

- Minimum Sizes & Clearances
- Dry vs. Wet Zoning
- Ventilation + Drainage Rules
- Under-Stair Toilet Layouts
- Master Bath Planning

# 07

## **Vertical Circulation**

**(117-148)**

- Staircase Types & Space Use
- Design Rules & Railing Safety
- Skylight & Lighting Tips
- Landing Size & Width Rules

# 08

## **Facade & Elevation Design**

**(149-165)**

- Massing and Shape
- Balanced Openings & Proportions
- Shading Devices & Sun Control
- Roof Forms & Parapet Design
- External Finish Types

# 09

## **Outdoor & Service Zones**

**(166-175)**

- Balcony, Sit-Out & Garden Areas
- Utility, Parking & Service Yards
- Landscape Flow with Building
- Privacy Walls & Compound Planning

# Chapter 1

## THE FIRST SKETCHES


## THE FIRST SKETCHES

# UNDERSTANDING PRELIMINARY SKETCHES

Every great residential design starts with a rough idea — not on AutoCAD, but on a simple sheet of paper or tablet. This early phase is where preliminary sketches come in. These are quick, hand-drawn layouts that help the designer visualize how the different rooms, zones, and flows should function before any measurements are applied.

The focus at this stage is not on accuracy but on relationships — how the living room connects to the dining space, how private the bedrooms feel, where natural light will enter, and how people will move through the house. Designers use simple shapes and arrows to block out space. It's where creativity meets logic.

### PRELIMINARY LAYOUT SKETCH



These sketches often use color-coded zones to improve clarity — for example, yellow for bedrooms, blue for bathrooms, orange for kitchens, and green for outdoor areas. By doing this, a designer can instantly see if the layout feels balanced, if any zone is dominating the plan, or if circulation space is eating into usable areas.

Another powerful benefit of sketching is how quickly ideas can be reworked. You can shift the kitchen closer to the entrance, pull bedrooms to the rear, or try placing a courtyard at the center — all within minutes. These variations are low-cost experiments that help eliminate weak concepts early, without wasting hours on digital drafts.


## THE FIRST SKETCHES

# BUBBLE DIAGRAMS – VISUALIZING SPACE FLOW

Once initial zoning ideas are sketched out, the next step is to explore how spaces interact with one another. Bubble diagrams are a tool used to show relationships between rooms without worrying about exact sizes or walls. Think of them as a map of how people will move through the house.

Each room is represented as a bubble, and the distance or overlap between bubbles tells a story — should the kitchen be close to the dining area? Should the guest room be isolated from private bedrooms? Arrows often represent the expected circulation, helping designers optimize traffic flow and avoid cross-movement through private areas.


### BUBBLE DIAGRAM



Bubble diagrams are also useful for checking hierarchy and zoning clarity. For instance, bedrooms grouped together form a private zone, while living, dining, and kitchen bubbles may create a semi-public zone. These distinctions are vital in designing homes that feel both open and secure.

Designers often sketch multiple bubble diagrams before choosing a final one. They may explore various layouts — such as a central courtyard scheme, linear corridor flow, or clustered functional pods. This method allows for fast iteration and visual feedback before committing to more structured floor plans.

### BUBBLE DIAGRAM



# TRAFFIC FLOW PRINCIPLES

One of the key goals in residential design is to ensure people can move smoothly through the house without obstruction or awkward detours. This is where traffic flow diagrams come in — they help identify how people will walk from one room to another and whether the layout supports natural circulation.

## TRAFFIC FLOW PRINCIPLES

A good layout ensures that you can enter the home, remove shoes, move to the living area, access the kitchen or go to bedrooms — all without cutting across private areas like bedrooms or toilets. These movement paths are often visualized as arrows or dashed lines drawn over the layout sketch.




## THE FIRST SKETCHES

# FROM SKETCH TO SCHEMATIC PLAN

Once preliminary sketches and diagrams are complete, the next step is to bring proportional accuracy into the drawing — this is where the schematic plan begins. A schematic plan is still conceptual, but it includes approximate dimensions, wall placements, and circulation paths drawn to scale.

This version helps you test if your initial ideas are practically viable. For example, does the 10'x10' bedroom really fit a double bed, wardrobe, and walking space? Will the kitchen triangle (sink-stove-fridge) fit well in a 7' x 10' kitchen? These questions get answered as the layout shifts from loose sketches to a scaled working draft.

## SCHEMATIC PLAN




A good schematic plan acts as a bridge between ideas and technical execution. It gives enough clarity to start discussions with clients, builders, or consultants — and ensures that essential space relationships are in place before moving to detailed working drawings.

Most importantly, it helps validate design intent. Once scale, proportions, and circulation are roughly defined, it becomes much easier to transition into CAD drawings or 3D models confidently.

## ZONING: PRIVATE VS. PUBLIC

In residential architecture, zoning refers to dividing the home into distinct areas based on their level of privacy and function. A well-designed home separates public zones (like the living room or guest toilet) from private zones (like bedrooms and attached bathrooms), creating a comfortable experience for both family and visitors.

Public zones are spaces where interaction with guests happens — these should be easy to access from the entry and should not require movement through personal areas. Private zones are for rest, study, or family-only access and should be protected from noise and circulation paths.



# PROPORTIONS AND SCALE IN SKETCHING

When making early sketches, many beginners focus only on shape and layout. But experienced designers always keep proportion and scale in mind — even when sketching freehand. A well-proportioned room looks natural, functions better, and feels more spacious, even if the actual size is small.

For example, a bedroom that's too long and narrow may technically fit a bed and wardrobe, but it will feel tight and awkward. Similarly, a living room that's too wide but shallow won't support a proper seating arrangement. These issues often begin at the sketch stage, when proportions are ignored in favor of just "fitting everything in."

## PROPORTIONS AND SCALE IN SKETCHING



WELL-PROPORTIONED




POORLY PROPORTIONED

When sketching with accurate proportions, designers often use modular grids or reference common furniture sizes. For example, allowing at least 3 feet of clearance around a double bed, or maintaining a minimum 5-foot width for a functional kitchen. These standards help ensure the space is not only buildable, but also comfortable.

In schematic sketches, scale doesn't have to be exact (like 1:100), but it should be consistent — for example, if a bed is shown as 6 units long, then a door should not be taller than that. This mental consistency builds habits that carry forward when transitioning to technical drawings.


## PROPORTIONAL BEDROOM SKETCH



# COMMON EARLY LAYOUT MISTAKES

Every designer — beginner or professional — has made early layout mistakes at some point. The key is learning to spot and correct them before the design progresses too far. The most common mistake is trying to fit too much into too little space. For instance, forcing 3 bedrooms, 2 toilets, a large kitchen, and a study into a 900 sq ft plot often leads to cramped, unlivable interiors.

Another frequent issue is poor circulation. This includes long, wasted corridors, doors opening into tight spaces, or people walking through bedrooms to reach toilets. A bad layout doesn't just look off — it feels uncomfortable to live in.



Sometimes, layout mistakes come from a lack of understanding of daily routines. For example, placing the kitchen far from the entry causes inconvenience when carrying groceries. Or placing a bedroom window directly facing a neighbor's wall — this reduces natural light and privacy, creating a boxed-in feeling.

Another common flaw is ignoring future flexibility. A home should be able to adapt — maybe a study becomes a nursery, or a guest room turns into a home office. Rigid layouts that don't allow furniture rearrangement or expansion quickly become outdated.

# THE FIRST SKETCHES

## KEY TAKEAWAYS


- **Start with Purpose, Not Perfection**  
Preliminary sketches help explore possibilities — don't worry about accuracy early on.



- **Bubble Diagrams Clarify Flow**  
Use bubble sketches to understand how rooms relate in movement, function, and privacy.




- **Zoning is the Backbone**  
Clearly divide your plan into public, semi-private, and private zones for better livability.



- **Proportions Matter More Than Detail**  
A space that "feels right" is often about size balance, not decoration.

### PRELIMINARY SKETCH DEVELOPMENT




# Chapter 2

## UNDERSTANDING THE SITE

## SITE ORIENTATION & SUN PATH

Before any walls are drawn, understanding the site's orientation is crucial. Orientation refers to how your plot sits in relation to the sun's path — which directly affects natural light, heat, and comfort within the home. In India, the sun rises in the east, travels slightly southward across the sky, and sets in the west.




Designing with orientation in mind means strategically placing windows, rooms, and walls to capture morning light, avoid harsh afternoon sun, and ensure passive cooling. For example, living areas on the east or north sides get pleasant light, while west-facing rooms often overheat.

# USING SUN PATH FOR BETTER DESIGN

A well-studied sun path helps you make rooms naturally lit and passively cooled. For example:

- North-facing rooms receive consistent, soft daylight — ideal for studies, bedrooms, and art spaces.
- East-facing spaces get morning sun, making them perfect for dining or living areas.
- South and west sides receive harsher light; use shading devices or service areas to buffer heat.

Good orientation also helps reduce dependence on artificial lighting and air conditioning — making your home more energy-efficient and comfortable.



A top-down site sketch showing shading elements like pergolas, trees, or sun-breakers on west/southwest sides.

# WIND FLOW & NATURAL VENTILATION

In architectural site planning, one of the first steps is identifying the prevailing wind direction — the direction from which the wind typically blows in a specific season or region. In most parts of India, the southwest monsoon winds dominate during summer, while cooler northeast winds may prevail in winter.

By studying wind flow, designers can orient openings, courtyards, and breezeways to naturally enhance airflow throughout the home. This ensures not just comfort, but also energy savings by reducing dependence on fans and AC.

## PROPORTIONS AND SCALE IN SKETCHING



WELL-PROPORTIONED




POORLY PROPORTIONED

When sketching with accurate proportions, designers often use modular grids or reference common furniture sizes. For example, allowing at least 3 feet of clearance around a double bed, or maintaining a minimum 5-foot width for a functional kitchen. These standards help ensure the space is not only buildable, but also comfortable.

In schematic sketches, scale doesn't have to be exact (like 1:100), but it should be consistent — for example, if a bed is shown as 6 units long, then a door should not be taller than that. This mental consistency builds habits that carry forward when transitioning to technical drawings.

## PROPORTIONAL BEDROOM SKETCH



## UNDERSTANDING THE SITE


# WIND FLOW & NATURAL VENTILATION

- Point 1: Understanding Prevailing Wind Directions

In architectural site planning, one of the first steps is identifying the prevailing wind direction — the direction from which the wind typically blows in a specific season or region. In most parts of India, the southwest monsoon winds dominate during summer, while cooler northeast winds may prevail in winter.

By studying wind flow, designers can orient openings, courtyards, and breezeways to naturally enhance airflow throughout the home. This ensures not just comfort, but also energy savings by reducing dependence on fans and AC.

### PREVAILING WIND DIRECTIONS



- Point 2: Cross Ventilation Design


Cross ventilation occurs when air enters from one side of a room and exits from the opposite side, creating a natural breeze that cools and refreshes the space. To achieve this, architects place windows, vents, or doors on opposing walls or corners.

For best results:

- Openings should be at a similar level (or slightly staggered)
- Rooms like bedrooms and living areas benefit most from cross ventilation
- Avoid placing large furniture in the airflow path — it blocks circulation

Cross-ventilation is one of the most passive, zero-cost techniques for thermal comfort, especially during hot Indian summers.

### CROSS VENTILATION DESIGN



## WIND FLOW & NATURAL VENTILATION


### Point 3: Window Placement & Size Matters

Properly placed windows not only bring in light but also determine how well air can circulate. For effective ventilation:

- Place larger windows on the windward side (the side from where wind enters)
- Add smaller openings on the leeward side (where air exits)
- Ensure windows are placed at human breathing level for comfort
- Use adjustable louvres or sliding windows to control airflow volume

Window size, height, and alignment directly impact how much air enters and exits a room — this helps prevent hot spots and stale corners.

### WINDOW PLACEMENT & SIZE MATTERS




POOR

GOOD

### Point 4: Passive Cooling with Courtyards & Vents

### PASSIVE COOLING WITH COURTYARDS & VENTS



Traditional Indian homes often used central courtyards, ventilators, and skylights to promote natural airflow. These features create a stack effect, where warm air rises and escapes, pulling in cooler air from below.

Key principles:

- Courtyards act as pressure-release zones, enabling vertical air movement
- High vents or clerestory windows release hot air buildup
- Skylights with operable openings allow warm air to escape while lighting interiors

These strategies are sustainable, cost-efficient, and ideal for warm Indian climates, especially in states like Rajasthan, Gujarat, or Kerala.

## UNDERSTANDING THE SITE

# NOISE, PRIVACY & VIEWS

- Point 1: Noise Control by Zoning & Layout

Controlling noise in residential design starts with how you zone spaces on the site. Loud areas like roads, parking zones, or common staircases should be kept away from quiet zones such as bedrooms, study areas, and meditation corners.

Design tips to reduce noise:

- Use buffer spaces like storage, toilets, or lobbies between noisy and quiet areas
- Place bedrooms away from the road-facing side of the house
- Use green belts or plant barriers to reduce outdoor noise
- Thick walls, double glazing, and sealing of doors also help in acoustic insulation

This smart spatial planning helps improve sleep quality, concentration, and overall well-being.

## NOISE CONTROL BY ZONING AND LAYOUT




Image: A colored site + floor plan layout showing noisy areas (road, parking), buffer zones (toilets/storage), and peaceful zones (bedrooms) separated effectively.

# NOISE, PRIVACY & VIEWS

### • Point 2: Privacy Planning with Smart Openings

Privacy is one of the most critical yet overlooked aspects in residential design. It's not just about placing walls — it's about controlling sightlines both inside and outside the house.

Key design strategies include:

- Avoid placing main doors directly in line with bedrooms or toilets
- Use L-shaped layouts or partitions to block unwanted visibility into private zones
- Orient windows to face internal courtyards, gardens, or blank compound walls rather than neighboring plots
- Frosted glass, jaalis, and green screens can maintain light while preventing direct views

These techniques ensure each room feels safe, undisturbed, and personal — especially in dense neighborhoods or joint family homes.





Image: A top-view home layout highlighting smart privacy techniques like angled entries, frosted glass, offset windows, and privacy walls.

# NOISE, PRIVACY & VIEWS

- Point 3: Planning for Positive Views

## PLANNING FOR POSITIVE VIEWS



Designing with views in mind enhances both mental well-being and property value. A well-placed window can completely change the experience of a space.

Here's how to make the most of it:

- Orient windows and openings towards gardens, courtyards, green belts, or scenic surroundings.
- Avoid placing windows that open directly to drainage, blank walls, or neighbor balconies.
- Balconies and sit-outs should be aligned with the best available view — even if it means adjusting the room layout slightly
- Use framing techniques — such as planting trees or adding pergolas — to beautify even average views

This approach turns everyday moments like having coffee or reading by the window into calming, uplifting experiences.

Image: A plan and sectional sketch showing ideal view alignments — garden-facing openings, framed balcony views, and blocked views toward unwanted areas.

## NOISE, PRIVACY & VIEWS

- Point 4: Blocking Unwanted Views

Just as important as capturing good views is the intentional blocking of unpleasant or intrusive ones. Whether it's a neighbor's window, a cluttered backyard, or a roadside drain — smart planning can help.

Here's how to handle it:

- Use high compound walls, green buffers, or planter screens to block direct line of sight
- Orient windows slightly away from problematic directions or place them higher up (clerestory style)
- Install louvers, vertical fins, or blinds to cut off unwanted visibility while still allowing airflow
- For interior privacy, use furniture placement (like wardrobes or partitions) to create subtle visual blocks

This not only increases comfort but also elevates the aesthetic feel of your home.





Image: A home layout with red arrows showing undesirable views (e.g. neighbor house, trash yard), and sketch elements like fins, greenery, and angled walls used to block them. Image created.

# UNDERSTANDING THE SITE

## SUMMARY: NOISE, PRIVACY & VIEWS


- Point 1: Noise Control by Zoning & Layout

NOISE CONTROL BY ZONING AND LAYOUT




- Point 2: Privacy Planning with Smart Openings

PRIVACY PLANNING WITH SMART OPENINGS




- Point 3: Planning for Positive Views

PLANNING FOR POSITIVE VIEWS



- Point 4: Blocking Unwanted Views

BLOCKING UNWANTED VIEWS



## UNDERSTANDING THE SITE

# GRADING, SLOPE & DRAINAGE

- Importance of Site Grading in Home Design

Grading refers to shaping the land surface for proper function — especially to ensure water drains away from the building. Poor grading can cause water stagnation, foundation issues, and even flooding during monsoons.

Key points to keep in mind:

- Always raise the plinth level of the house at least 300–450 mm above the finished ground level
- Ensure a gentle slope (1:50 to 1:100) away from the building on all sides
- Use retaining walls, stepped gardens, or terracing for sloped sites
- Paved areas like driveways and paths should have built-in slope and surface drains

Proper grading helps keep your foundation dry, your site usable, and your home long-lasting.

## GRADING, SLOPE & DRAINAGE

Importance of Site Grading in Home Design




- Managing Natural Slope — Don'ts & Smart Workarounds

Every site has a natural slope — it might be gentle or steep. Instead of flattening it entirely (which increases cost and disrupts drainage), work with the slope when possible.

Here's how:

- Avoid deep cutting or excessive filling — it weakens soil and adds cost
- Split-level homes or stepped foundations are a great solution for sloping sites
- Use retaining walls and landscape terraces to hold soil and create usable zones
- Always direct water away from the structure using slope channels or French drains

## MANAGING NATURAL SLOPE




## DRAINAGE PLANNING — SURFACE & SUBSURFACE

### Drainage Planning — Surface & Subsurface

Drainage ensures that water doesn't stagnate or seep into foundations. It includes both surface drainage (what you can see) and subsurface drainage (hidden systems beneath the ground). Here's how both work together:

- Surface drainage uses visible elements like:
  - Sloped paving
  - Open drains
  - Gully traps and scupper drains near entrances
- Subsurface drainage uses:
  - French drains (gravel-filled trenches with perforated pipes)
  - Soak pits for rainwater absorption
  - Drainage blankets under lawns or planters

In combination, these systems prevent waterlogging and protect the structure.




### Slope Direction & Water Harvesting Integration

Grading isn't just about removing water — it's also an opportunity to reuse it. Smart designers use slope direction to naturally guide rainwater toward:

- Recharge pits to refill underground water table
- Rainwater harvesting tanks for reuse in toilets, gardening, etc.
- Swales and percolation trenches in gardens to slowly absorb water

Also, avoid letting water flow onto neighboring plots — it can lead to disputes and legal issues. So, always:

- Design site slope to guide water toward safe zones
- Add collection chambers or filters where needed
- Blend drainage with sustainability goals




# SUMMARY: DRAINAGE PLANNING

## Importance of Site Grading in Home Design


### GRADING, SLOPE & DRAINAGE

Importance of Site Grading in Home Design




## Managing Natural Slope — Don'ts & Smart Workarounds

### MANAGING NATURAL SLOPE




## Drainage Planning — Surface & Subsurface


### SURFACE DRAINAGE



### SECTION



## Slope Direction & Water Harvesting Integration



## UNDERSTANDING THE SITE

# RESPONDING TO LOCAL CLIMATE


### Understanding India's Climatic Zones

- India has five major climatic zones, and each affects residential design differently:
- Hot and Dry (e.g., Rajasthan):
  - Intense heat, low humidity
  - Use thick walls, small shaded openings, and courtyards
  - White or light finishes reflect sunlight
- Warm and Humid (e.g., Chennai, Kolkata):
  - High moisture, high rainfall
  - Prioritize cross-ventilation, shaded verandas, and sloped roofs
- Temperate (e.g., Bengaluru, Pune):
  - Pleasant weather mostly
  - Flexible planning with good ventilation, skylights, and outdoor connections
- Cold (e.g., Himachal, Ladakh):
  - Cold winters, snow in some areas
  - Compact designs with south-facing windows and thermal insulation
- Composite (e.g., Delhi, Lucknow):
  - Mix of all climates
  - Requires seasonal adaptability, like operable windows and shading control

These zones form the foundation of all passive design decisions.

## HOUSEHOLDS WITH AIR CONDITIONERS

Percentage of Households who own Air Conditioner or Air Cooler





## RESPONDING TO LOCAL CLIMATE

### Design Responses for Each Climate Zone

#### Hot & Dry Climate

- Thick Insulated Walls: Reduce heat gain through thermal mass.
- Courtyards: Create internal micro-climates and promote air movement.
- Small, Deep-Set Windows: Limit direct sun while allowing ventilation.
- Jaalis & Screens: Diffuse sunlight and maintain privacy.



#### Warm & Humid Climate

- Elevated Floors or Stilts: Improve air circulation below the structure.
- Large Openings on Opposite Walls: For cross-ventilation.
- Extended Roofs & Shaded Balconies: Protect walls from rain and sun.
- Sloped Roofs with Overhangs: Help in quick water drainage.

# RESPONDING TO LOCAL CLIMATE

## HOUSE COMPARISON BY CLIMATE



Flat-type Window


Thick earth walls with small high windows



Roof Window

Small wall openings and intermediate windows

### HOT-DRY CLIMATE



Ventilation Techniques

Minimizes solar heat absorption to maintain a cool interior

### WARM-HUMID CLIMATE



Open Verandahs

Widen roof overhangs to regulate humidity


# RESPONDING TO LOCAL CLIMATE

### Passive Cooling Techniques

Passive cooling is essential in hot Indian climates, especially in regions with unreliable electricity or high temperatures.

Key Strategies:

- Stack Effect Ventilation: Taller structures or vent towers allow hot air to rise and exit, pulling in cooler air from below.
- Shading Devices: Elements like pergolas, brise-soleils, louvers, or even balcony overhangs can cut solar gain significantly.
- Earth Cooling Techniques: Underground ducts or walls leverage the cooler underground temperature to regulate indoor air.
- White or Reflective Roofs: Reduce heat absorption and improve thermal comfort inside.



## RESPONDING TO LOCAL CLIMATE

### Material Choices for Local Climate

Choosing construction materials based on the local climate can greatly enhance comfort and energy efficiency.

#### Recommended Materials:

- **Hot-Dry Regions (e.g., Rajasthan):** Use thick walls, mud plaster, stone, and courtyards to regulate temperature.
- **Hot-Humid Areas (e.g., Kerala):** Prefer materials like terracotta tiles, laterite stone, and ample wooden louvered windows.
- **Cold Regions (e.g., Himachal):** Focus on insulation — use wood, double-glazed windows, and sloped roofs to manage snow.
- **Composite Climate (e.g., Delhi):** Use a mix — cavity walls, shading devices, and ventilated facades.

## MATERIALS FOR LOCAL CLIMATE



**HOT-DRY  
(RAJASTHAN)**  
Courtyard, thick  
laterite walls, wood traps



**COLD  
(HIMACHAL)**  
Double-glazed  
windows



**COLD  
(HIMACHAL)**  
Steep sloped roof  
for snow runoff



**COMPOSITE  
(DELHI)**  
Cavity wall  
Ventilated facade

# KEY TAKEAWAYS

- **Orientation Matters:** Designing with sun movement can naturally reduce energy use and improve comfort.
- **Wind flow & Ventilation:** Cross ventilation + wind direction-based planning = healthier homes.
- **Site context is crucial:** Analyze noise sources, privacy angles, and scenic views before zoning.
- **Drainage and slope:** Ignoring site grading leads to long-term structural and usability issues.
- **Climate-responsive design:** Aligning material and design choices with local climate ensures longevity and efficiency.

# Chapter 3

## LIVING ROOM PLANNING

# LIVING ROOM TYPES & ZONES

The living room is one of the most used spaces in any home. It serves as a hub for relaxation, socialization, and entertainment. Depending on the layout and family lifestyle, living rooms can vary greatly in form and function.

**There are typically three common types of living rooms:**

1. **Formal Living Room:** Primarily used for hosting guests; placed near the entrance.
2. **Informal/Family Lounge:** Used daily by family members for relaxing, watching TV, etc.
3. **Open Plan Living:** A part of a larger space that combines kitchen and dining; ideal for compact homes.

**Zoning in a Living Room:**

Creating zones within the living area helps in organizing furniture and activities. Common zones include:

- Seating Zone
- Media/TV Zone
- Reading Nook
- Transit Zone / Circulation Path


Good zoning ensures easy movement, visual balance, and better functionality.

## LIVING ROOM TYPES & ZONES




**FORMAL LIVING ROOM**

For hosting guests  
Near the entrance



**FAMILY LOUNGE**

Daily use,  
relaxing, TV...



**OPEN PLAN LIVING**  
Combined with kitchen &  
dining

# LIVING ROOM TYPES & ZONES

Broadly, living rooms can be categorized into formal, informal, open-plan, and multi-functional types. A formal living area is usually kept elegant and reserved for guests, while an informal setup focuses more on comfort and everyday use. Open-plan living rooms combine with dining or kitchen zones for a spacious and fluid experience, and multi-functional designs often include workstations, reading corners, or even kids' play areas.






Image: Illustrating all 4 types in one floor-plan or layout comparison

## LIVING ROOM TYPES & ZONES

The living room serves various functions depending on the family's lifestyle, size of the home, and available space. Broadly, we can categorize living rooms into:

- **Formal Living Room** – Primarily for hosting guests. Often located near the entrance and kept clutter-free with minimal personal items.
- **Family Living Room** – Used by family members for daily activities, relaxation, watching TV, etc. Usually more casual and cozy.
- **Open-Plan Living Room** – Merged with kitchen and dining in modern layouts, this type enhances flow but needs zoning through furniture, rugs, or lighting.
- **Compact Living Area** – Found in smaller homes or apartments; often multifunctional and space-optimized.



ZONING LIVING ROOM

### Zoning within Living Rooms:

- **Seating Zone:** For interaction and relaxation
- **Media Zone:** TV, music, or gaming setup
- **Passage Zone:** Should remain clear for circulation
- **Activity/Reading Corner (optional):** With a chair, lamp, or shelf

# SEATING ARRANGEMENT RULES

Seating layout plays a crucial role in how comfortable and functional a living room feels. It affects movement, communication, and visual flow. Keep in mind the following rules:

## 1. Conversation Circles

Sofas and chairs should be arranged in a way that allows for natural face-to-face interaction. Ideally, no seat should be more than 8 feet apart to encourage conversation.




Image – A top-view living room sketch showing an ideal conversational layout (circular or U-shaped seating).

## 2. Clear Circulation Paths

Maintain 30" to 36" of clearance in walkways, especially around entry points and between furniture. Avoid blocking doors or windows with bulky items.




Image – A sketch highlighting proper walking clearances between furniture (with labels like 30", 36", etc.).

# IDEAL FURNITURE SPACING

### Introduction to Furniture Spacing

Furniture spacing isn't just about aesthetics — it's about comfort, flow, and function. Even a beautiful sofa set can feel frustrating if it blocks walkways or forces people to squeeze through gaps. Ideal spacing ensures every piece of furniture has room to breathe, enhancing usability without making the space feel empty.

A good living room layout prioritizes human movement and interaction. Whether it's passing a cup of tea or getting up to answer the door, furniture must be arranged with real-life usage in mind — not just what looks balanced on paper.

### Standard Clearance Guidelines

Designing a functional living room starts with proper spacing. Without it, even high-end furniture can feel uncomfortable and impractical.

This diagram shows key clearances that ensure comfort and smooth movement:

- 4" (10 cm) minimum between a seat and an ottoman
- 10" (25 cm) minimum gap between chairs and sofas
- 12"–18" (30–46 cm) between seating and coffee table for easy access
- 22" (56 cm) minimum space between other objects to avoid clutter
- 36" (91 cm) is ideal for high-traffic passageways
- TV viewing distance should be based on screen size — about 6–8 ft for a 50" screen
- Using these measurements makes the space feel open, organized, and user-friendly.




## IDEAL FURNITURE SPACING

### Circulation Flow in Living Rooms

Smooth circulation is at the heart of a well-designed living area. People should be able to walk through the space without weaving awkwardly between furniture or disturbing seated guests. If your living room doubles as a path between other areas (like dining or kitchen), clear walking paths are essential.

The key is to identify primary and secondary circulation routes and keep them at least 36 inches (90 cm) wide. Avoid placing furniture that blocks natural movement lines between doors, seating, or functional areas. Think of circulation as invisible pathways that guide how people naturally move through the space.

### CIRCULATION FLOW




### Common Mistakes to Avoid

Smooth circulation is at the heart of a well-designed living area. People should be able to walk through the space without weaving awkwardly between furniture or disturbing seated guests. If your living room doubles as a path between other areas (like dining or kitchen), clear walking paths are essential.

The key is to identify primary and secondary circulation routes and keep them at least 36 inches (90 cm) wide. Avoid placing furniture that blocks natural movement lines between doors, seating, or functional areas. Think of circulation as invisible pathways that guide how people naturally move through the space.


### MISTAKES VS. IDEAL FURNITURE LAYOUT



# FURNITURE ARRANGEMENTS IN LIVING ROOMS


- Circular Seating = Smooth Circulation

A curved arrangement solves dual-door layout challenges by offering a natural path behind the seating zone while keeping conversations central.




- Circular Seating = Smooth Circulation

A Central path Limits furniture Placement but Creates a Natural divide in a Compact living Room.



- Rectangular Center = Restricted Circle


A bulkier table limits circular flow, but thoughtful placement still preserves clear passage through the living room.



# FURNITURE ARRANGEMENTS IN LIVING ROOMS


- Curved Circulation Living Room

A curved circulation path allows smooth movement around a compact seating layout while maintaining clear zones for work and relaxation.




- Floating Seating with Wraparound Flow

Furniture can float in the center if circulation wraps around it smoothly.



- TV Viewing with Clear Paths

TV-facing layouts should balance screen distance and circulation space behind sofas.




## VIEW PLANNING & TV POSITION

A well-designed living room ensures clear views for relaxation, entertainment, and social interaction. Among all features, the TV placement and visual access are two of the most important.

### 1. Eye-Level TV Mounting

When seated, the average viewer's eye level is about 42 inches (106 cm) from the floor. Therefore, the center of the television should align with this level.

Mounting a TV too high — like above a fireplace — may look aesthetic but causes neck strain during prolonged viewing.



### 2. Optimal Viewing Distance


The distance between the TV and seating depends on the screen size. As a thumb rule:

Viewing Distance = 1.5x to 2.5x the diagonal size of the TV.

**For example:**

A 50-inch TV should ideally be placed 6 to 10 feet (1.8 to 3 meters) away from the seating.

This prevents eye strain while maintaining image clarity.



## VIEW PLANNING & TV POSITION


### 3. Avoiding Common Mistakes

Improper planning often leads to discomfort. The most frequent issues include:

- TV placed off-center to seating
- Placing the sofa at an angle to the TV
- Placing windows behind or opposite the TV (causing glare)

#### The ideal setup ensures:

- Direct and centered viewing
- Balanced layout without obstruction
- No reflective surfaces interfering with view




## LIGHTING PRINCIPLES IN LIVING AREA

### Lighting Zones

Lighting transforms a living room from dull to dynamic. A well-lit living space layers three types of lighting: ambient (general), task (functional), and accent (decorative). Each type serves a specific role and contributes to the room's mood and usability.

Ambient lighting comes from ceiling fixtures, recessed lights, or natural daylight — it provides overall brightness. Task lighting is focused — such as a floor lamp beside a reading chair or a spotlight over a desk. Accent lighting highlights art, architectural features, or adds a warm visual tone using lamps or LED strips.




### Layering Light for Ambience & Function

In a well-planned living room, lighting isn't just functional — it adds warmth, focus, and visual depth. Instead of relying on a single overhead fixture, layering different light sources creates a balanced atmosphere that adjusts to various needs.

There are three main types of lighting:

- **Ambient Lighting:** General illumination, typically from ceiling-mounted fixtures or recessed lights.
- **Task Lighting:** Focused lights for specific activities like reading — often table lamps or floor lamps.
- **Accent Lighting:** Decorative highlights on artwork, niches, or architectural features — such as wall-mounted fixtures or LED strip lights.

Combining these three types in layers creates both comfort and control.




# LIGHTING PRINCIPLES IN LIVING AREA


### Avoiding Lighting Mistakes in Living Areas

Poor lighting design can ruin an otherwise well-designed living room. One of the most common mistakes is relying only on overhead lighting, which can cause glare, shadows, and eye strain. Another frequent issue is placing bright task lights too close to the TV or reflective surfaces — leading to visual discomfort.

Well-designed lighting avoids harshness. It offers control, flexibility, and comfort. Use dimmers wherever possible to adapt to different times of the day. Combine ambient lighting with soft accent lights to reduce contrast and create a more welcoming environment. Avoid placing light fixtures directly in the line of sight or above screens.




# DINING ROOM ARRANGEMENTS AND CIRCULATION




**DESIGN 1**

Movement flow around a dining table set in a compact-sized dining area.




**DESIGN 2**

Clearances around a round table located in the corner of a dining zone.



**DESIGN 3**

Circulation layout around a table positioned in a small dining nook.








**DESIGN 4**

Pathways around a dining table arranged in a medium-sized dining space.

## GUEST BATHROOM DESIGN

Guest bathrooms are small bathrooms with a toilet and lavatory, usually located on the main level of a house. As the name implies they are commonly used by guests, but also by family members because they are conveniently to be located near the living areas. The following are typical layouts of guest



## KEY TAKEAWAYS

### Types & Zones

- Formal Living Room: Used for guests, near entry, minimal circulation overlap.
- Family Living Room: Informal, cozy, near kitchen/dining for daily use.
- Open Plan Living: Integrates living with dining & kitchen, ideal for modern homes.
- Zoning: Create distinct seating, circulation, and activity zones.

### Seating Arrangement Rules

- Maintain 900–1000mm circulation space around sofas/chairs.
- Center table clearance: 450–500mm from seating.
- Conversation circle: Seating layout encourages eye contact & comfort.
- Avoid blocking natural light or pathways with furniture.

### Furniture Spacing Standards

- Sofa to TV: 2.5–3.5m for comfortable viewing.
- Side table height = same as sofa armrest (~450–500mm).
- Sofa length: 1.8–2.1m for 3-seater; chair ~900mm.
- Maintain balanced proportions between furniture & room scale.

### View Planning & Focal Points

- Primary focal point: TV wall, fireplace, artwork, or outdoor view.
- Orient seating toward focal point but keep flexibility.
- Avoid direct glare from windows behind TV.

### Lighting Principles

- Ambient Lighting: Ceiling/wall-mounted fixtures for uniform light.
- Task Lighting: Floor/reading lamps near seating.
- Accent Lighting: Spotlights on art, niches, or textured walls.
- Mix natural + artificial light for comfort & mood.

### Privacy & Openness Balance

- Living room near entry = needs partial privacy screen/partition.
- Open layouts: balance transparency with furniture placement & rugs.
- Large openings should connect to outdoor spaces for light & ventilation.


# Chapter 4

## KITCHEN DESIGN ESSENTIALS

## INTRODUCTION TO THE KITCHEN WORK TRIANGLE

The kitchen work triangle is a time-tested design principle that connects the three most used zones in a kitchen: the cooktop (or hob), the sink, and the refrigerator. These three points form a triangle that helps streamline kitchen activity — from cooking to cleaning to food storage.

A well-designed triangle minimizes unnecessary movement, reduces backtracking, and enhances cooking efficiency. Whether you're preparing a quick breakfast or a festive meal, a smooth flow between these key zones makes the experience more comfortable and organized.



## KITCHEN LAYOUT TYPES


### Layout 1: L-Shaped Kitchen

The L-shaped kitchen is one of the most common and efficient layouts for Indian homes. It uses two adjoining walls to form an L shape, making it perfect for open layouts or corner spaces. This design provides a clear work triangle, ample counter space, and room for movement, making it ideal for small to medium-sized kitchens.

It also allows for flexibility in placing appliances and offers the option to add a small dining table or island in the open area.

**Suitable for:** 1–2 cooks, compact to mid-sized homes

### L-SHAPED KITCHEN




### Layout 2: U-Shaped Kitchen

The U-shaped kitchen features counters and cabinets along three adjacent walls, forming a U. This layout maximizes storage and workspace, making it highly functional for homes with larger kitchen areas. It offers an efficient work triangle and minimizes through traffic, allowing multiple people to cook without interference. This layout is perfect for homeowners who enjoy serious cooking or need more storage.

**Suitable for:** 1–3 cooks, medium to large homes

### U-SHAPED KITCHEN




## KITCHEN LAYOUT TYPES

### Layout 3: Parallel (Galley) Kitchen

The Parallel Kitchen, also known as the Galley Kitchen, features two parallel countertops that create a narrow corridor for cooking. This layout is highly efficient for small spaces and is commonly used in apartments and compact Indian homes.

It provides a clear workflow with one counter for cooking and the other for preparation or cleaning. The layout supports excellent ergonomics and a proper work triangle, but it may feel cramped if the width is too narrow.

**Suitable for:** One-cook kitchens, narrow spaces, compact urban homes




### Layout 4: Straight Line Kitchen (One-Wall Kitchen)

The Straight Line Kitchen — also known as the One-Wall Kitchen — is a space-saving layout where all appliances, sink, and workspaces are arranged along a single wall. It's commonly used in studio apartments or compact homes where space is tight.

While it may not support a full work triangle, it can still be efficient when zones are well planned. Adding upper cabinets or open shelving maximizes vertical storage.

**Suitable for:** Small homes, studio apartments, single-person usage

## STRAIGHT LINE (ONE-WALL) KITCHEN



## KITCHEN LAYOUT TYPES


### Layout 5: Parallel (Galley) Kitchen

The Island Kitchen is highly functional and aesthetically appealing. It includes a freestanding island unit that can serve multiple purposes — prep station, dining area, or additional storage. This layout works best in large kitchens where there is enough clearance space around the island.

The island enhances workflow and creates a central hub for cooking and socializing. However, poor planning can disrupt the work triangle — so the placement of the island should be carefully considered.

**Suitable for:** Large homes, open-plan kitchens, families that enjoy cooking or entertaining.

### ISLAND KITCHEN




### Layout 6: L-Shaped Kitchen with Island

This layout builds on the efficiency of the L-shaped kitchen by adding a central island. The island can serve multiple purposes — as a prep zone, dining space, or additional storage. However, the placement of the island must be carefully planned. If it's too close to the work triangle (hob, sink, refrigerator), it can obstruct movement and reduce efficiency.

When done right, an island enhances workflow and creates a more social kitchen space.

**Suitable for:** Medium to large kitchens, open-plan homes, families who entertain or need multi-use counter space

### L - SHAPED KITCHEN WITH ISLAND




# VENTILATION AND CHIMNEY PLANNING

A well-ventilated kitchen is essential not only for comfort but also for health and hygiene. Indian cooking often involves frying, spices, and high heat — which can lead to smoke, grease, and odors lingering in the kitchen.

That's why a combination of natural and mechanical ventilation is ideal. Windows should be placed opposite the stove or hob area to create cross-ventilation. Additionally, installing a chimney or exhaust fan above the hob helps pull out smoke and oil particles efficiently.

Modern chimneys with ducted or ductless options are available, and suction power should be chosen based on your cooking habits.

Keep in mind: A chimney with 1000+ m<sup>3</sup>/hr suction is suitable for Indian kitchens.



This comparative illustration highlights the difference between two common kitchen ventilation solutions:

Left Side (Exhaust Fan Not Ideal):

- Smoke and fumes from the cooking range are dispersed into the kitchen before eventually reaching the exhaust fan.
- Poor ventilation leads to discomfort, greasy walls, and compromised indoor air quality.
- The cook is exposed to rising smoke, causing inconvenience and health risks.


Right Side (Chimney Hood Recommended):

- A chimney hood is placed directly above the cooktop, capturing smoke and fumes at the source.
- The vertical chimney unit quickly extracts pollutants outside the home.
- Maintains cleaner air, better hygiene, and a comfortable cooking environment.


# VENTILATION AND CHIMNEY PLANNING

This image illustrates the correct vs. incorrect installation height for a kitchen chimney hood—a crucial element in modern kitchen design for effective ventilation and safety.

- On the left side, the red X indicates an incorrect chimney height set at 95 cm above the cooktop. This distance is too high, which compromises the hood's suction efficiency. As a result, smoke and fumes escape into the kitchen, reducing air quality and defeating the purpose of the chimney.
- On the right side, the green check mark shows the recommended installation range — between 65 cm to 80 cm above the cooking surface. This height ensures optimal smoke capture without obstructing the user's view or posing safety risks.



The illustration shows a sloped roof where rainwater is flowing directly towards the back of the chimney.



- Without a chimney cricket, water gets trapped behind the chimney base, leading to water seepage issues, leaks, and potential structural damage.
- The person inside appears confused, highlighting a typical homeowner's concern about unexplained leakage — marked by the red.
- Bottom Half – With Chimney Cricket (Correct):
- Here, a chimney cricket is added behind the chimney. It's a small triangular ridge that effectively diverts rainwater away from the chimney.
- This prevents water accumulation and ensures proper drainage on the sloped roof.
- The homeowner looks satisfied — signaling the problem is solved — marked by the green

## STORAGE ZONES AND APPLIANCES PLACEMENTS

Kitchen zoning is all about organizing your space into five key zones to boost functionality and reduce unnecessary movement. These zones include: Consumables (pantry and fridge), Non-Consumables (dishes, utensils), Cleaning (sink and dishwasher), Preparation (countertops for chopping/mixing), and Cooking (stove, oven, microwave).

### KITCHEN ZONING



Each zone should be placed logically next to each other to reduce movement.

### The 3x4 Kitchen Rule




The 3x4 Rule of Kitchen Zoning is a practical design guideline used to efficiently organize kitchen spaces by combining 3 core activities with 4 key zones.

The "3" — Core Kitchen Activities:

1. Storage – Ingredients, utensils, appliances
2. Preparation – Counter space, cutting, mixing
3. Cooking/Cleaning – Stove, oven, sink, dishwasher


The "4" — Key Kitchen Zones:

1. Consumables Zone – Fridge, pantry (for storing food)
2. Non-Consumables Zone – Crockery, utensils, daily-use items
3. Preparation Zone – Countertop, knife rack, mixing bowls
4. Cooking & Cleaning Zone – Stove, oven, sink, chimney, dishwasher



## STORAGE ZONES AND APPLIANCES PLACEMENTS

Below is the typical kitchen designing blueprint as per Indian standard, if you are going for fully functional storage and appliances placement keep in mind that the lightest items or equipments should be placed in top cabinets while the heavier should be kept in lower cabinet so that the weight distribution and longevity easily get maintained.



# COMPACT VS MODULAR KITCHENS



**COMPACT  
KITCHEN**

A compact kitchen is a small, space-saving cooking area typically built by local carpenters. It follows a fixed layout with basic cabinetry and limited scope for upgrades. Often seen in rental homes or studio apartments, compact kitchens are budget-friendly but offer minimal customization. They usually have single-wall or small L-shaped layouts and are best suited for users with basic cooking needs and limited space.





**MODULAR  
KITCHEN**

A modular kitchen is a modern setup made using factory-produced cabinets and modules that are assembled on-site. It offers high functionality, sleek finishes, and efficient use of every inch through pull-outs, tall units, and corner storage. Modular kitchens are ideal for permanent homes and users who value organized cooking, modern aesthetics, and easy maintenance. While they cost more than compact kitchens, they offer great long-term value.


## DIFFERENT ZONES AND COUNTERTOP THUMBRULE

The diagram also notes the recommended 24-inch minimum countertop depth on either side of the sink—ensuring ample room to handle washing and prepping tasks comfortably. With a clear human figure shown at the sink, the image effectively conveys how landing zones align with real user movement, reinforcing ergonomic design. Incorporating these countertop landing zones not only improves function but also contributes to a safer, more enjoyable kitchen experience.




The standard height for kitchen countertops is typically around 36 inches (91 cm) from the floor, which is considered ergonomic for most users during food preparation. For dining or seating areas attached to the countertop (like a breakfast counter), the overhang should be around 12 to 15 inches (30–38 cm) to provide legroom for stools. Ensure a minimum clearance of 24 inches (61 cm) in depth for comfortable working space on the counter. For functional efficiency, sink counters are best placed 2 inches below elbow height, preparation counters should be 3 to 4 inches below, and cooking surfaces around 5 to 6 inches below the elbow.


# RECOMMENDED COUNTERTOP LANDING AREAS



REFRIGERATOR LANDING AREA




COOKING SURFACE LANDING ON ISLANDS




COMBINING LANDING AREAS

# COUNTERTOP DESIGNING




As with many design standards, there are practical reasons for standard counter height being what it is. The heights outlined above maximize ergonomics for the various tasks an adult of average height (5' 9" for Indian men, 5' 1" for women) would perform on a countertop. Sticking to these measurements will make it easier to complete your renovation using common installation standards. Kitchen base cabinet manufacturers, for example, typically design their products with a height of 34.5 inches. Countertops come with a standard thickness of 1.5 inches. Add the two together and you've got your standard kitchen counter height of 36 inches — no expensive customization needed.

This illustration compares the ergonomic dimensions of a standard dining table and a kitchen island seating. The dining table typically stands at 75 cm (29.5") high, paired with a chair seat height of around 45 cm (17.7") and a maximum leg clearance of 67 cm (26.3"). In contrast, a kitchen island is taller, standing at 90 cm (35.4"), with stool seating around 65 cm (25.5") high to maintain comfortable legroom. These measurements ensure proper posture, knee clearance, and ease of use for dining or casual seating, making them essential reference points for functional interior design.




## COUNTERTOP STANDARDS


Each layout ensures that the space between the seat and countertop allows for comfortable posture, arm movement, and leg room. As a designer, incorporating these standards maintains both form and function, preventing discomfort and aligning with universal design principles.




A kitchen table usually stands between 28 and 30" high. A chair with 17 to 18" would be required.



A counter usually stands between 35" and 36" high. A stool with a seat height of 24 to 26" would be required.



**BAR HEIGHT:**  
A bar usually stands between 40 and 42" high. A stool with seat height of 28 to 30" is required.




**SPECTATOR HEIGHT:**  
For a bar that stands between 45 and 48" high. A stool with a seat height of 33 to 34" is needed.

## KITCHEN CABINETS OVERVIEW

### Types of Kitchen Cabinets

1. Base Cabinets:
  2. Installed on the floor and support countertops. Often house sinks, dishwashers, or ovens.
3. Wall Cabinets:
  4. Mounted above the counter. Used to store lighter items like glasses, spices, and dry goods.
5. Tall Cabinets (Pantry Units):
  6. Extend from floor to ceiling. Great for food storage or housing built-in appliances like ovens or microwaves.
7. Corner Cabinets (Lazy Susans):
  8. Specialized units for corner spaces. Often include rotating shelves to maximize hard-to-reach areas.




## KITCHEN CABINETS

The standard counter height is 36 inches for kitchens and 32 inches for bathrooms. People frequently deviate from these norms, however, to create a custom design that works for their needs or desires.

If you choose to go this route, just remember that it will cost you in the form of custom cabinetry and — if you get really adventurous — money off the future sale of your home.

As their name implies, they provide the base for countertops, sinks, and cooktops. They also provide storage space for large items like pots, pans, and small kitchen appliances.


Standard height (to countertop)	34 1/2 inches
Standard depth (front to wall countertop)	24 inches
Standard widths	12, 15, 18, 24, 30, 56 inches



Always check dimensions supplied by your kitchen cabinet manufacturer.

They are attached directly to the wall.

Standard heights	12, 15, 18, 24, 30, 36 inches
Standard widths	12 or 24 inches



Always check dimensions supplied by your kitchen cabinet manufacturer.


## COUNTERTOP EDGES

Countertop edges are the finishing detail on the outer edge of a kitchen or bathroom countertop. They are not only important for aesthetics but also impact the safety, durability, and maintenance of the surface.


### Why It Matters:

- Safety: Rounded edges reduce the risk of injury.
- Durability: Some edge types are less prone to chipping.
- Style: Edge profiles complement different kitchen aesthetics.
- Cleaning: Simpler edges are easier to wipe down and maintain.


Edge Type	Best For
Eased	Modern kitchens, safety
Bullnose	Family-friendly, soft look
Beveled	Sleek and geometric design
Ogee	Traditional or luxury kitchens
Waterfall	High-end islands and open layouts




RADIUS




EXTENDED BEVEL




STRAIGHT




BEVEL




FULL BULLNOSE




DEMI BULLNOSE



THUMB MOLD STEPOUT




O'GEE OVER VERSAILLES




VERSAILLES OVER O'GEE


# COUNTERTOP EDGES DESIGNS




**1-1/2" Dupont Bullnose**




**1-1/2" Pencil Edge**




**1-1/2" Dupont Square**




**1-1/2" Reverse Bevel**




**3/4" Dupont Demi**



**1-1/2" Dupont Step Sq.**



**3/4" Dupont Demi**







**1-1/2" Dupont Step Sq.**

## KITCHEN AISLE WIDTH

Countertop edges are the finishing detail on the outer edge of a kitchen or bathroom countertop. They are not only important for aesthetics but also impact the safety, durability, and maintenance of the surface.

Why It Matters:



- Safety: Rounded edges reduce the risk of injury.
- Durability: Some edge types are less prone to chipping.
- Style: Edge profiles complement different kitchen aesthetics.
- Cleaning: Simpler edges are easier to wipe down and maintain.



## BLIND CORNER CABINETS

A blind corner cabinet is exactly like a regular 36" cabinet. It commonly features one functional drawer and one door. Half of the cabinet is hidden in the corner, but the space is still usable.

Many people will use a blind corner cabinet to store baking trays, pots & pans, or even large appliances not commonly used. A blind corner will also have an option shelf inside to double storage inside. This shelf is removable for additions one wants to add later on.




Some space needs to be used to pull the cabinet out. These cabinets are pulled out 6 inches from the wall rather than sitting flush against both walls.

A filler is typically used to space 3" from the center stile of the blind corner cabinet to the next cabinet. The filler creates enough space for the door handles to open fully without colliding with other handles or doors.



## KITCHEN LAYOUT WITH DIMENSIONS

Dimensions are the foundation of functional kitchen design. No matter how beautiful a layout looks, if the circulation space is too tight or the worktop is too short, daily use becomes frustrating. That's why it's critical to plan each layout with accurate spacing in mind — from countertop depth to walkway width.




# KITCHEN DESIGN ESSENTIALS

The below U shaped kitchen layout is approx 10 feet by 10 feet which is most preferred in Indian Homes as most of the people designing the kitchen for 1000 sq. feet. while the same goes with straight kitchen mentioned below, the idea behind selecting this specific dimensions is that most of us find it suitable for Indian homes.



## Island Kitchen



# KITCHEN DESIGN ESSENTIALS

This L-shaped kitchen layout is compact yet efficient, ideal for medium-sized homes. It follows smart design principles, maintaining optimal clearances and functional spacing for safety, accessibility, and a smooth cooking experience.




Image – A top-view of L shaped modular kitchen with dimensions.




Image – A top-view of L shaped modular kitchen with Indian Standard.




Image – A top-view of U shaped modular kitchen with central Island.




Image – A top-view of L shaped modular kitchen without dining.

# KITCHEN DESIGN ESSENTIALS

Straight kitchen layout is compact yet efficient, ideal for small-sized homes. It follows smart design principles, maintaining optimal clearances and functional spacing for safety, accessibility, and a smooth cooking experience.




Image – A top-view of U shaped modular kitchen with dimensions.




Image – A top-view of Straight modular kitchen with Indian Standard.





Image – A top-view of U shaped straight modular kitchen.


## COMMON MISTAKES TO AVOID

Avoid common design mistakes like placing appliances in corners, skipping fillers, poor fridge clearance, and ignoring counter space near the stove.



# KITCHEN DESIGN ESSENTIALS

While designing the modular kitchen or even the conventional kitchen we usually forget the basic key principles to avoid basic mistakes which are illustrated below.



*Image – Drawer in corner block access*



*Image – Appliances in corner block access*



*Image –Check for Base cabinet Filler*



*Image –Refrigerator Door block the access of cabinets/drawer.*

# KEY TAKEAWAYS

- **The Work Triangle** remains the foundation of efficient kitchen planning. Ideal distance between sink, stove, and fridge should range from 4' to 9' for optimal workflow.
- **Different kitchen layouts** (L-shaped, U-shaped, parallel, island) work best in different space sizes. Select based on user movement, storage need, and cooking frequency.
- **Ventilation matters** Every kitchen should have proper chimney placement, openable windows, or exhaust systems to manage heat and odors.
- **Zone-based storage** improves functionality. Divide the kitchen into consumables, non-consumables, cleaning, preparation, and cooking zones to reduce back-and-forth.
- **Dimensional clarity** is critical. Maintain standard heights, cabinet depths, walkways, and island clearances to avoid clutter and discomfort.

# Chapter 5

## BEDROOM LAYOUT AND PRIVACY

### IDEAL BEDROOM PLACEMENT

Bedroom location plays a key role in ensuring comfort, noise isolation, and long-term usability. It's not just about fitting a bed into a space — it's about privacy, views, light, and how the room connects (or disconnects) from active zones like the living area or kitchen.


Ideally, bedrooms should be positioned in the quietest corner of the house, away from the main entrance and high-traffic zones. For multi-storey homes, the master bedroom is often placed on the upper floor for better privacy, while kids' or guest rooms remain on the ground floor.



# BEDROOM REQUIREMENTS

The room adheres to a minimum horizontal dimension of 7 feet and covers at least 70 square feet (6.5 sq.m), which aligns with common building codes for habitable bedrooms. A large window on the exterior wall provides natural light and ventilation, with the sill height kept below 44 inches (112 cm) to meet egress and daylighting norms. The layout includes a dedicated seating zone featuring two single lounge chairs and a small center table — a thoughtful addition for reading or relaxation.



Additional notes highlight key functional and safety guidelines: the bedroom door cannot open directly into a garage, and heating must be capable of maintaining a room temperature of at least 68°F (20°C).




# BED + WARDROBE + TV LAYOUTS

A well-planned bedroom layout balances comfort, circulation, and visual clarity. The key is to position furniture in a way that avoids clutter while supporting ease of use — especially around the bed, wardrobe, and entertainment zone.

- **Bed Placement:** Ideally centered on the longest wall, leaving at least 2'–3' clearance on both sides for movement. Avoid placing beds directly under windows or against shared bathroom walls.
- **Wardrobe Planning:** Sliding wardrobes work best in compact rooms, while hinged shutters require a minimum of 2' clearance in front. Avoid placing wardrobes behind doors or next to windows to prevent light blockage.
- **TV Units in Bedrooms:** Keep TV at a comfortable viewing height (around 42" from floor to center) and opposite the bed. Use floating consoles or narrow furniture to save space.




## Small Bedroom Layouts 10x10 ft (3mx3m)



# BED + WARDROBE + TV LAYOUTS

A well-planned bedroom layout balances comfort, circulation, and visual clarity. The key is to position furniture in a way that avoids clutter while supporting ease of use — especially around the bed, wardrobe, and entertainment zone.

- **Bed Placement:** Ideally centered on the longest wall, leaving at least 2'–3' clearance on both sides for movement. Avoid placing beds directly under windows or against shared bathroom walls.
- **Wardrobe Planning:** Sliding wardrobes work best in compact rooms, while hinged shutters require a minimum of 2' clearance in front. Avoid placing wardrobes behind doors or next to windows to prevent light blockage.
- **TV Units in Bedrooms:** Keep TV at a comfortable viewing height (around 42" from floor to center) and opposite the bed. Use floating consoles or narrow furniture to save space.



## BEDROOM LAYOUT & PRIVACY

# BED + WARDROBE + TV LAYOUTS

### Top-Left: Queen Bed Layout

- Features a 60" (152 cm) wide queen bed, centered with balanced side tables.
- A desk and chair are placed near the window, creating a cozy work nook.
- Ample walking space on both sides for ease of circulation.

### Top-Right: Twin Bed + Workspace


- A single bed is placed to the side, leaving space for a comfortable desk and chair setup.
- Ideal for a teen's room or a guest room with work-from-home functionality.
- Wardrobe/storage zone near the bed.

### Bottom-Left: Full Bed + Study Table

- Includes a full bed (54" / 137 cm) with a study table placed across from the bed.
- Works well for single users who want both rest and productivity in one space.
- Simple and highly efficient for solo living.




### Bottom-Right: Twin Beds for Shared Room

- Two single beds (with small gap and side tables) suitable for siblings, roommates, or twin guests.
- A low-height TV unit or storage bench at the foot of the beds.
- Maximizes bed space while keeping the layout symmetrical.





# NATURAL LIGHT & CROSS VENTILATION

To ensure proper airflow, place windows on opposite or adjacent walls, especially in corner rooms. This allows air to enter from one side and exit from the other, creating a continuous flow. For single-wall rooms, even a combination of a window and a ventilated door can help. Louvers, mesh panels, and clerestory windows can also boost ventilation without compromising privacy.





## WORKSPACE & STUDY INTEGRATION

The best location for a work/study corner is near a window for natural light. A desk should ideally face a blank wall or outward-facing window to reduce distractions. Floating desks, wall-mounted shelves, and vertical storage units help save floor space, especially in smaller bedrooms. Always leave at least 2.5'–3' clearance in front of the chair for legroom and movement.





# IDEAL DIMENSIONS FOR WORKSPACE DESIGNING

A comfortable study space should be at least 70 square feet, but ideally closer to 100-200 square feet for a dedicated room, according to design resources. The space should accommodate essential furniture like a desk, chair, and storage, while also allowing for comfortable movement. A good study desk should be around 28 to 30 inches high, with a width of at least 48 inches to accommodate books and other materials. Consider the placement of the study area, prioritizing natural light and minimal distractions.



# IDEAL DIMENSIONS FOR WORKSPACE DESIGNING

- **Bed Placement:**
  - Positioned centrally with clear circulation space on both sides. This allows for ease of movement and makes the room feel balanced.
- **Study Table Setup:**
  - A dedicated workspace is created near the bed, with a desk measuring:
    - Desk Width: 36"–48"
    - Desk Depth: 18"–24"
    - Minimum Legroom Depth: 18"
    - Chair Clearance: 30" minimum behind the desk.



- **Wall Shelf:**
  - Installed above the desk, 4'–5' from the floor, ensuring easy accessibility while keeping the worktop clutter-free.
- **Wardrobe:**
  - Located near the desk area without obstructing movement. Its placement optimizes storage without disrupting the study zone or blocking natural light from the window.
- **Window Placement:**
  - Right beside the bed and study desk, allowing natural light to flood both the sleeping and work areas — promoting better sleep and productivity.


# GUEST VS MASTER BEDROOM

**Guest Bedroom** is designed for short-term use — it's often compact, minimal, and multi-functional. It may double as a study, hobby room, or kids' room when not in use. While a guest room can include an attached bath, it's common to have shared or common bathroom access. These rooms are ideally located closer to the living area or entry for easy guest access, while still maintaining a buffer from the main activity zones.


GUEST BEDROOM



MASTER BEDROOM




**Master Bedroom** is typically the largest, most private, and most equipped bedroom in a house — reserved for the primary residents (often a couple). It usually includes an attached bathroom, large wardrobe, sometimes even a balcony, or a walk-in closet. Master bedrooms are ideally placed in quieter, more secluded corners of the home




## IDEAL MASTER BEDROOM

- Spacious Layout: Includes a large sleeping area, walk-in closet (W.I.C), seating space, and an attached bathroom.
- Dimensions:
- Sleeping Area: ~11'4" wide with a 9'4" bed placement.
- Walk-in Closet: 12'2" long corridor-style W.I.C.
- Bath Area: Private, well-proportioned (~9'8" x 15'4").
- Storage: Dedicated storage space outside the bathroom.
- Added Features: Includes a balcony/lounge with bifold doors, enhancing light and openness.



## LAYOUT OF MASTER BEDROOM


- Key Features:
- Interior Perspective View:
- A cozy, spacious bedroom with a king-size bed, bedside tables, and accent lighting.
- Large sliding bifold doors separate the main sleeping area from a lounge/balcony zone.
- Attached Master Bath includes a bathtub, toilet, vanity, and subtle storage.
- Floor Plan Dimensions:
- Bedroom Size: 12' x 15' — allows generous space for circulation and furniture.
- Lounge/Balcony: 8' x 6' seating zone ideal for relaxation, located beside the bifold doors.
- Master Bath: 6' x 9', efficiently laid out with clear zoning for bathing and toilet functions.
- Color Scheme:
- Earthy tones with calming accents — ideal for a restful private space.
- Neutral walls, soft green and beige furnishings, and warm wooden cabinetry complete the look.




## BEDROOM LAYOUT & PRIVACY

# LAYOUT OF GUEST BEDROOM


- Key Features:
- Interior Perspective View:
- A cozy, spacious bedroom with a king-size bed, bedside tables, and accent lighting.
- Large sliding bifold doors separate the main sleeping area from a lounge/balcony zone.
- Attached Master Bath includes a bathtub, toilet, vanity, and subtle storage.



- Floor Plan Dimensions:
- Bedroom Size: 12' x 15' — allows generous space for circulation and furniture.
- Lounge/Balcony: 8' x 6' seating zone ideal for relaxation, located beside the bifold doors.
- Master Bath: 6' x 9', efficiently laid out with clear zoning for bathing and toilet functions.
- Color Scheme:
- Earthy tones with calming accents — ideal for a restful private space.
- Neutral walls, soft green and beige furnishings, and warm wooden cabinetry complete the look.




# PLAN OF A GUEST BEDROOM




The bed is centrally placed against the solid wall for optimal stability and balance. Side tables on both ends offer convenience for personal items, while wall-mounted lights free up tabletop space and enhance nighttime visibility. A spacious wardrobe with three doors is positioned near the entrance, offering ample storage for clothes, luggage, and guest essentials. A bench or low console at the foot of the bed provides added seating or space for unpacking.

A spacious wardrobe with three doors is positioned near the entrance, offering ample storage for clothes, luggage, and guest essentials. A bench or low console at the foot of the bed provides added seating or space for unpacking. The clear floor space around the bed ensures ease of movement and accessibility. The room follows a minimalist approach with a muted, neutral color scheme, making it universally welcoming and easy to blend with most home aesthetics.




## THINGS TO CONSIDER

- **Natural Light from the Side:** The bed is placed perpendicular to the window, allowing guests to enjoy soft morning light without glare.
- **Solid Wall Support:** The bed rests against a solid wall, offering better headboard support and less exposure to cold or noise.
- **Improved Decor & Comfort:** A king-size bed is paired with:
  - Light curtains for controlled sunlight
  - A wall painting for visual interest
  - Indoor plants to freshen the space
- **Guest-Friendly Layout:** This arrangement ensures better airflow, reduced distractions, and a cozy yet polished look — perfect for short or long stays.




# BEDROOM LAYOUT & PRIVACY




*Image – Entry with three sitting and attached bathroom*



*Image – Contrast Wall with adjacent window for natural light.*



*Image – Entry with attached bathroom in glass enclosure style.*



*Image – Entry with traditional attached bathroom for convinience.*

### KEY TAKEAWAYS

- **Prioritize Privacy & Comfort:** The master bedroom should be located in the most private zone of the house, away from public areas like the living room or kitchen.
- **King-Sized Bed Orientation:** Place the bed on a solid wall with balanced access on both sides. Avoid positioning it directly under a window or facing the entrance.
- **Functional Furniture Layout:** Include essential furniture like side tables, wardrobes, and a laundry cabinet—ensuring all circulation paths are clutter-free.
- **Integrated Bathroom Access:** The attached bathroom should have direct yet subtle access, preferably placed adjacent to the wardrobe for convenience.
- **Natural Lighting & Ventilation:** Position windows strategically to bring in natural light from the side while maintaining privacy and minimizing glare.
- **Warm Aesthetic & Soft Furnishings:** Use rugs, lamps, and subtle decor like artwork or indoor plants to create a cozy and relaxing atmosphere.
- **Efficient Storage Zones:** Include his-and-her wardrobes or built-in storage to keep the space organized and visually clean.
- **Ergonomic Design Standards:** Maintain sufficient clearance (minimum 2'6") around the bed for easy movement and accessibility.


# Chapter 6

## BATHROOM PLANNING

## BATHROOM DESIGN GUIDE

This illustration breaks down bathroom design into three practical layouts (A, B, and C), each showing optimal circulation flow using arrows.

- **Layout A** is compact and suitable for narrow spaces. It separates the bathtub and WC effectively, maintaining circulation across zones. Ideal for quick-access bathrooms.
- **Layout B** offers a more rectangular shape, with a side-entry door and good alignment of the basin and WC. The layout balances privacy and function, commonly used in mid-sized homes or guest baths.
- **Layout C** shows a longer configuration with the most efficient flow. The door opens into a clear circulation path, with the basin and WC placed linearly for ease of use. Great for modern apartments and compact en-suites.




  
CIRCULATION  
DIAGRAM

## MINIMUM SIZES AND CLEARANCE


A well-designed bathroom balances utility and comfort — even within compact spaces. The key lies in understanding minimum dimensions required for fixtures, circulation, and accessibility. Whether designing a powder room or a full bath, these clearances ensure safe and comfortable use.

Standard Dimensions:

- WC Area (Toilet Zone): Minimum 30" (76 cm) wide x 48" (122 cm) deep
- Wash Basin: Requires at least 30" width for comfort and 21" clearance in front
- Shower Area: Minimum 30" x 30", but 36" x 36" is ideal for movement
- Bath Tub (if included): Standard size ~5' x 2'6" with 24" clear zone in front
- Door Size: Minimum 2'4" wide, preferably opening outward or as a sliding door



# MINIMUM STANDARD OF BATHROOM DIMENSIONS




The standard overall size for a small residential bathroom typically starts at 5' x 7' (1.5m x 2.1m), accommodating essential fixtures like a toilet, wash basin, and shower area. The minimum width for a water closet (WC) space is 30 inches (76 cm), with at least 21 inches (53 cm) of clearance in front of the toilet for legroom. Accessories such as towel bars and toilet paper holders should be mounted at accessible heights — typically 42 to 48 inches (107–122 cm) above the floor.

The wash basin requires a width of 30 to 36 inches (76–91 cm) and a minimum 21-inch front clearance for usability. Between two fixtures, a gap of at least 15 inches (38 cm) should be maintained from center to edge to avoid crowding. For the shower or glass enclosure area, a minimum internal size of 30" x 30" (76 cm x 76 cm) is essential, though 36" x 36" (91 cm x 91 cm) is considered ideal for comfort.




## MINIMUM STANDARD OF BATHROOM DIMENSIONS

The minimum layout measures 2.30m (width) × 1.20m (depth). The seated figure shows that each functional zone — including the basin and WC — is just within clearance norms, with 0.77m of width in front of each fixture and 1.20m total clearance from wall to wall. This layout meets bare minimum usability but offers limited comfort.






The ideal layout expands the room to 2.90m (depth) × 1.50m (width). The person seated on the toilet benefits from increased clearance — 0.90m of front space and 0.97m of side access — providing a more comfortable and user-friendly experience. Fixtures are spaced more generously, and circulation paths are easier to navigate.



# TOILET CLOSET STANDARDS

Top Design shows poor planning, where the toilet is directly visible from the door, compromising user privacy. The bottom layout (with tick mark) demonstrates an ideal design with proper zoning — placing the sink in the center as a buffer, and separating the toilet and shower areas for enhanced privacy. Dimensions are clearly labeled, and the soft color palette enhances visual clarity for professional presentation.



The sink is centrally positioned to act as a visual and functional buffer, ensuring no direct line of sight to the toilet or shower when the door opens. Measurements like 0.90m spacing per zone and a total width of 1.52m are clearly marked for reference. Soft, warm tones and human figures make the comparison intuitive and relatable — perfect for educational use or design handbooks focused on spatial planning and residential comfort.


# DRY VS WET ZONING IN BATHROOMS

The dry zone typically includes the wash basin, vanity, and storage units, while the wet zone comprises the shower area or bathtub and often the toilet. Separating these areas helps control moisture spread, reduces the risk of slipping, and keeps dry activities like grooming and dressing unaffected by water splashes.



A well-zoned bathroom usually positions the basin and mirror near the entry, creating a functional and clean transition space. The shower and WC are placed deeper into the room, often with partial walls, glass enclosures, or level differences to contain water. Even in compact bathrooms, smart layout planning can ensure this division is maintained without requiring extra square footage.


## IMPORTANCE OF DRY VS WET ZONING



The dry zone remains free from direct water exposure and typically includes the washbasin, mirror, towel rack, and storage cabinets. It allows for more design flexibility and easier maintenance. Clear zoning improves cleanliness, prolongs material life, and enhances user comfort by keeping the dry area usable even after a shower. In bathroom design, separating the space into dry and wet zones is essential for functionality, hygiene, and safety. The wet zone includes areas exposed to water, such as the shower, bathtub, and often the toilet. These areas require proper drainage, water-resistant materials, and anti-slip flooring to handle moisture and prevent accidents.


This area demands waterproofing membranes, non-porous tiles, and effective ventilation systems to reduce humidity buildup. Fixtures like showers and bathtubs are ideally placed in this zone with proper slope and drainage planning.

Meanwhile, the dry zone benefits from being shielded from excess moisture, making it ideal for features like mirrors, electrical points, storage units, and grooming counters. This helps maintain a cleaner, safer, and more organized space. Good bathroom design ensures that the dry zone is easily accessible upon entry, while the wet zone is positioned deeper inside — reducing splash, minimizing water spread, and improving privacy.







## BATHROOM LAYOUTS OVERVIEW

Bathroom layouts vary based on space and functionality. A Single Wall layout aligns all fixtures on one wall, ideal for compact spaces. The Galley or Two-Wall layout places fixtures on opposite walls, making it suitable for narrow bathrooms. L-Shaped layouts utilize two adjacent walls, efficiently separating wet and dry zones — great for corners. Meanwhile, U-Shaped layouts use three walls, offering maximum storage and movement in larger bathrooms. Choosing the right layout enhances comfort, circulation, and usability.




The showerhead is placed higher at 2.10 m, providing optimal overhead clearance and better water distribution. The shower niche is elevated to 0.35 m and starts at 1.10 m, offering easy access without bending. The total vertical height of 0.85 m for the shelf ensures practicality for storing bottles and toiletries comfortably.

# BATHROOM LAYOUTS



## KEY HIGHLIGHTS

The image highlights key differences between an incorrect and correct washbasin setup in residential bathroom design. In the incorrect setup, the countertop is too narrow (0.62 m width and 0.45 m depth), with a low basin height of 0.82 m, forcing the user into an uncomfortable posture. The mirror is also undersized and poorly aligned, reducing usability.



## TYPES OF SHOWER HEADS

This hand-drawn, sketch-style infographic illustrates six different types of shower heads, each designed for a unique bathing experience:

1. Handheld Shower Head
2. Ceiling Mount Rainfall
3. Wall-Mounted Rainfall Shower
4. Double Cascade Shower
5. Body Spray Shower System
6. Traditional Wall Mount



**1** HANHELD



**2** CEILING MOUNT RAINFALL



**3** RAINFALL



**4** DOUBLE CASCADE



**5** BODY SPRAYS




**6** WALL MOUNT



**6** WALL MOUNT

## CIRCULATION SPACE IN BATHROOM

This bathroom layout illustration demonstrates the essential circulation space required for functional and comfortable movement around key fixtures. Each fixture is placed considering ergonomic clearances:




- Toilet (WC): A clear space of 750–800 mm is maintained in front of the toilet for easy access, along with ~450 mm on either side for lateral comfort.
- Shower Area: Allocated a minimum area of 900×900 mm, ensuring ample room for movement and preventing water spillage into the dry zone.
- Washbasin: Positioned with at least 600–800 mm clearance in front, allowing users to stand and use the sink without feeling cramped.
- Door Planning: The layout encourages either an outward-opening door or a sliding door, preventing collision with internal fixtures and maximizing usable space.

# UNDER STAIR TOILET LAYOUT

This clever layout demonstrates an efficient use of space beneath a staircase to accommodate a compact yet functional bathroom. The design features two views:

**Side Elevation View:** The toilet is positioned at the area with maximum vertical clearance (213 cm or 84 inches). The front ceiling height tapers down to a minimum of 152 cm (60 inches) under the stairs, ensuring comfortable headroom at critical spots.

**Top View / Floor Plan:** The layout spans 152 cm (5 feet) in length and 91 cm (3 feet) in width. The toilet is placed centrally, with a basin in the front corner. The door opens inward, optimizing circulation space.



# BATHROOM PLANNING

## MASTER BATHROOM DESIGNING


The master bathroom is one of the most important spaces in a home, designed for both functionality and luxury. Its layout should provide ease of use while also serving as a relaxing, spa-like retreat. Thoughtful planning is crucial to ensure that the space meets the needs of the homeowners while also being aesthetically pleasing.

**Zoning:** In a master bath, it's essential to create distinct zones for the shower, bathtub, toilet, and sinks. This ensures that multiple people can use the space at the same time without disrupting one another. For example, place the toilet away from the bath or shower area for privacy.

**Size & Clearances:** A spacious master bath should ideally be around 10' x 12' (3m x 3.7m), with ample space for circulation. Each fixture should have a minimum clearance of 24" (61cm) in front for easy access, especially around the toilet and sink.



**Storage:** Incorporate plenty of storage for towels, toiletries, and cleaning supplies. Custom cabinetry, built-in shelves, or a linen closet can help keep the space organized.

**Natural Light & Ventilation:** Position windows or skylights strategically to bring in natural light and enhance the relaxing feel. Proper ventilation is critical in preventing humidity build-up, so an exhaust fan is a must.



## THINGS TO CONSIDER

This diagram provides a functional layout and key ergonomic dimensions for designing a master bathroom. The showerhead and shower seat are placed at optimal heights to ensure comfort and accessibility, while the pedestal sink is positioned at 32 inches, aligning with standard reach for most users. A towel bar placed at 48 inches allows easy access when exiting the shower or washing hands. The vanity sconces are aligned at eye level, ensuring optimal facial illumination without shadows. The toilet seat height of 17–19 inches supports comfort for a wide range of users, and a 26-inch clearance from the rim provides sufficient maneuvering space. Overall, this layout ensures ease of use, safety, and efficient circulation in a master suite.



The shower enclosure is shown with a height of 230 cm and width of 90 cm, accommodating both a fixed showerhead and handheld shower, with controls at reachable heights. The toilet seat height is 41 cm, with a clearance of 100 cm in front for ease of movement. The vanity counter sits at a comfortable height with adequate spacing for accessories like towel bars and mirrors. The mirror and shelf heights are aligned with ergonomic eye level for the average user. A small floor plan below illustrates an ideal compact layout, with minimum clearance zones of 100 cm in front of the vanity and toilet to maintain flow and usability.

## BATHROOM VANITY DESIGN CONSIDERATIONS


When designing a bathroom vanity, several key considerations ensure both functionality and aesthetics. First, size and proportions should match the bathroom's dimensions, allowing enough clearance for movement and door swings.

The countertop height is generally around 30–36 inches for comfort, while the depth should balance storage needs without encroaching on circulation space.

Sink placement is important — it should be centered for ease of use, with enough counter space on either side. Storage solutions like drawers, cabinets, or open shelves help keep essentials organized. Material selection is critical for durability in moisture-rich environments — opt for water-resistant finishes and easy-to-clean surfaces.


Lighting above or beside the mirror ensures proper visibility for grooming, while mirror size and placement should complement the vanity width.

Finally, consider plumbing access, future maintenance, and integration of modern features like under-cabinet lighting or built-in power outlets for maximum convenience.




## VANITY CONSIDERATIONS

The master bathroom is one of the most important spaces in a home, designed for both functionality and luxury. Its layout should provide ease of use while also serving as a relaxing, spa-like retreat. Thoughtful planning is crucial to ensure that the space meets the needs of the homeowners while also being aesthetically pleasing. This images illustrates the fundamental spatial requirements for bathroom fixtures, focusing on toilet and double vanity sink arrangements. It highlights the ideal clearances necessary for comfort and functionality.



For the toilet, a minimum side clearance of 15 inches (38 cm) from the centerline to any wall or obstruction, and a front clearance of 24 inches (61 cm), ensures ease of use and accessibility. The double vanity sink setup shows two basins separated by a 36-inch (91 cm) space, with an additional 18 inches (46 cm) of clearance on either side, allowing two users to operate comfortably at the same time. A front clearance of 24 inches (61 cm) in front of the sink area provides sufficient room for movement. The inclusion of human figures in the top view helps demonstrate how users interact with each space, reinforcing the importance of ergonomic planning. This layout is especially suitable for master bathrooms or shared washrooms where both functionality and personal space are essential.






# BATHROOM PLANNING

## VANITY DESIGNS IN BATHROOM



### Key Considerations for Bathroom Vanity Design

- Height: 750–900 mm for comfortable use
- Width: 600–900 mm (single) / 1200–1800 mm (double)
- Depth: 450–600 mm to balance space & storage
- Material: Moisture-resistant like marine ply or HDHMR
- Countertop: Durable options like quartz or granite
- Storage: Mix of drawers, cabinets, and organizers
- Mirror: Eye-level, width matching the basin
- Lighting: Side sconces or backlit mirror
- Sink Type: Countertop, undermount, or integrated
- Plumbing & Power: Concealed pipes, GFCI outlet nearby



## THUMB RULE IN DESIGNING



This diagram provides a functional layout and key ergonomic dimensions for designing a master bathroom. The showerhead and shower seat are placed at optimal heights to ensure comfort and accessibility, while the pedestal sink is positioned at 32 inches, aligning with standard reach for most users. A towel bar placed at 48 inches allows easy access when exiting the shower or washing hands. The vanity sconces are aligned at eye level, ensuring optimal facial illumination without shadows. The toilet seat height of 17–19 inches supports comfort for a wide range of users, and a 26-inch clearance from the rim provides sufficient maneuvering space. Overall, this layout ensures ease of use, safety, and efficient circulation in a master suite.



The shower enclosure is shown with a height of 230 cm and width of 90 cm, accommodating both a fixed showerhead and handheld shower, with controls at reachable heights. The toilet seat height is 41 cm, with a clearance of 100 cm in front for ease of movement. The vanity counter sits at a comfortable height with adequate spacing for accessories like towel bars and mirrors. The mirror and shelf heights are aligned with ergonomic eye level for the average user. A small floor plan below illustrates an ideal compact layout, with minimum clearance zones of 100 cm in front of the vanity and toilet to maintain flow and usability.

# BATHROOM CABINET CONSIDERATIONS

This bathroom vanity is a floating, double-sink design measuring 43.25 inches (110 cm) in width and 17.75 inches (45 cm) in depth, making it ideal for modern bathrooms with limited space. The countertop sits at a comfortable height of 30 inches (76 cm), while the mirror extends up to 52.75 inches (134 cm) from the floor, offering both practicality and visual balance. The vanity features a sleek deep teal cabinet with gold knobs, a white countertop with dual rectangular sinks, and a slim gold-framed mirror topped with a soft-glow overhead light.



The visual also emphasizes maintaining appropriate clearances for comfortable access, ensuring moisture-resistant materials to withstand bathroom humidity, and incorporating organized shelving for toiletries and daily essentials. Additionally, it shows how thoughtful cabinet height, depth, and positioning can enhance both the aesthetics and practical usability of the vanity area, while keeping the bathroom clutter-free and easy to maintain.

## KEY TAKEAWAYS

### Minimum Sizes & Clearances

- Small/Guest Bath: 1.2m × 2.1m (basic WC + shower).
- Standard Family Bath: 1.5m × 2.4m.
- Master Bath: 2.4m × 3.0m or larger.
- Clearance: At least 750–800mm in front of WC & basin.

### Zoning (Dry vs. Wet)

- Dry Zone: Basin, dressing, WC (ideally near entry).
- Wet Zone: Shower, bathtub (kept farthest inside).
- Use glass partitions/half walls for separation.

### Ventilation & Drainage

- Ventilation: Windows (0.5–0.6m<sup>2</sup>) or exhaust fans.
- Drainage Slope: 1:50 towards floor traps.
- Trap Placement: At least 1 per wet zone; avoid pooling.

### Fixture Standards

- WC: 0.7m × 1.2m minimum space.
- Shower: 0.9m × 0.9m enclosure recommended.
- Bathtub: Standard size ~1.5–1.8m × 0.75m.
- Vanity Basin: Counter height ~850mm, depth 450–600mm.

### Under-Stair & Compact Bathrooms

- Useful in small homes, but minimum headroom = 2.1m.
- Plan compact layouts: WC + shower with 0.8–0.9m clear passage.

### Master Bath Essentials

- Include double vanity, shower cubicle + tub, ample storage.
- Ensure luxury + privacy balance with natural light & ventilation.
- Maintain adjacency to master bedroom but with acoustic separation.



# Chapter 7

## VERTICAL CIRCULATION

## STAIRCASE TYPES & SPACE USE

### Introduction to Vertical Circulation

In residential design, vertical circulation refers to the movement of people and goods between different levels of a building. This includes staircases, ramps, elevators, and even ladders in certain compact or loft-style homes. A well-planned vertical circulation system ensures comfort, safety, and efficiency, while also influencing the overall architectural aesthetics. Poorly designed circulation can lead to bottlenecks, safety hazards, and an uncomfortable user experience, no matter how beautiful the rest of the home is.



Unlike horizontal movement, which is more intuitive and requires fewer safety considerations, vertical movement demands precise planning of dimensions, slopes, headroom clearance, lighting, and handrail placement. It not only serves a functional purpose but also offers opportunities to create a strong design statement—whether through a sculptural staircase in the living room, a discreet flight tucked into a corner, or a skylight-lit stairwell that becomes the focal point of the home.



## STAIRCASE TYPES & SPACE USE

### Straight Staircase – Pros, cons, ideal dimensions, best placements

A straight staircase is the simplest and most functional vertical circulation type. It consists of a continuous flight without turns, making it easy to design, build, and use. Its linear nature allows for efficient movement, clear sightlines, and straightforward integration into rectangular floor layouts.

### Ideal Dimensions (Indian Standards)

- Riser Height: 150–175 mm
- Tread Depth (Going): 250–300 mm
- Stair Width: 900–1200 mm (main stair), 750–900 mm (secondary/service stair)
- Slope: 30°–37°
- Headroom Clearance: Minimum 2.1 m
- Landing (if required): Minimum length = stair width




## STRAIGHT STAIRCASE

### Pros of Straight Staircase

- **Ease of Construction:** Simplest form to build with minimal structural complexity.
- **Cost-Effective:** Requires fewer materials and labor compared to complex designs.
- **Functional & User-Friendly:** Direct travel path without intermediate landings (unless added for safety).
- **Good for Moving Furniture:** Straight path facilitates shifting bulky items between floors.
- **Clear Lighting & Ventilation:** Can be placed against a wall or under a skylight for natural illumination.


### Best Placements

- **Along a Wall:** For space efficiency in narrow plans.
- **Near Entry Foyer:** Acts as a visual feature and directs movement upstairs without disrupting living areas.
- **Parallel to Living/Dining Wall:** Integrates circulation with open-plan interiors.
- **Under Skylight or Large Window:** Enhances brightness and makes the staircase a design focal point.
- **Against a Structural Core:** In duplex apartments or villas, central placement can balance circulation flow.



PLAN

SIDE ELEVATION



30°


## L-SHAPED / QUARTER TURN STAIRCASE

### Overview

An L-shaped stair turns 90° once (usually at mid-flight or near the top/bottom). The turn can be made with a landing (preferred for safety) or with winders (space-saving but stricter rules). It's popular in homes because it separates floors visually, fits corners well, and naturally creates a pause point.

### Ideal Placements (Indian Standards)

- Use the same comfortable run as straight stairs, with tweaks at the turn:
- Riser: 150–175 mm
- Tread/Going (rectangular treads): 250–300 mm
- Stair Width: 900–1100 mm (main stair); 750–900 mm (service)
- Slope: 30°–37°
- Headroom:  $\geq 2100$  mm over treads and landing
- Landing length (with landing turn):  $\geq$  stair width (e.g., 1000 mm wide stair  $\rightarrow$  1000 mm landing)
- Clear turning space: Keep newel/rail posts outside the walking line; avoid pinching the inside corner.
- If using Winders (space-saving option)
- Number of winders at 90°: typically 3 (balanced).
- Minimum going at narrow end:  $\geq 150$  mm (never knife-edge).
- Going at walk line:  $\geq 250$  mm measured 300 mm from the inner handrail.
- Keep the walk line smooth through the turn; avoid one oversized/undersized winder.



# VERTICAL CIRCULATION



## Best Placements

- Corner of living–dining core: Uses two walls, hides the upper floor.
- Near foyer with return: Turn helps create a feature wall under the lower flight.
- Duplex edge: Run along external wall, turn onto a windowed landing for daylight.
- Between private/public zones: Turn acts as a subtle threshold.

## Planning & Detailing Tips

- Choose landing vs winders intentionally:
- Landing: best for comfort, kids/elderly, and moving furniture.
- Winders: only when footprint is tight; follow strict goings.
- Natural light: Place a window/skylight at the landing to wash both flights.
- Handrails: Continuous through the turn; use a corner post or smooth bend.
- Under-stair use: Storage, study niche, or compact washroom (check headroom!).
- Acoustics & privacy: The turn reduces noise and views into upper floor.
- Safety: Anti-slip nosing, consistent risers, contrast strip at nosing on the turn.

## WINDER STAIRS AT 90°



## U-SHAPED / HALF TURN STAIRCASE

### Overview

A U-shaped staircase, also called a half-turn stair, consists of two flights running in opposite directions with an intermediate landing between them. This configuration makes a 180° turn, creating a compact, functional, and visually appealing circulation element. The design is popular in residential layouts where the staircase needs to fit within a smaller footprint but still provide comfort, safety, and design flexibility.


The half-turn layout works particularly well in homes with central cores, duplex apartments, or multi-level villas, as it reduces long, steep runs and provides a resting point mid-journey.

### Ideal Placements (Indian Standards)

- Riser: 150–175 mm
- Tread / Going: 250–300 mm
- Stair Width: 900–1100 mm (main stair), 750–900 mm (service stair)
- Landing Length: Equal to stair width or more (minimum 900 mm for standard residential)
- Slope: 30°–37°
- Headroom:  $\geq 2100$  mm measured vertically from tread to ceiling
- Handrail Height: 850–900 mm above tread nosing

### Advantages

- Space Efficiency: Fits in square or rectangular stair wells without requiring long linear runs.
- Safety: The landing provides a natural break, reducing fall risk and giving users a rest point.
- Furniture Handling: Easier to maneuver large furniture compared to L-shaped stairs.
- Design Opportunities: The central landing can be used for decorative lighting, windows, or as a viewing point.
- Privacy: The turn naturally blocks direct sightlines between floors.




# VERTICAL CIRCULATION

## Best Placements

- Central Core: Creates balanced circulation to both upper and lower floors.
- Near Entry Foyer: Adds a grand architectural element right at the entrance.
- Against Structural Wall: Reduces wasted space and makes use of the wall for railing support.

## Pro tips for Designers

- Ensure that landing dimensions meet code — cramped landings reduce usability.
- Use glass balustrades or open risers if you want to create a more open and airy feel.
- If possible, place a window or skylight over the landing for natural light.
- Integrate the staircase as a design statement, using materials like timber, steel, or stone to complement interiors.
- Always provide continuous handrails for safety and compliance.



# VERTICAL CIRCULATION

## SPIRAL STAIRCASE

### Overview

A spiral staircase is a compact vertical circulation solution where treads wind around a central column, forming a helical shape. It's often chosen for space-saving purposes or as a design feature in modern, industrial, or traditional interiors. While visually striking, it requires careful design to balance aesthetics, comfort, and safety.


Spiral stairs work well for secondary circulation (e.g., attic access, mezzanines, roof terraces) but are less ideal for main stairs in family homes due to tighter walking lines and limited furniture movement.

### Ideal Dimensions (Indian Standards)

- Diameter: 1500–2000 mm for comfortable residential use (minimum 1500 mm)
- Clear Walking Width: 600–900 mm at 500 mm from central column
- Tread Going (at walk line): 250 mm minimum
- Riser Height: 150–190 mm
- Central Column Diameter: 100–150 mm
- Headroom Clearance:  $\geq 2000$  mm
- Slope: Generally steeper than straight stairs,  $\sim 30^\circ$ – $38^\circ$

### Advantages


- Space Efficiency: Requires a small footprint, ideal for tight layouts.
- Aesthetic Appeal: Adds a sculptural element to the interior.
- Flexibility in Placement: Can be located in corners, courtyards, or central atriums.
- Cost-Effective in Metal Construction: Prefabricated spiral kits reduce labor time.




# VERTICAL CIRCULATION

## Best Placements


- Lofts & Mezzanines: Ideal where a full stair run is impossible.
- Garden/Patio Access: Adds charm while keeping space free.
- As a Feature Piece: In living areas, combined with statement lighting.
- Rooftop Access: Especially in duplexes or villas with terraces.





PLAN



DETAIL VIEW



DETAIL VIEW



## Pro tips for Designers

- Use wider diameters for more comfort if space allows.
- Contrast nosing strips help visually define treads.
- Handrails must be continuous and comfortable to grip.
- Non-slip tread surfaces are essential, especially for outdoor spirals.
- Avoid using spiral stairs as the only main access between frequently used floors.

# FLOATING & MODERN MINIMALIST STAIRCASE

### Overview

Floating staircases are a modern design statement where treads appear to “float” without visible supports. This effect is achieved using concealed stringers, cantilevered treads, or glass/steel supports integrated into walls. They are ideal for luxury residences, open-plan interiors, and spaces where lightness and transparency are priorities.


Minimalist floating designs often use glass balustrades, thin-profile treads, and hidden fixings to maintain a sleek, uninterrupted look.

### Ideal Dimensions (Indian Standards)

- Tread Thickness: 50–75 mm (varies by material and span)
- Riser Gap (if open):  $\leq 100$  mm for safety compliance
- Tread Depth: 250–300 mm
- Width: 900–1100 mm for main stairs
- Handrail Height: 850–900 mm above tread nosing
- Use tempered glass balustrades for a clean look without compromising safety.
- Integrate LED lighting under treads for night visibility and ambience.

### Advantages

- High Visual Impact: Creates a striking modern focal point.
- Openness & Light: Allows natural light to pass through, making spaces feel bigger.
- Material Flexibility: Works with wood, glass, steel, or stone treads.
- Customizable: Can be straight, L-shaped, U-shaped, or even helical.




# VERTICAL CIRCULATION

## Best Placements


- Central living room for a dramatic architectural statement.
- Along a window wall to enhance the floating effect with daylight.
- In open-plan lofts where transparency and minimalism are key.

## Pro tips for Designers


- Tread Thickness: 50–75 mm (varies by material and span)
- Riser Gap (if open):  $\leq 100$  mm for safety compliance
- Tread Depth: 250–300 mm
- Width: 900–1100 mm for main stairs
- Handrail Height: 850–900 mm above tread nosing
- Use tempered glass balustrades for a clean look without compromising safety.
- Integrate LED lighting under treads for night visibility and ambience.




WOODEN-TREADS



STEEL PLATE TREADS



CANTILEVER STEPS



WOOD & STEEL TREADS


## CURVED STAIRCASE

### Overview

A curved staircase features a smooth, continuous arc that can be either gentle or dramatic, depending on the radius. Unlike spiral stairs, curved stairs have a broader turning radius, making them more comfortable to walk on and suitable as a main staircase in luxury residences. They are often a centerpiece in foyers, lobbies, or open living areas, combining elegance with functionality.

### Ideal Dimensions (Indian Standards)

- Riser Height: 150–175 mm
- Tread Depth (at walk line): 250–300 mm
- Width: 1000–1500 mm for main staircases
- Slope: 30°–37° for comfort
- Radius: Gentle curves ( $\geq 3000$  mm radius) for primary stairs; tighter curves for secondary use
- Provide continuous handrail along the curve for safety.
- Use contrasting nosing strips to visually guide users.



### Advantages

- High Visual Impact: Serves as an architectural statement.
- Comfortable Walk: Larger radius ensures even tread widths along the walking line.
- Flexible Design: Can be paired with ornate railings, glass balustrades, or minimalist details.
- Adds Value: Often seen as a premium feature in property design.




# VERTICAL CIRCULATION

## Best Placements

- Grand entrance foyer
- Living/dining room as a central feature
- Connecting split-levels with style
- Hotel lobbies or high-end commercial spaces

## Pro tips for Designers

- Pick radius early —  $\geq 3000$  mm for comfort, tighter only for space-saving.
- Measure tread depth at walking line (250–300 mm).
- Position to frame views or act as a focal point.
- Use continuous curved handrails for seamless flow.
- Match materials to style — timber, stone, glass, or metal.
- Add LED strip lighting under treads or along rails.
- Keep riser gaps  $\leq 100$  mm for safety.
- Mock-up curve on site before construction.
- Align floor patterns with tread edges.
- Pair with statement lighting for impact.




- 1 Pick radius early**  
Pick radius early— $\geq 3000$  mm for comfort



- 2 Measure tread depth at walking line**  
(250–300 mm)



- 3 Use continuous curved handrails for seamless flow**




- 6 Match materials to style – timber, stone, glass, or metal**


- 7 Add LED strip lighting under treads or along rails**



- 7 Keep riser gaps  $\leq 100$  mm for safety**



- 9 Align floor patterns with tread edges**




# VERTICAL CIRCULATION

## Key Design Elements

- Walking Line: The path where tread depth is measured; keeps step sizes consistent.
- Balustrade Curve: Must match stair arc for safety & aesthetics.
- Structural Support: Usually a central spine, stringer beams, or embedded steel frame.
- Landing Integration: Often blends seamlessly without distinct landings.

## Material & Finish Options

- Steps: Marble, granite, timber, steel, concrete.
- Railings: Glass, stainless steel, wrought iron, wood.
- Treads: Can be cantilevered for a floating look.




## Pros

- Elegant focal point.
- Smooth, continuous flow without abrupt turns.
- Works well with premium finishes.

## Cons

- Costlier than straight or L-shaped stairs.
- Requires skilled labor for construction.
- Occupies more floor area.



## FLOATING & MODERN MINIMALIST STAIRCASES

### Overview


Floating and minimalist staircases are characterized by their open, airy structure, clean lines, and an emphasis on functionality with visual lightness. They often feature cantilevered treads, concealed stringers, and frameless or minimal railings.

### Ideal Dimensions (Indian Standards)

- Tread Depth
- 250–300 mm
- Riser Height
- 150–175 mm
- Stair Width
- 900–1200 mm
- Landing Depth
- Equal to stair width
- Handrail Height
- 900–1000 mm from tread nosing
- Gap Between Treads (if open)
- ≤ 100 mm for safety

### Key Features

- Wall-Mounted Cantilever: Treads fixed into RCC wall with steel supports.
- Central Stringer: Single steel beam with floating treads on either side.
- Suspended Steps: Supported by thin steel rods from above.
- Monolithic Concrete Floating Stairs: Minimalist look with solid appearance.




# VERTICAL CIRCULATION

## Safety Considerations


- Use anti-slip coating on treads.
- Ensure sturdy wall or frame support for cantilevered designs.
- Maintain railing height as per building codes.

## Material & Finish Options


- Wood: Warm, organic feel; use hardwood for durability.
- Steel: Industrial modern aesthetic; powder-coated finish for longevity.
- Concrete: Minimalist and durable; can be polished or textured.
- Glass: For treads or railings to maximize transparency.



PLAN



PLAN




SECTION

## Pros

- Sleek, modern, and airy visual appeal
- Maximizes natural light and openness
- Offers a premium, high-end design statement
- Highly customizable with multiple material options
- Concealed fixings for a clean, seamless finish
- Works well in compact layouts without feeling cramped
- Can increase property value with unique aesthetics

## Cons

- Higher cost due to precision engineering.
- Requires strong wall or steel spine for support.
- Safety concerns for children/elderly without riser closings.




## SPACE OPTIMIZATION TIPS – STORAGE UNDER STAIRS

### Overview

The space under a staircase is often underutilized, but with smart planning, it can serve as a functional and aesthetic asset in residential interiors. Designs should maximize storage while blending seamlessly with the staircase structure.


### Measurements (Indian Residential Standards)

- Minimum usable depth: 450–600 mm at front edge.
- Minimum height for comfortable access: 1800 mm (for walk-in under-stair use).
- Drawer height: 200–250 mm (shoe storage), 300–450 mm (general items).
- Shelf spacing: 300–400 mm for books/decor.




### Placement

- Works best for straight or L-shaped staircases with open sides.
- Consider visibility — hidden under-stair storage works well in transitional spaces, while display shelves suit living/dining rooms.



### Design Integration Tips

- Match cabinet finishes with tread or railing materials.
- Use hidden handles or push-to-open mechanisms for a seamless look.
- Integrate lighting inside shelves or display niches.
- Ensure adequate ventilation for enclosed spaces.



## VAASTU TIPS FOR UNDER STAIRS STORAGE USE

### Placement & Direction



The space under a staircase is often underutilized, but with smart planning, it can serve as a functional and aesthetic asset in residential interiors. Designs should maximize storage while blending seamlessly with the staircase structure.

### Placement & Direction

- Best Directions for staircase storage: South, West, or South-West parts of the house.
- Avoid North-East (Ishan Kon) for heavy storage, as it's considered the zone of divine energy and should be kept light and open.
- If the staircase is in the North, use storage for light, frequently used items only — avoid heavy objects.

### Suitable Uses

- Ideal for storage cupboards, drawers, bookshelves, or utility cabinets.
- Can also be used for shoe racks in the South or West zones (avoid in North-East).
- Store tools, cleaning items, seasonal items, or files — but avoid storing cash, jewellery, or important documents here.



# VERTICAL CIRCULATION

## Design & Energy Flow

- Keep the space clean, well-lit, and clutter-free to avoid negative energy.
- Use closed cabinets or drawers instead of open clutter to keep the energy balanced.
- Use light or earthy colours inside — avoid very dark shades.

## Items to avoid

- No water tanks, aquariums, or water elements under stairs.
- Avoid storing pooja items, religious books, or idols under stairs.
- Do not use the space as a toilet or bathroom unless it's in the South or West, and even then, follow proper Vastu remedies.

## Remedies if Under Stair Area is in Inauspicious Zone

- If the storage is in the North-East, keep it light and decorate with plants or spiritual symbols.
- Place a small copper wire pyramid or crystal to balance the energy.


### GOOD DIRECTIONS




### SUITABLE USES



### AVOID WATER




### AVOID RELIGIOUS ITEMS



## DESIGN RULES & RAILING SAFETY


### Standard Dimensions

- Rise 150–190 mm, Going 250–300 mm, Width  $\geq 900$  mm, Slope  $30^{\circ}$ – $35^{\circ}$ , Max 12–14 steps per flight, landing equal to stair width.



### Headroom Clearance


- Definition: Minimum vertical distance between the tread nosing and the ceiling or any overhead obstruction.
- Indian Standard: Minimum 2000 mm (2 m) clearance for comfort and safety.
- International Standard (IBC/IRC): 1980–2050 mm depending on jurisdiction.
- Design Tip: Maintain consistent clearance along the entire flight to prevent accidents.
- Special Cases: For spiral or curved stairs, clearance may reduce near the inner radius — keep it above 1900 mm where possible.



# VERTICAL CIRCULATION


## Railing Safety & Design

- Railing height – Indian standard (minimum 900 mm / 3 ft) vs. International codes.
- Grip design – Circular handrail diameter (30–50 mm) for comfortable grip.
- Child safety – Vertical baluster spacing  $\leq 100$  mm to prevent head entrapment.
- Material safety – Pros/cons of glass, steel, wood, mixed designs.
- Anti-slip & edge protection – Adding nosing strips, tactile indicators, or matte finishes.
- Aesthetic integration – Matching railing design to modern, classic, or industrial interiors.
- Code compliance diagrams – IS 4912 (India) + IBC (International Building Code) basics.



## Child Safety & Anti-Slip Considerations

- Railing Design for Kids: Use vertical balusters with gaps  $< 100$  mm to prevent head entrapment. Avoid horizontal bars that can be climbed.
- Railing Height: At least 900 mm (36") for safety; for small children, consider 1,000 mm (39").
- Edge Protection: Add rounded edges on treads and nosing to avoid injuries.
- Non-Slip Surfaces: Use anti-skid tiles, textured stone, or anti-slip adhesive strips. Avoid glossy finishes.
- Lighting: Adequate illumination to prevent tripping hazards, especially for night use.
- Safety Gates: For toddlers, install removable safety gates at top/bottom of stairs.



## MATERIAL TYPES AND USES

### Types of Wood (for railings, treads, and finishes)

- Teakwood – High durability, termite resistant, rich golden-brown color.
- Mahogany – Dense, strong, and has a deep reddish tone.
- Oak (Red/White) – Hard, heavy, and wear-resistant; widely used in premium staircases.
- Maple – Smooth, fine grain; good for modern, light-toned designs.
- Walnut – Rich dark brown, elegant appearance.
- Ash – Strong yet lightweight, flexible grain pattern.
- Sal Wood (Indian) – Common in India; durable and resistant to decay.



### Steel Grades (commonly used for railings and supports)

- Grade 202 Stainless Steel – Cost-effective, good for indoor railings (avoid coastal/high-moisture areas).
- Grade 304 Stainless Steel – Most common, corrosion-resistant, suitable for both indoor and outdoor use.
- Grade 316 Stainless Steel – Superior corrosion resistance, ideal for coastal or high-humidity locations.
- Mild Steel (MS) – Economical but needs powder coating or paint for rust prevention.
- Powder-Coated Steel – Mild steel with a durable powder finish for aesthetics and protection.



### Glass Specifications (for balustrades and railing infills)


- Toughened Glass – 8–12 mm thickness for residential use; 15–19 mm for heavy-duty/commercial use.
- Laminated Glass – Two sheets bonded with PVB layer for safety; remains intact even if broken.
- Frosted Glass – For privacy while maintaining light flow.
- Clear Float Glass – Standard transparent glass, often toughened or laminated.
- Tinted Glass – Bronze, grey, or green shades for aesthetics and UV control.
- Low-Iron Glass – Extra clear, no green tint, premium appearance.



## CODE COMPLIANCE (INDIAN BASICS)


### Core Rules (India)

- Rise (R): 150–170 mm (keep a single flight within  $\pm 5$  mm tolerance)
- Going (G): 270–300 mm (measured tread to tread, excluding nosing)
- Comfort rule:  $2R + G = 600\text{--}650$  mm (target 610–640 mm)
- Slope:  $30^\circ\text{--}35^\circ$
- Width (residential): main 1000–1100 mm (ok 900 mm in tight homes), service 800–900 mm
- Landing length:  $\geq$  stair width (never  $< 900$  mm)
- Headroom:  $\geq 2100$  mm along the nosing line
- Handrail height: 900–1000 mm from nosing; baluster gap  $< 100$  mm
- Open-riser gap:  $< 100$  mm; nosing projection 15–25 mm



### Ready-to-Build Packs (pick one per project)


- Pack A – Compact Home  
 $R = 165$  mm,  $G = 270$  mm  $\rightarrow 2R+G = 600$  mm; slope  $\approx 31^\circ$
- Width = 900–1000 mm, Nosing = 20 mm
- Pack B – Standard Comfort (recommended)  
 $R = 167$  mm,  $G = 280$  mm  $\rightarrow 2R+G = 614$  mm; slope  $\approx 30.5^\circ$
- Width = 1000–1100 mm, Nosing = 20 mm
- Pack C – Premium/Grand  
 $R = 170$  mm,  $G = 300$  mm  $\rightarrow 2R+G = 640$  mm; slope  $\approx 29.9^\circ$
- Width = 1200 mm, Nosing = 20–25 mm



# VERTICAL CIRCULATION

## Floor-to-Floor Examples (common Indian heights)

- 3000 mm FFL-to-FFL (typical duplex)
- Choose 18 risers →  $R = 166.7$  mm (ok)
- Straight: 17 treads ×  $G$  (e.g., 280 mm) = 4760 mm run
- L-shape: split 9 + 9 risers with landing ≥ width (≥ 1000 mm)
- U-shape: 9 + landing + 9; each flight run =  $9 \times 280 = 2520$  mm
- 2850 mm FFL-to-FFL
- 17 risers →  $R \approx 167.6$  mm (good)
- Flight run (9 treads @ 280) = 2520 mm; landing ≥ width
- 3300 mm FFL-to-FFL
- 20 risers →  $R = 165$  mm (best)
- Flight run (10 treads @ 280) = 2800 mm




## Curved & Spiral (India-friendly)

- Curved: inner radius ≥ 1500 mm; walking-line radius = inner radius + 500 mm; going at walking line ≥ 250 mm; inner-edge going ≥ 150 mm.
- Spiral (secondary access): diameter ≥ 1800 mm (1500 mm absolute min); walking width ≥ 750 mm;  $R \leq 180$  mm; going at walking line ≥ 250 mm; headroom ≥ 2000 mm.

## Tolerances & QC


- Max rise variation within a flight: ≤ 5 mm
- Tread variation: ≤ 5 mm
- Landing levelness: ≤ 5 mm across the landing
- Anti-slip nosing or texture on every tread; uniform lighting; no protrusions in the 2100 mm headroom envelope.



## SKYLIGHT & LIGHTING TIPS

### Purpose of Skylights

- **Daylighting:** Brings natural sunlight into spaces that would otherwise rely heavily on artificial lighting (e.g., internal bathrooms, staircases, corridors).
- **Energy Efficiency:** Reduces daytime electricity usage, especially in common areas.
- **Ventilation:** Operable skylights allow warm air to escape, improving cross-ventilation and indoor air quality.
- **Spatial Enhancement:** Makes rooms appear larger, brighter, and more inviting.
- **Highlighting Design Features:** Creates natural spotlight effects for architectural elements like staircases, indoor gardens, or feature walls.




### Benefits of Skylights in Indian Context

- **Cost Savings:** Lower electricity bills due to reduced artificial lighting use.
- **Thermal Comfort:** Modern double-glazed or heat-reflective skylights prevent excessive heat gain, crucial in hot climates.
- **Improved Well-being:** Natural light is proven to boost mood, productivity, and regulate sleep cycles.
- **Eco-Friendly:** Supports sustainable building practices by reducing carbon footprint.
- **Aesthetic Appeal:** Adds architectural interest and premium value to the property.

### Purpose of Artificial Lighting

- While skylights work during the day, artificial lighting ensures functionality after sunset and in shaded areas. A layered lighting approach — ambient, task, and accent lighting — ensures every space remains well-lit and comfortable at all times.



# TYPES OF SKYLIGHTS & IDEAL PLACEMENT FOR INDIAN HOMES


### Fixed Skylights

- Description: Non-opening, sealed units that bring in light without ventilation.
- Ideal Use in India: Best in AC rooms or where dust and insects are a concern.
- Placement:
  - Above stairwells, galleries, or central corridors.
  - Sloped roofs to avoid water pooling.




### Ventilated Skylights

- Description: Can be opened manually or electronically for air circulation.
- Ideal Use in India: In kitchens, bathrooms, or lofts to release heat buildup.
- Placement:
  - Ensure they face away from dust-heavy wind direction.
  - Fit insect mesh for Indian climates.



### Tubular/Light Tube Skylights

- Description: Uses reflective tubes to channel sunlight into small/dark spaces.
- Ideal Use in India:
  - Pooja rooms, small offices, or internal corridors.
  - Areas without direct roof access.
- Placement: Keep tube length minimal for better brightness.



# VERTICAL CIRCULATION

## Pyramid/Dome Skylights

- Description: Elevated or dome-shaped units allowing sunlight from all angles.
- Ideal Use in India:
  - Large lobbies, atriums, commercial halls.
  - Areas needing dramatic daylight effect.
- Placement: Avoid south-facing in very hot climates.




## Custom/Architectural Skylights

- Description: Tailor-made shapes for design statement + daylighting.
- Ideal Use in India: Premium residences, resorts, public spaces.
- Placement:
  - Combine with shading devices to avoid glare.
  - Use laminated glass for safety.



## Placement Principles for India


- Direction: North-facing for soft, consistent light; avoid harsh south-west glare.
- Slope: Minimum  $15^\circ$  for rainwater runoff.
- Glass Choice: Low-E coated, laminated safety glass for heat & UV control.
- Shading: Integrate blinds or louvers for seasonal comfort.



# ARTIFICIAL LIGHTING LAYERING – AMBIENT, TASK, ACCENT

### Ambient Lighting (General Illumination)

- Purpose: Provides overall uniform light across the room.
- Examples: Ceiling-mounted fixtures, chandeliers, recessed lights.
- Design Note: Should be glare-free and evenly distributed. Warm white (2700K–3000K) works best for comfort in living and bedrooms, while neutral white (3500K–4000K) suits kitchens and work areas.



### Task Lighting (Focused Illumination)

- Purpose: Supports specific activities like reading, cooking, grooming, or working.
- Examples: Pendant lights over kitchen counters, study lamps, vanity mirrors with LED strips.
- Design Note: Use bright but controlled lighting (around 4000K–5000K) with adjustable direction. Ensure no shadows fall on the working surface.



### Accent Lighting (Highlighting Features)


- Purpose: Adds drama and visual interest by highlighting architectural elements, artworks, or textures.
- Examples: Wall washers, spotlights, cove lights, backlit panels.
- Design Note: Use accent lighting sparingly (about 3–5 times brighter than ambient). Warm tones enhance textures and depth.



## LANDING SIZE & WIDTH RULES


### Standard Landing Rules

- Width of Landing = Width of Staircase
- (Minimum 900 mm for residential; 1200–1500 mm preferred in public/commercial).
- Length (Depth) of Landing
- At least equal to stair width.
- For staircases >3 m rise without break → landing is compulsory.
- Clear Headroom: Minimum 2.1 m (7 ft) to avoid discomfort.



### Turning & Intermediate Landings

- 90° or 180° Turns: Landings must be wide enough to allow safe and smooth turning without obstruction.
- For wheelchair accessibility: Minimum 1500 mm × 1500 mm turning space recommended.
- Intermediate Landings: Required after 12–15 risers for comfort.



### Door & Corridor Considerations

- Door opening onto a landing: Landing must be minimum 900 mm deep beyond door swing.
- Corridor/Stair interface: Landing should not feel cramped; align width with corridor dimensions.


### Special Cases

- Fire Exit Stairs: Wider landings (minimum 1500 mm) for evacuation safety.
- External Stairs: Ensure weather protection, anti-slip surface, and proper water drainage.

# VERTICAL CIRCULATION


## Standard Landing Rules

- Width of Landing = Width of Staircase
- (Minimum 900 mm for residential; 1200–1500 mm preferred in public/commercial).
- Length (Depth) of Landing
- At least equal to stair width.
- For staircases >3 m rise without break → landing is compulsory.
- Clear Headroom: Minimum 2.1 m (7 ft) to avoid discomfort.




## Turning & Intermediate Landings

- 90° or 180° Turns: Landings must be wide enough to allow safe and smooth turning without obstruction.
- For wheelchair accessibility: Minimum 1500 mm × 1500 mm turning space recommended.
- Intermediate Landings: Required after 12–15 risers for comfort.




## Door & Corridor Considerations

- Door opening onto a landing: Landing must be minimum 900 mm deep beyond door swing.
- Corridor/Stair interface: Landing should not feel cramped; align width with corridor dimensions.



## Special Cases

- Fire Exit Stairs: Wider landings (minimum 1500 mm) for evacuation safety.
- External Stairs: Ensure weather protection, anti-slip surface, and proper water drainage.



# KEY TAKEAWAYS

- **Landings:** Depth = stair width (minimum).
- Turning landings needed at direction changes.
- Clear of obstructions; extend adequately at door swings.
- **Width Rules:** Main stairs: 1.5–2.0 m (public); 1.0–1.2 m (residential).
- Service stairs: 0.75–0.9 m.
- Stair width should align with adjoining corridor width.
- **Doors & Corridors:** Doors must not reduce landing width.
- Minimum 900 mm corridor clearance near stairs.
- Prefer outward opening doors away from stair path.
- **Natural Lighting (Skylights):** Place facing north/north-east in India.
- 15° slope for rainwater runoff.
- Use low-E laminated safety glass for UV/heat control
- **Artificial Lighting:** Ambient: uniform, general lighting.
- Task: brighter lights on steps/handrails.
- Accent: highlight walls, railings, or art.
- **Safety & Comfort:** Continuous, ergonomic handrails.
- Headroom: minimum 2.1 m.
- Non-slip finishes & tactile strips for safety.
- Louvers/blinds in skylights for seasonal comfort.


# Chapter 8

## FACADE AND ELEVATION DESIGNS

## MASSING & SHAPE

### Importance of Form & Silhouette

- The first impression of a house comes from its massing — the way volumes, voids, and overall silhouette interact. A well-balanced mass ensures harmony between function and visual identity. A poor massing can make even luxurious finishes look unappealing.



### Symmetry vs. Asymmetry

- Symmetrical façades create a sense of order, tradition, and balance — often seen in classical and colonial homes.
- Asymmetrical façades bring modern dynamism, allowing unique proportions, creative voids, and personalized elevation expression.



### Layering Volumes for Depth

- Façades look flat when treated as a single surface. Depth can be added by layering walls, projecting balconies, recessed windows, and varying rooflines. This layering creates shadows, visual interest, and a sense of richness.



### Key Design Principles

- Maintain hierarchy of volumes (main block vs. secondary blocks).
- Keep scale human-centric, avoiding oversized voids.
- Respect proportion between height, width, and openings.



- Use bold, simple geometric forms



- Go for solid, grounded shapes

- Combine & balance volumes



## BALANCED OPENINGS & PROPORTIONS

### Importance of Form & Silhouette

- A well-designed façade depends heavily on the proportion and placement of its openings. Doors, windows, and voids must follow a sense of balance to create harmony and visual comfort. Disproportionate or randomly placed openings can disturb the elevation, making the structure look unorganized or unstable.

### Key Points:

- Symmetry vs. Asymmetry: Openings should either follow a symmetrical rhythm (classical approach) or a deliberate asymmetry (modern approach) that still maintains balance.
- Vertical Balance: Openings stacked directly above one another strengthen the structure's rhythm.
- Horizontal Alignment: Windows and doors aligned along a horizontal datum create a neat visual order.
- Proportion Guidelines: Ratios like the Golden Ratio or Rule of Thirds help determine ideal sizes and spacing of openings.
- Human Scale: Openings must respect functional comfort (standard window sill height, door width, etc.) to remain user-friendly while aesthetically balanced.



- Arrange windows evenly & symmetrically



- Aim for mostly tall, vertical openings



GROUND FLOOR  
TOO OPEN



BALANCED  
ARRANGEMENT

- Ensure a sense of visual balance


## SHADING DEVICES & SUN CONTROL

### Introduction

- One of the most important aspects of façade design in warm climates like India is controlling heat gain and glare while maintaining natural light and ventilation. Shading devices, if designed well, enhance both energy efficiency and aesthetic character of the building. The principle is simple: stop harsh sun before it enters the interior.


### Key Principles of Shading

- Orientation Matters:
  - North façade: minimal shading required.
  - South façade: horizontal projections like overhangs, balconies, pergolas are effective.
  - East & West façades: vertical fins, louvers, or dense vegetation work best.
- Seasonal Response:
  - Summer → block direct sunlight to cut heat gain.
  - Winter → allow lower-angle sun to penetrate for warmth.
- Human Comfort: Prevents glare inside spaces, making living areas and workspaces more comfortable.



### Sun Control Techniques

- Brise-Soleil (Sun Breakers): Architectural extensions designed to block sunlight while allowing ventilation.
- Double Skin Façades: Outer shading layer with glass behind, reducing heat gain.
- Solar Shading Glass: Low-E coated or fritted glass reduces UV and IR penetration.
- Smart Solutions: Automated blinds and louvers integrated with sensors for real-time control.




# FACADE AND ELEVATION DESIGNS

## Types of Shading Devices

### 1. Horizontal Overhangs

- Best suited for south-facing façades in hot climates.
- Blocks high summer sun but allows low winter sun to enter.
- Common examples: chajjas, canopies, balconies.




### 2. Vertical Fins (Louvers/Jalis)

- Best suited for south-facing façades in hot climates.
- Blocks high summer sun but allows low winter sun to enter.
- Common examples: chajjas, canopies, balconies.

### 3. Brise-Soleil (Sun Breakers)

- A system of fixed or movable panels projecting from the façade.
- Famous in tropical modernism, popularized by Le Corbusier.
- Provides strong shading with architectural expression.



### 4. Double-Skin Facades

- A modern energy-efficient strategy.
- An additional external glass layer creates a buffer zone, reducing heat gain.
- Allows integration of operable louvers or blinds within the cavity.

### 5. Double-Skin Facades

- Specialized glazing with coatings that reflect infrared radiation while transmitting visible light.
- Minimizes air-conditioning load without making interiors too dark.

## ROOF FORMS & PARAPET DESIGN

### Common Roof Forms

#### 1.Flat Roofs

- Suitable for urban residences.
- Often used for terraces, service areas, and solar panels.
- Require careful drainage planning.

#### 2.Pitched/Gable Roofs

- Traditional form, common in areas with heavy rainfall or snow.
- Efficient in draining water and protecting interiors.
- Adds strong character to elevation.

#### 3.Hip Roofs



- A system of fixed or movable panels projecting from the façade.
- Famous in tropical modernism, popularized by Le Corbusier.
- Provides strong shading with architectural expression.

#### 4.Curved or Shell Roofs

- A modern energy-efficient strategy.
- An additional external glass layer creates a buffer zone, reducing heat gain.
- Allows integration of operable louvers or blinds within the cavity.

#### 5.Combination Roofs

- Merge flat, sloping, and curved elements for visual balance.



# FACADE AND ELEVATION DESIGNS

## Parapet Functions

- Safety barrier
- Wind deflector
- Screen for rooftop utilities
- Aesthetic finishing element

## Types of Parapets

### 1.Plain Parapet

- Simple, low wall for safety.
- Common in residential terraces.

### 2.Embattled/Decorative Parapet

- Historically used in fortifications.
- Adds character to elevations.

### 3.Perforated/Jali Parapet



- Combines safety with ventilation and light play.
- Useful in hot climates.

### 4.Glazed/Modern Parapet

- Glass, steel, or composite finishes.
- Provides a sleek, contemporary look.

## Design Considerations

- Proportion: Roof pitch and parapet height should relate to building scale.
- Materiality: Tiles, concrete, glass, or brickwork chosen to match façade.
- Climate: Steeper roofs for rain/snow; flat roofs for usable terraces.
- Integration: Parapets should merge with façade lines rather than appear as afterthoughts.




## EXTERIOR FINISH TYPES

### Introduction to Exterior Finishes

Exterior finishes are the outermost protective and aesthetic layer of a building. Their role goes far beyond decoration; they influence the durability, weather resistance, thermal comfort, and identity of a structure.


### Functional Role

- Protects building fabric from rain, UV radiation, wind, and temperature fluctuations.
- Provides a barrier against moisture penetration and surface deterioration.
- Reduces heat gain/loss, improving indoor comfort.
- Offers sound insulation in urban contexts.



### Aesthetic Role

- Defines the character and style of the building — modern, traditional, industrial, or organic.
- Supports architectural language: e.g., glass for sleek modernism, stone for monumental weight, timber for warmth.
- Plays a role in brand identity in commercial architecture.



### Economic Role

- Exterior finishes directly impact construction costs and lifecycle maintenance.
- High-end finishes may be costly upfront but reduce long-term repair costs.
- Poorly chosen finishes often lead to early deterioration and repainting/replacement expenses.

### Environmental & Climatic Response

- In hot climates: reflective or light-colored finishes minimize heat absorption.
- In humid zones: finishes must resist algae, moss, and efflorescence.
- In cold climates: finishes should tolerate freeze-thaw cycles without cracking.

# FACADE AND ELEVATION DESIGNS

## Natural Stone Finishes

Natural stone has been used for centuries as one of the most prestigious and durable finishes. Each stone type offers distinct aesthetic, structural, and climatic properties.

## Types of Natural Stones

### Granite

- Hard, dense, and weather-resistant.
- Wide color range: black, grey, pink, red.
- Used in monumental and commercial projects for luxury appeal.
- Drawback: Expensive, heavy, requires strong structural support.

### Marble

- Elegant veining, smooth finish.
- Associated with heritage, luxury, and interiors (e.g., Taj Mahal).
- Vulnerable to acid rain and pollution → surface pitting, discoloration.
- High maintenance — requires sealing and periodic polishing.


### Sandstone

- Widely used in India (e.g., Red Fort, Jaipur palaces).
- Warm earthy tones (red, buff, yellow, beige).
- Easy to carve; suitable for traditional/vernacular architecture.
- Weathering issues in polluted cities; prone to erosion.

### Slate

- Dark grey/black finish with natural cleft texture.
- High water resistance, suitable for roofing and cladding.
- Aesthetic: bold, rustic, modern industrial.
- Drawback: brittle, requires careful handling.

## NATURAL STONE FINISHES



**Taj Mahal**  
MARBLE



**Red Fort**  
SANDSTONE

## BRICK & MASONRY FINISHES

### Types of Masonry Finishes



- Rubble Masonry
- Rough stones arranged irregularly; used for rustic and rural aesthetics.
- Ashlar Masonry
- Precisely cut and polished stones for a high-quality, elegant finish (seen in monuments, temples, and palaces).
- Stone Cladding
- Thin stone veneers attached to walls for premium, natural appeal.
- Pointing Styles
- Different mortar finishes (flush, recessed, struck, weathered) that influence the character of masonry walls.

### Functional Roles

- Weather Resistance: Protects structure from rain, wind, and temperature fluctuations.
- Durability: Both brick and stone can last centuries with minimal maintenance.
- Thermal Insulation: Provides natural cooling in summer and warmth in winter.
- Fire Resistance: Bricks and stones are naturally fireproof, improving safety.

### Aesthetic Roles


- Texture & Depth: Adds richness and variation to façades.
- Cultural Identity: Heritage structures like forts, temples, and colonial buildings often feature distinctive masonry.
- Color Palette: From warm earthy tones of red brick to the royal elegance of sandstone and marble.
- Symbol of Prestige: High-quality stonework often signifies wealth, legacy, and craftsmanship.



# FACADE AND ELEVATION DESIGNS


## Thermal Performance of Masonry Walls

- Thermal Mass Effect:
- Masonry has a high thermal mass, meaning it absorbs heat during the day and releases it slowly at night. This helps moderate indoor temperatures in hot climates but can be a disadvantage in cold climates without proper insulation.
- Insulation Role:
- Bare masonry has low thermal resistance (R-value). Adding plaster, insulation boards, or cavity walls significantly reduces heat transfer. Exterior finishes like EIFS (Exterior Insulation and Finish Systems) also enhance performance.
- Surface Colour Impact:
- Light-coloured finishes reflect solar radiation, keeping walls cooler.
- Dark finishes absorb heat, which may increase indoor discomfort if not balanced with insulation.




## Moisture-Related Problems

- Absorption & Porosity:
- Bricks and stones are porous; they absorb rainwater which can lead to damp patches, efflorescence, and frost damage in colder regions.
- Capillary Rise:
- If damp-proof courses are absent or defective, water rises through brick pores, causing plaster peeling, salt deposits, and mould growth.
- Condensation:
- Temperature differences between interior and exterior surfaces can lead to interstitial condensation, damaging finishes and encouraging microbial growth.



## Preventive Measures


- Protective Coatings:
- Applying breathable water-repellent coatings prevents rain penetration while allowing trapped vapour to escape.
- Proper Pointing:
- Well-maintained mortar joints reduce water ingress.
- Overhangs & Drip Edges:
- Architectural features like shading devices and parapet copings prevent direct water impact.
- Ventilated Cavity Walls:
- Keeping an air gap between outer and inner layers reduces thermal bridging and directs moisture away.



## PLASTER & PAINTED FINISHES

### Smooth Cast Plaster

- Description: A uniform, fine-textured plaster applied with steel trowels to achieve a very smooth finish.
- Applications: Modern houses, office interiors, showrooms.
- Advantages: Provides a sleek background for paints; enhances reflectivity of light.
- Limitations: Can show cracks easily if not cured properly.



### Rough Cast (or Spatter Dash) Plaster


- Description: A coarse mixture of cement, sand, and gravel is dashed onto the surface, creating a rugged texture.
- Applications: External walls of cottages, rustic villas, and heritage-style buildings.
- Advantages: Very durable; hides unevenness in walls; resists weathering.
- Limitations: Difficult to repair once damaged

### Textured Plaster

- Description: Achieved by using special tools or rollers to create geometric, wavy, or patterned effects while plaster is still wet.
- Applications: Contemporary interiors, feature walls, corporate lobbies.
- Advantages: Decorative appeal, eliminates need for wallpapers.
- Limitations: Requires skilled workmanship.

### Stucco Plaster

- Description: A traditional plaster finish made of lime or cement, often molded into decorative shapes.
- Applications: Colonial-style bungalows, institutional buildings.
- Advantages: Elegant; can be sculpted into cornices, moldings, or relief patterns.
- Limitations: Labour-intensive; requires periodic maintenance.




**Roughcast Plaster  
+ Cement Paint**

# FACADE AND ELEVATION DESIGNS


## Acoustic & Special Plasters

- Description: Plasters mixed with fibrous materials for sound absorption, or additives for fire resistance.
- Applications: Auditoriums, theaters, recording studios.
- Advantages: Improves performance beyond aesthetics.
- Limitations: Expensive and specialized.

## ACOUSTIC & SPECIAL PLASTERS



ACOUSTIC PLASTER



ACOUSTIC PANEL PLASTER



WATERPROOF PLASTER



FIRE-RESISTANT PLASTER

## Paint Finishes

### Distemper

- Composition: Water-based, made from chalk, lime, and pigments.
- Uses: Low-cost interior walls in residential buildings.
- Pros: Cheap, easy to apply.
- Cons: Poor durability, not washable.

### Emulsion Paint


- Composition: Water-based synthetic resins.
- Uses: Most common for interior & exterior walls.
- Pros: Washable, durable, wide color range.
- Cons: Requires well-prepared surface.

### Oil-Based Paints

- Composition: Pigments + linseed oil or alkyd medium.
- Uses: Woodwork, metal railings, doors, and furniture.
- Pros: Smooth glossy finish, water-resistant.
- Cons: Slow drying, may yellow with time.

### Cement Paint

- Composition: White/colored cement with pigments.
- Uses: Exterior surfaces of low-cost housing.
- Pros: Weather-resistant, economical.
- Cons: Limited smoothness, absorbs moisture.



# FACADE AND ELEVATION DESIGNS

## Enamel Paints

- Composition: Pigments + varnish.
- Uses: High-end finishes on wood, steel, kitchen, bathrooms.
- Pros: Glossy, hygienic, long-lasting.
- Cons: Expensive; requires careful application.

## Plastic Paints

- Description: A luxurious paint type offering matte, satin, or semi-gloss finishes.
- Applications: Hotels, high-end residences, showrooms.
- Advantages: Long life, easy cleaning, premium aesthetics.
- Limitations: Expensive.


## Textured & Decorative Paints

- Description: Paints that include aggregates or additives for stone-like, metallic, or fabric-like effects.
- Applications: Accent walls, exteriors, feature partitions.
- Advantages: Adds depth and richness.
- Limitations: Higher cost and maintenance.

## Functional Roles of Plaster & Paint

- Protection from weather: Seals masonry against rain, moisture, and dust.
- Thermal comfort: Certain plasters add insulation.
- Durability: Prevents cracks and surface erosion.
- Hygiene: Painted finishes allow washable and stain-resistant surfaces.
- Fire & Acoustic resistance: Special plasters enhance building performance.

## FUNCTIONAL ROLES OF PLASTER & PAINT




## WOOD & TIMBER FINISHES

### Types of Wood Finishes

#### Polish Finishes

- French Polish: A traditional high-gloss finish using shellac, giving a rich depth to natural grains.
- Wax Polish: Produces a soft sheen, ideal for antique furniture, but requires frequent re-application.




#### Oil Finishes

- Linseed Oil: Penetrates deep, enhancing natural tones but takes long to dry.
- Tung Oil: Water-resistant and durable, giving a matte to semi-gloss finish.

#### Varnishes & Lacquers

- Varnish: Transparent protective coating, resistant to scratches and heat.
- Lacquer: Quick-drying, high-gloss finish that provides a smooth, durable surface.




#### Painted Finishes

- Used when color is more important than visible grain. Provides protection along with decorative flexibility.

#### Stains & Sealers

- Stains: Change the wood color while keeping grain visible.
- Sealers: Form a protective base layer to enhance durability and prevent moisture penetration.



## METAL CLADDING & FINISHES

### Types of Metal Cladding

#### Aluminum Panels

- Lightweight and corrosion-resistant.
- Available in anodized or powder-coated finishes.
- Popular for commercial façades and curtain walls.

#### Steel Cladding

- Galvanized or stainless options.
- Very strong and highly durable.
- Used in industrial, high-rise, and infrastructural projects.

#### Copper Sheets

- Develop a natural green patina over time.
- Elegant, premium finish for heritage or luxury buildings.

#### Zinc Panels

- Highly malleable, self-healing against scratches.
- Long lifespan with a natural matte finish.

#### Bronze / Brass

- Rich, warm appearance.
- Often used for decorative façade panels, entrances, and cultural institutions.

#### Surface Finishes for Metals

- Brushed Finish → Subtle linear texture, reduces glare.
- Polished / Mirror Finish → Reflective, glossy, modern aesthetic.
- Powder-Coated → Colored protective layer, customizable shades.
- Anodized → Enhances corrosion resistance, adds metallic tones.
- Patinated Finish → Naturally aged look, especially for copper and bronze.

### METAL CLADDING & FINISHES



Brushed stainless steel or aluminum




Standing seam panels



Weathered copper



Corrugated metal



## KEY TAKEAWAYS

When deciding between different finishes, consider the following factors:

### Functionality

- Wet areas (bathrooms, kitchens): Avoid wood; prefer tiles, plaster with protective paints, or metal cladding.
- High-traffic areas: Durable finishes like roughcast plaster, laminates, or metal sheets.

### Aesthetics

- Luxury/heritage look: Stucco, timber, or decorative paints.
- Contemporary/minimalist: Smooth plaster with emulsion, or sleek metal cladding.

### Budget

- Low-cost: Cement paint, emulsion on plaster.
- Mid-range: Laminated wood, textured plaster.
- Premium: Stucco, veneers, metal cladding.

### Climate & Durability

- Humid/tropical: Avoid wood unless treated; prefer plaster + emulsion or metal cladding.
- Dry climates: Wood and textured plaster last longer.
- Coastal: Metal cladding with anti-corrosion treatment.

# Chapter 8

## OUTDOOR & SERVICE ZONES

# BALCONY, SIT-OUT & GARDEN AREAS

### Balcony Design Considerations

- Orientation: East- and north-facing balconies are preferred for morning light and cooler shade.
- Safety & Railing: Minimum railing height of 1.1 m with sturdy materials like steel, glass, or timber.
- Weather Protection: Use of pergolas, canopies, or overhangs to shield from rain and harsh sun.
- Integration with Interiors: Sliding glass doors or French windows enhance the visual flow.

### Sit-out Planning

- Scale & Comfort: Can range from a small 2-seater porch to a large covered veranda.
- Furniture: Outdoor-grade chairs, swings, or loungers with weather-resistant materials.
- Ambience: Lighting, planters, and flooring treatments (like wooden decking or stone paving).
- Privacy: Screens, planters, or lattice walls to maintain a cozy, intimate feel.

### Garden Areas

- Zoning: Divide into functional areas – lawn, flower beds, herb/vegetable patches, and relaxation corners.
- Planting Strategy: Mix of shrubs, seasonal flowers, and shade trees.
- Hardscape Elements: Pathways, seating platforms, pergolas, and water features.
- Maintenance: Drip irrigation, proper drainage, and compost pits.


### Design Integration Tips

- Combine balconies with planters and creepers to merge with garden views.
- Use sit-outs as buffer zones between main building and landscape.
- Keep circulation free-flowing so balconies and gardens feel connected.
- Ensure barrier-free access for elderly or differently-abled residents.

## Balcony, Sit-Out & Garden Areas

### Balcony Concepts

- Size & Proportion: Width at least 1.2 m, with enough depth to allow seating.
- Safety: Railings minimum 1.05 m high, made of metal, glass or concrete.
- Flooring: Non-slip, weather-resistant tiles, rough stone, or treated wood.
- Drainage: Slope to direct rainwater away; no water stagnation



Approximately  
1.2 m  
minimum



# OUTDOOR & SERVICE ZONES

## Balcony Proportions



- A well-designed balcony should be at least 1.2–1.5 m deep to allow comfortable seating.
- For dining or extended use, 2–2.5 m depth works better.
- Width depends on building façade — small balconies can be 2–3 m wide, while larger ones can extend up to 5–6 m for shared spaces.
- Overhang should balance aesthetic appeal and structural safety.

## Railing Height

- Standard railing height: 1.05 m (1050 mm) from finished floor level.
- For high-rise buildings, many codes recommend 1.2 m (1200 mm) for added safety.
- Railings should not have horizontal gaps that allow children to climb. Vertical spacing:  $\leq 100$  mm.

## Materials for Railings

- Glass + Metal: Modern, transparent, enhances views.
- Steel (powder-coated or stainless): Durable, sleek, low maintenance.
- Wooden Railings: Warm, natural look, best for low-rise or traditional homes.
- Masonry + Concrete: Solid, safe, heavier visual impact.
- Combination Systems: Glass with metal handrail, wood with steel balusters, etc.



# FURNITURE PLACEMENT IN SIT-OUTS

### Key Guidelines for Furniture Placement

#### Proportional Sizing

Use compact furniture (like cane chairs, foldable sets, or slim loungers) in small sit-outs; larger sectional seating or swing seats for spacious ones.



#### Circulation Space

Leave at least 750–900 mm around seating for comfortable movement.

#### Functional Grouping

Arrange furniture around a focal point (coffee table, planter cluster, or view).



#### Flexibility

Use stackable or movable furniture in multifunctional sit-outs (convertible to party or dining space).

#### Comfort Additions

Add cushions, rugs, and side tables, but keep them portable for outdoor use.



#### Integration with Nature

Position furniture to capture views, ventilation, and daylight, blending seamlessly with plants and railing designs.

## UTILITY AREA LAYOUT

### Hardscape vs. Softscape

Utility spaces are meant for laundry, washing, and storage of cleaning equipment. Ideally, they are connected to the kitchen or backyard for convenience. Provision of water outlets, electrical points, and ventilation ensures long-term efficiency.



### PARKING & SERVICE YARD DESIGN




### Parking

Parking zones must balance vehicle safety and circulation with aesthetics. Covered carports protect vehicles from weather, while open parking can double up as multipurpose courtyards. Proper driveway widths, turning radii, and buffer spaces help avoid congestion.

### Service Yards


Service yards act as the “backbone” of a house, handling outdoor chores like drying clothes, storing tools, or placing air conditioning units. Placing them strategically keeps clutter hidden while maintaining functionality. Service yards are best tucked behind kitchens, side alleys, or at the rear of the property. Together, these zones ensure that household activities remain organized, keeping the primary living spaces neat, functional, and visually appealing.



## DIMENSION STANDARDS FOR UTILITY AREAS

### Service Yard / Laundry Zone

- Minimum width: 1.5 m (to allow circulation + washing machine placement).
- Length: 2.0–2.5 m minimum.
- Washing machine space: 600 mm × 600 mm.
- Counter height for utility sink: 850–900 mm.
- Sink size: 450 × 600 mm (min).
- Drying space: 1000–1200 mm clear zone.




### Parking Standards

- Car parking (standard sedan): 2.5 m (width) × 5.0 m (length).
- SUV parking: 2.75 m × 5.5 m.
- Two-wheeler: 1.0 m × 2.0 m.
- Circulation clearance: 600–750 mm around vehicle.
- Ramp slope: Max 1:8 (comfortable 1:10).

### Service Passages

- Minimum width: 900 mm (single circulation).
- For carrying cylinders/furniture: 1200 mm.
- Door widths:
- Utility/service entry: 750 mm.
- Store: 700 mm.



# OUTDOOR & SERVICE ZONES

## Storage & Service Rooms

- Utility store (general): 1.5 m × 2.0 m (minimum).
- Overhead storage: 450–600 mm depth.
- Clear height under loft: min 2100 mm.

## Outdoor Utility / Garbage Handling

- Dustbin alcove: 600 × 600 mm.
- Collection point: 1.5 m × 1.5 m.
- Separation distance: At least 3 m away from habitable windows.

## Storage & Shelving

- Overhead Cabinets: 350–400 mm deep, placed 450–600 mm above counter.
- Tall Cabinets (for broom, mop, etc.): 450–600 mm wide × 1800–2100 mm high.
- Open Shelves: 200–300 mm depth for detergents/essentials.

## Service Yard & Drying Area


- Minimum Width: 1200 mm for comfortable movement.
- Clothes Drying Rod Height: 1800–2100 mm above floor.
- Clearance from Walls: 250–300 mm for airflow.

## Passage & Circulation

- Minimum Passage Width: 900–1000 mm
- Utility Corridor Width (if narrow): 750 mm minimum.




WASHING MACHINE PLACEMENT




SERVICE YARD CIRCULATION

WASHING MACHINE PLACEMENT

Single Car arp 2500mx5000 mm



Two-Car Side-by-Side arp 500m x 5500mm



## Service Yard Planning

- Vehicular Entry + Pedestrian Safety
- Vehicular Entry + Pedestrian Safety
- Screening for Privacy & Aesthetics
- Drainage + Waterproof Flooring



## Integration with Compound

- Vehicular Entry
- Pedestrian Safety



# LANDSCAPE FLOW WITH BUILDING

### Hardscape vs. Softscape

- Hardscape: All the built elements — pavements, driveways, patios, retaining walls, steps, ramps. These give structure and permanence to a landscape.
- Softscape: All living and natural elements — grass, shrubs, trees, flowers. These bring flexibility, seasonal changes, and climate response.
- The right balance is crucial. Too much hardscape → harsh and monotonous. Too much softscape → messy and impractical. A well-planned flow uses hardscape as the skeleton and softscape as the life of the design.



HARDSCAPE SOFTSCAPE

### Walkways, Circulation & Visual Connectivity

- Walkways should naturally guide users from entrance → garden → house → service areas.
- Circulation should feel intuitive, avoiding sharp dead-ends.
- Visual connectivity ensures that wherever a person stands, they see greenery balanced with built edges, creating harmony.
- The flow of people should align with the flow of visual sightlines.



WALKWAYS & CIRCULATION

### Climate-Responsive Landscape Choices

- In hot regions, use shaded walkways, pergolas, trees with wide canopies, and water bodies for cooling.
- In rain-prone regions, ensure slopes and drains in hardscapes to avoid waterlogging.
- In cold climates, maximize south-facing gardens for sun exposure and use evergreens for year-round greenery.
- Local plant selection is critical to reduce maintenance and support sustainability.



CLIMATE-RESPONSIVE CHOICES

### Integration with Building Design

- Landscape should not feel like an add-on but rather an extension of architecture.
- The building edges, verandas, balconies, and service yards should blend with softscape transitions.
- Hardscape elements like ramps and steps should be integrated aesthetically rather than looking like technical afterthoughts.



BUILDING INTEGRATED WITH LANDSCAPE

## PRIVACY WALLS & COMPOUND PLANNING


### Wall Height, Material & Aesthetics

- Height: Typically 6–8 feet for privacy and security. Too tall makes it fortress-like, too short loses privacy.
- Materials: Brick masonry, concrete, stone cladding, or modern options like textured RCC + greenery.
- Aesthetics: Should match the house façade. Adding creepers, vertical gardens, or textured finishes reduces monotony.




### Gate Design & Placement

- Placement: Ideally aligned with driveway/parking. Gate should be centrally positioned for symmetry or offset for design interest.
- Design: Options include wooden slats, wrought iron, laser-cut metal panels, or minimalist steel frames.
- Automation: Sliding/remote-controlled gates improve convenience and safety.



### Security + Privacy + Openness Balance

- Security: Solid lower half of wall, with grills or perforated panels on top.
- Privacy: Use height + opaque finishes for bedrooms/yard areas.
- Openness: Transparent/partially open gates for visibility from road, avoiding an isolated look.
- Blend: Green screens, shrubs, and layered landscape soften the compound boundary.



## KEY TAKEAWAYS

### Checklist

- Parking meets turning & clearance rules.
- Separate, private service yard.
- Laundry/utility sized for appliances.
- Proper drainage, ventilation, and sunlight in all utility spaces.
- Integration with greenery for aesthetics & privacy.

### Best Practices Checklist

- Provide 1 car space per family + guest bay.
- Keep service yard close to kitchen.
- Allocate separate access for staff/service if possible.
- Maintain clear distinction: Parking – Utility – Landscape zones.
- Follow local bye-law parking standards.

## Key Takeaways

### 1 Parking Design



- Standard car Parking Dimension 2.5m x 5m
- Two-wheeler Parking: ~1m x 2 m per unit wheasy accessibility
- Driveway Width: ~3 m for single lane, 5.5 -6 m for double lane
- Semi-covered or covered plantantn visually shield sérvce visually shield service areas

### 2 Service Yard Planning




- Placement: Tucked away from main living areas but easily accessible from kitchen & utility zones
- Uses: Clothes drying, outdoor sink, dishwashing, wate segregation
- Proper slope (1:100) and water outlet with grating is mandatory

### 3 Utility & Support Areas



- Utility passages: Should have minimum width 1.5m for utility ppreferred 2m+
- Laundry machine, ironing, storage for cleaning supplies
- Service areas must be naturally lit and ventilated

### 4 Security + Privacy + Openness Balance

- Security: High walls, lockable gates, CCTV (budget allows) 
- Privacy: Service areas must be naturally lit and ventilated

### 5 Landscape & Service Coordination

- Balcony: Sit-out vs Garden serve different functions, planning should be based on lifestyle and plot size
- Key points: Service areas should blend with softscape elements (hedges, green walls)
- Checklist: Accessibility, drainage, ventilator, security, security, and user comfort



# MASTER RESIDENTIAL DESIGNING

Interior Designer's Handbook for Beautiful Living Spaces

A must-have handbook for interior designers to create beautiful and functional living spaces. Discover expert techniques, design principles, and styling tips to transform any home into a masterpiece of comfort and elegance. Elevate your interior design skills with practical insights and creative inspiration

The logo for INFRARC features a stylized icon of a building with horizontal lines on the left, followed by the word "INFRARC" in a bold, dark blue, sans-serif font.

**INFRARC**

A white silhouette of a city skyline with various buildings and structures, spanning the width of the page.

**(2025 EDITION)**