

**DUROPAL**



**SOIS MENDINNI™**

## ABS - EDGEBANDING PROCESSING

### Working Temperature

For best results when applying edge bands to boards or panels, the edge should be processed at room temperature (Not below 10 degrees celsius)

### Cleaning

Edge bands should be cleaned in ordinary soapy water or using cleaners that are designed specifically for use on ABS materials. Solvent based or those cleaning products containing alcohol should not generally be used.