


Joolbaby®

SmartWave™ Plus Touch-Free Diaper Pail


Assembly & Instructions




Instructions



Front



Back



How to Install the Legs



- 1 Turn the pail upside down so the bottom is facing up.



- 3 Once all the legs are installed, turn the pail upright.

Note: The legs are designed to be assembled only once and should not be removed after installation.



- 2 Align the square guides on the bottom with the leg notches—legs only fit one way. Insert the four legs into the corresponding holes on the bottom until you hear a “click.”

Install Deodorizer

- 1 Peel & Stick deodorizer holder inside the lid with the opening facing up.



- 2 Remove the plastic wrapper from the baking soda packet.

- 3 Insert the packet into the holder.

Each baking soda packet provides 30 days of freshness. Purchase more at joolbaby.com.

Operating Instructions



- 1 Open the battery cover on the back of the pail. Insert 4 1.5V AA alkaline batteries, following the (+/-) shown inside the battery compartment. Replace the battery cover.

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- Do not recharge non-rechargeable batteries.
- Only Insert the batteries with the correct polarity (+ and -)
- Remove exhausted batteries and dispose promptly.



2 Slide down the latch to open the front door of the main compartment. Pull out the liner holder, then follow the instructions printed on the liner's paper wrap to prepare it for use.



3 Press and hold the button for 3 seconds to power on the pail. The indicator light will turn solid white.



4 Wave your hand near the sensor, and the pail will open automatically. The lid will close automatically 7 seconds after no movement is detected.



5 To keep the lid open longer, press the button once. The lid will remain open until you press the button again to close it. All set! Your pail is ready to use.

Tips & Notes

Low battery reminder: when the indicator light changes from solid white to solid red, the batteries are low and should be replaced soon.

Power off: to power off the pail, press and hold the button for 3 seconds until the indicator light turns off.

How to Empty the Pail



1 When the pail is full, open the front door of the main compartment and pull the bag **downward**. This will bring the full portion outside the door while also pulling out new liner for the next bag.

2 Slide the liner into the built-in blade on the door, leaving enough length to tie later. Pull straight down to cut the full bag, then tie it closed and dispose of it.



3 Tie a knot at the end of the new liner to create a fresh bag. Then close the door.



Know more

Troubleshooting

- **Check power:** ensure the batteries are installed correctly and the power switch is on. If the indicator light turns red, replace the batteries soon.
- **Clean the sensor:** wipe the sensor lens clean with a soft, dry cloth to remove any dust or debris that might interfere with its detection.

Care & Maintenance

This pail requires very little maintenance. If cleaning is needed:

1. Turn off the power by holding the button for 3 seconds until the indicator light turns off.
2. Do not allow any liquid or cleaner to enter the top through the sensor, button, indicator light, lid hinge openings, or battery compartment. Use a dry cloth only when cleaning near these areas. If liquid does get inside, let the unit air dry completely before turning it on and using it again.



3. Wipe gently with a soft cloth dampened with a non-abrasive cleaner. Afterward, wipe the surface again with a clean, damp cloth to remove any residue.
4. Allow the pail to air dry completely before re-lining.



WARNING:

- **SUFFOCATION HAZARD** To prevent suffocation, keep plastic liners and refill bags away from children and never allow a child to play with them.
- Not intended to be used by a child. Discourage children from using the hands-free features of the diaper pail.
- **HEALTH WARNINGS**
- Cleaning: Clean your diaper pail regularly.
- Ventilation: Keep the pail in a well-ventilated area.
- Always wash your hands thoroughly after use.



NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

MANUFACTURER:

JOOL PRODUCTS LLC
P.O. Box 1273,
LAKEWOOD, NJ 08701
1-888-788-JOOL (5665)
MADE IN CHINA