







## XP-endo® Rise Shaper

30/04




XP-endo® Rise Glider 15/.04

XP-RG

C 1000 RPM - 1Ncm






· Use XP-endo Rise Glider with gentle strokes of 2-3 mm, applying very light apical pressure and allowing the instrument to progress passively along the canal.

working length is reached.

· After 3 strokes, remove and clean the instrument, then irrigate: recapitulate with an ISO 010 hand file



 Start the shaping procedure. applying your usual irrigation protocol.





· Use long gentle strokes to progress down to WL. If WL is not reached in 8 strokes, stop, irrigate, recapitulate, and proceed again.

- · Once working length is reached, remove the instrument to avoid supplementary enlargement of the canal.
- · Irrigate the canal in order to eliminate suspended debris.
- · Choose a gutta percha point that is tight and seats at the correct WL. If 30/.04 is desired and does not fit, work the XP-endo Rise Shaper for an additional 1-3 strokes.
- · Apply your usual disinfection protocol.



· Once all the canals have been shaped, proceed with the deep cleaning (or disinfection) of the canals. For an optimal result, the use of the Finisher is recommended.

· Once the cleaning of the canals is completed, obturate with gutta percha and sealer. TotalFill BC Points and TotalFill BC Sealer are recommended.



explore the canal.

· Determine the working length (WL).

More info

