

# PIANC Fender Guidelines 2024

DOCUMENT INSIGHTS BY TRELLEBORG



**PIANC**  
The World Association for Waterborne  
Transport Infrastructure

## PIANC FENDER GUIDELINES 2024



MarCom Working Group Report N° 211 – 2024



## CONTENTS:

Webinar series: The new PIANC fender guidelines 2024 explained	3
A whole system approach to fender performance	4
Chapter 1 - Introduction and general aspects	5
Chapter 2 - Introduction to principles of fendering	6
Chapter 3 - Particular aspects regarding design vessels	7
Chapter 4 - Basis of design	9
Chapter 5 - Berthing energy	11
Chapter 6 - Fender system selection	15
Chapter 7 - Fender response under moored vessels	18
Chapter 8 - Fender system component design	20
Chapter 9 - Manufacturing of fender systems	22
Chapter 10 - Test procedures of marine fenders	24
Chapter 11 - Installation, inspection and maintenance	27
Chapter 12 - Sustainability of fenders	29
Chapter 13 - Specification writing	31
Trelleborg's contributions to the PIANC Fender Guidelines 2024	32


### DISCLAIMER:

This is a summarized version of the PIANC Fender Guidelines 2024 prepared by Trelleborg and does not encompass the entire report. It provides a brief overview of the revisions and key points. We strongly advise reviewing the official report for a comprehensive understanding of the chapters.



# Webinar series: The new PIANC fender guidelines 2024 explained

To help you get up to speed with the comprehensive changes incorporated into the new fender guidelines, watch our five-part on-demand webinar series led by our Technical Director, Marco Gaal, and Business Unit Director - Technology & Innovation, Mishra Koushik Kumar. This series will delve into the technical details of the guidelines and help you understand their implications.



# A whole system approach to fender performance



When it comes to fender systems, Trelleborg takes a whole system approach covering every aspect from application engineering to detailed design to rigorous quality control, along with installation and maintenance to ensure fender reliability and performance. PIANC's recently released Fender Design Guidelines reflect this approach across its 13 chapters.

Below is a comprehensive overview of the aspects that contribute to fender excellence, highlighting how PIANC offers initial insights through these chapters. Chapters 1 and 13 provide a general overview, while chapters 2 through 12 delve into the components of the whole system approach in greater detail.



## APPLICATION ENGINEERING

Trelleborg's highly-skilled application engineers across the globe are dedicated to engineering best-fit fender systems to better protect today's modern ports and terminals.

**PIANC WG211 CHAPTERS 2-6**



## MANUFACTURING AND TESTING

Our state-of-the-art manufacturing facilities are equipped with test presses that enable us to conduct comprehensive tests on a wide range of fenders. We also perform independent quality and performance verification of all fender system components to ensure optimal performance.

**PIANC WG211 CHAPTERS 9-10**



## DETAILED DESIGN

Our dedicated center of excellence designs meticulously engineered solutions and verifies their compliance with design standards. This provides assurance that the solutions perform well in given site conditions throughout their design life.

**PIANC WG211 CHAPTERS 7-8**



## INSTALLATION AND MAINTENANCE

We provide complete support for fender system installation, operational and maintenance requirements, including training manuals, on-site supervision, and fender inspection services.

**PIANC WG211 CHAPTERS 11-12**



**DOWNLOAD THE WHITEPAPER**

# Chapter one

## INTRODUCTION AND GENERAL ASPECTS

The latest report from Working Group 211 (WG211) is a comprehensive revision of the PIANC MarCom WG33, "Guidelines for Design of Fender Systems." It supersedes both the WG33 report and any other fender design and berthing guidance found in previous PIANC reports. Users are advised not to combine the WG33 report with the latest report in their designs or specifications, as the design approach presented in the latest report is different from that of the WG33 report.

User specifications need a complete update and PIANC WG211 emphasizes the use of site-specific information.

Fender suppliers have until Nov. 1, 2025, to align their catalogs with the new guidelines, which require substantial type approval testing. Meanwhile, designers can begin using the new guidelines for fenders effective immediately.

This introductory chapter covers the following aspects:

- Background of the Report
- Function and Scope
- Climate Change
- PIANC Certification and Type Approval
- Report Contributors
- Guidelines Utilization

FUNCTION	SCOPE
<ul style="list-style-type: none"><li>■ Provide guidance for designing, manufacturing and testing of fender systems</li><li>■ Enhance knowledge about fender systems</li><li>■ Guide through the steps from initial design stage up to testing and installation</li></ul>	<ul style="list-style-type: none"><li>■ Applies to seagoing vessels, primary tug assisted or equipped with thrusters</li><li>■ WG211 is for berthing, not collisions or protection structures</li><li>■ The design approach is for new structures as older structures may have conservative Partial Safety Factors</li><li>■ Guidance for assessing existing structures</li></ul>

### Climate change impact

PIANC WG211 recognizes climate change as a key factor influencing berthing conditions and fender system design. The report suggests ways to make a positive impact through design (Chapter 5) and improve the longevity of the fender system, and reduce the carbon footprint (Chapter 12).

### PIANC certified fenders and PIANC type approval

Sometimes, certain suppliers may claim their products are certified using terms like "PIANC Certified Fenders," even though PIANC is not a certifying authority. PIANC WG211 addresses this misconception in this chapter and explains that fenders can be designed, produced, and tested according to the new guidelines.



### TRELLEBORG'S COMMITMENT TO EXCELLENCE:

At Trelleborg, we are committed to following the guidelines in the latest PIANC WG211 document and will update all catalogs accordingly. We provide full transparency regarding third-party type approval as per PIANC WG211 and are dedicated to educating the industry about all aspects of the report.







# Chapter two

## INTRODUCTION TO PRINCIPLES OF FENDERING

This chapter provides an overview of various types of fenders and fender systems used globally, as well as general fender selection and design approach. It provides insights on cone, cell, arch, cylindrical, MV elements, foam and pneumatic fenders, complete with illustrations, performance curves, and information on dimensions and sizes. Additionally, engineered solutions like parallel motion, pivot, and rolling fenders, as well as ship-to-ship considerations, are also discussed.

This chapter serves as an introduction for less experienced engineers, offering valuable insights on the various types of fenders.


The table below, extracted from PIANC WG211, details the different types of fenders and their respective performance ranges.

Cone Fenders	Cell Fenders	Element/Leg Fenders	Arch Fenders	Foam Fenders	Pneumatic Fenders
					
Size: $h_f$ 300 - 2500	Size: $h_f$ 400 - 3000	Size: $h_f$ 250 - 2000	Size: $h_f$ 150 - 1000	Size: D 700 - 4200	Size: D 500 - 4500
E <sub>A</sub> : ~ 10 - 9500	E <sub>A</sub> : ~ 10 - 9800	E <sub>A</sub> : ~ 10 - 1300	E <sub>A</sub> : ~ 5 - 450	L 1500 - 8500	L 1000 - 12000
R <sub>F</sub> : ~ 55 - 7200	R <sub>F</sub> : ~ 50 - 8850	R <sub>F</sub> : ~ 80 - 1750	R <sub>F</sub> : ~ 90 - 1050	E <sub>A</sub> : ~ 30 - 9000	E <sub>A</sub> : ~ 6 - 9050
		Performance values for single unit of 1,000 mm length	Performance values for single unit of 1,000 mm length	R <sub>F</sub> : ~ 130 - 8500	R <sub>F</sub> : ~ 65 - 10500
All sizes are in mm   EA in kNm   RF in kN   Shapes might differ from manufacturer to manufacturer					

PIANC WG211 Table 2-1: Typical fender types

### Fender efficiency and fender selection

PIANC explains how fenders function and absorb berthing energy. There are primarily two types of fenders: buckling and side-loaded, each with distinct characteristics. PIANC WG211 aims to give readers a thorough understanding of the various types of fenders, enabling designers to make informed choices about fender selection. Below is an illustration from PIANC WG211 demonstrating the operation of a buckling fender.



PIANC WG211 Figure 2-1: Typical buckling fender deflection curve



### TRELLEBORG'S COMMITMENT TO EXCELLENCE:

Trelleborg is committed to helping customers select the right fender. To this end, we have developed online tools and brochures that simplify the fender selection process, which will soon be updated to reflect changes in WG211. Our in-house manufacturing capabilities allow us to produce a wide range of fenders, including rubber, foam, and pneumatic options, as well as the largest selection of fenders, including intermediate sizes up to SCN2500 and SCK3000.

# Chapter three

## PARTICULAR ASPECTS REGARDING DESIGN VESSELS

This chapter focuses on the specific aspects of designing vessels and their relevance to fender design. It discusses the importance of understanding the characteristics of the design vessel, as provided by the customer, to guide the fender design process.

It also provides information on ship types and hull shapes relevant to the design of fenders and should be read in conjunction with PIANC WG235: Ship Dimensions and Data for Design of Marine Infrastructure (PIANC WG235, 2022).

This chapter is essential for working with accurate vessel data.


**This chapter, as outlined by PIANC WG211, is divided into three main sections:**

- Vessel Characteristics
- Displacement
- Influence of Vessel Hull Characteristics on Fender Design

### VESSEL CHARACTERISTICS

This section offers practical guidance to designers on vessel characteristics relevant to designing fendering systems, in addition to the WG235 report. PIANC WG211 covers all ocean-going vessels such as dry bulk and ore carriers, cruise vessels, RoRo, RoPax and vehicle (car) carriers, tankers, gas carriers (LPG and LNG), general cargo, refrigerated cargo and livestock carriers, passenger ferries, and fishing vessels.

For example, it discusses how the relatively short parallel body of container vessels impacts the berthing energy and thus fender design. Refer to Figure 3-1.



PIANC WG211 Figure 3-1: Parallel mid-body of a typical container vessel hull

## DISPLACEMENT

Vessel owners often overlook providing information about displacement in their specifications, focusing more on parameters like DWT. However, designers should consider displacement to be an important factor.

PIANC WG211 provides three methods to estimate the displacement:

- I. Full laden displacement as listed in WG235
- II. Calculate with the following formula:

$$M = L_{BP} \cdot B \cdot D \cdot \rho_w \cdot C_b$$

Where


$M$	Mass equivalent to the water displacement of berthing vessel [tonnes]
$L_{BP}$	Length between perpendiculars [m]
$B$	Beam of vessel [m]
$D$	Draught of vessel at midships [m]
$\rho_w$	Density of water (1.025 typical for seawater) [tonne/m <sup>3</sup> ]
$C_b$	Block coefficient of vessel

- III. Relationship between displacement and capacity (DWT)

## IMPACT OF VESSEL HULL CHARACTERISTICS ON FENDER DESIGN

This section provides insights into assessing vessel hull configurations and their impact on the clearance between the vessel and the structure, the engagement with the fender or multiple fenders, and the initial point of contact with the fender.

Figure 3-2 In this section, PIANC WG211 defines key zones of a vessel hull with respect to fender contact.



PIANC WG211 Figure 3-2: Fender contact zones on vessel hull at low berthing angles



### TRELLEBORG'S COMMITMENT TO EXCELLENCE:

Trelleborg offers support in vessel assessments, resulting in more accurate fender designs and cost-effective investments. Our online tools, which include WG235 data, help users avoid common design errors and better account for complex hull shapes in multiple fender contacts.


The information in this chapter will aid in optimizing the design, reducing costs, and improving operations. It is recommended to read the relevant information as needed. For instance, review the container vessel information when working on a container berth.



# Chapter four

## BASIS OF DESIGN

This chapter outlines the key factors to consider when designing a fender system. It serves as both a guide for the design process and a template for creating a comprehensive design document. The design of the fender system should serve the primary functions outlined in Chapter 2 and meet both functional and operational requirements. It's essential to give the design of a fender system the same level of consideration as any other element of the structure of which it is a part. A fender system should be designed considering the following six criteria:



### **Functional requirements :**

The functional requirements, in essence, revolve around elucidating the fundamental purpose of the fender.



### **Operational requirements:**

Operational considerations have substantial influence over fender system selection and design. This section provides guidance on the key operational aspects that need to be considered.



### **Assessment of site conditions:**

To establish the factors influencing fender system design, it's essential to gather comprehensive data about the berth's configuration and location. These factors impact aspects like fender system loading, durability, and material selection. PIANC WG211 provides guidance on the key site conditions to be considered.



### **Assessment of design criteria:**

After evaluating the functional and operational requirements and considering site conditions, the design criteria used to calculate berthing energy and the selection of the fender system can be established.



### **Operation and maintenance:**

The design life of a fender system is typically shorter than that of the marine structures it interacts with. To ensure its continuous functionality throughout its design life, a regular maintenance and inspection plan is crucial, typically involving annual visual inspections. PIANC WG211 offers guidance to effectively address this process.



### **Assessment of acceptable reliability levels:**

A crucial aspect of designing a fender system is understanding the consequence of failure of a fender system and its impact. Understanding these failure consequences is vital, as higher consequences typically necessitate greater reliability. In some cases, a single fender failure might not result in significant economic impacts, while in others, it could lead to major accidents.

Table 4-1: PIANC WG211 provides detailed examples of fender systems for different consequence classes, with class A and class B being the most common for marine structures. The port authorities or terminals, should choose the consequence class based on appropriate input, as detailed in Chapter 13 of PIANC WG211.

CLASS	EXAMPLE OF FENDER SYSTEMS
A	<p><b>Fenders installed on a marine structure within a terminal or port with functional redundancy and a limited number of people at risk.</b></p> <p>If one fender were to fail, it is unlikely that it would lead to the unavailability of the berth or cause extensive damage to the marine facility, provided there is sufficient redundancy with the additional berths. For instance, this could include a continuous earth-retaining quay wall or a dolphin berth equipped with more than two redundant berthing (breasting) dolphins, or marine facilities that have multiple berths with similar capabilities.</p>
B	<p><b>Fenders installed on a marine structure without functional redundancy.</b></p> <p>If the fender system fails, the berth will most likely be unavailable, leaving no alternate options. A single berth with two berthing (breasting) dolphins is an example.</p>
C	<p><b>Fenders installed on marine structures, positioned at locations where failure of the fender system is likely to endanger public lives.</b></p> <p>Fenders installed on a marine structure where failure of the fender system is likely to close the berth and cause significant economic losses. Examples include critical floating power plants or floating storage regasification units that are prohibited from operating due to fender failure and lack sufficient backup methods to resume operations.</p>
D	<p><b>Fenders installed on marine structure where failure of the fender system is likely to lead to significant socio-economic disruptions.</b></p> <p>Examples include progressive damage or cascading effects on other types of structures, like critical installations such as essential power plants or floating storage regasification units that are prohibited from operating due to fender damage with no backup measures available to resume operations.</p>

**The selection of the right consequence class is important as it impacts:**

- 1) The Partial Energy Factor PIANC WG211 Chapter 5
- 2) The Partial Safety Factor for multiple fender contact PIANC WG211 Chapter 6
- 3) The Partial Load Factor for fender system accessories design PIANC WG211 Chapter 6

This ultimately impacts design berthing energy, fender selection and fender panel calculation.



#### **TRELLEBORG'S COMMITMENT TO EXCELLENCE:**

Trelleborg can support you in the assessment of all relevant design requirements. We are well-equipped to help you understand the relevance of the consequence class and determine the suitable class to identify the optimal fender design to incorporate.

# Chapter five

## BERTHING ENERGY

PIANC WG211 chapter 5 provides guidance on calculating the berthing energy of a vessel that the fender system should absorb. It outlines clear steps and specifies the key factors to consider in the energy calculation process as below:



### 1. BERTHING MANEUVERS & NAVIGATION CONDITIONS

PIANC WG211 considers the various berthing maneuvers as they occur in ports: alongside berthing and end berthing. A notable update in PIANC WG211 compared to the previous PIANC WG33 is the inclusion of navigation conditions. PIANC WG211 has taken into account the following navigation conditions:

- Favorable
- Moderate
- Unfavorable

PIANC Working Group 211 offers detailed descriptions of these navigation conditions, assisting designers in selecting the right navigation conditions. This is critical in determining the berthing energy process as the navigation conditions could impact the berthing energy and the Partial Energy Factor.

### 2. KINETIC ENERGY OF A BERTHING VESSEL

PIANC WG211 introduces a new terminology for Berthing Energy:

Characteristic Berthing Energy:

This is the calculated berthing energy based on characteristic conditions and the following formula (PIANC WG211, equation 5-4):

$$E_{k,c} = \left( \frac{1}{2} M_c V_c^2 \right) C_{e,c} C_{m,c}$$



Design Berthing Energy:

This is the berthing energy used for the design of the fender system, including the Partial Energy Factor that accounts for uncertainty in the berthing energy calculation.

$$E_{k,d} = \gamma_E E_{k,c}$$

### 3. DISPLACEMENT:

The characteristic displacement ( $M_C$ ) should be considered for the berthing energy calculation, defined as the largest operational displacement of the design vessel.

PIANC WG211 recommends using site-specific information, but when not available, the recommendations of WG235 can be considered. Additionally, PIANC WG211 Chapter 3 Section 2 provides guidance on determining the vessel's displacement.

### 4. BERTHING VELOCITY:

The berthing velocity is the dominant factor in determining the berthing energy of a vessel. The berthing velocity is defined by PIANC WG211 as the vessel's approach velocity at first contact with the fender system.

PIANC WG211 recommends that the berthing velocity should be provided by the asset owner. Furthermore, PIANC WG211 suggests that site-specific information and experience are used. When site-specific information is not available for a new design, table 5-3 shown below can be used for the transverse velocity while table 5-4 in PIANC WG211 can be used for the longitudinal velocity applicable for end berthings.

Navigation Condition:	Favourable	Moderate	Unfavourable
Type of Vessel <sup>a</sup>	$V_{B,c}$ (m/s)		
Coaster	0.180 <sup>f</sup>	0.300 <sup>e</sup>	0.400 <sup>e</sup>
Feeder, Handysize	0.150 <sup>b</sup>	0.225 <sup>e</sup>	0.300 <sup>d</sup>
Handymax, Panamax	0.120 <sup>b</sup>	0.200 <sup>e,g</sup>	0.275 <sup>d</sup>
Vehicle Carriers	0.120 <sup>a</sup>	0.200 <sup>e</sup>	0.275 <sup>e</sup>
Post Panamax, Capesize (small), Aframax	0.100 <sup>b,e</sup>	0.175 <sup>e</sup>	0.275 <sup>d</sup>
New Panamax, Capesize (large), Suezmax, ULCV, VLBC, VLCC, ULCC	0.100 <sup>b,e</sup>	0.150 <sup>e,f</sup>	0.250 <sup>d</sup>
Cruise & Passenger Vessels	0.100 <sup>a</sup>	0.150 <sup>e,f</sup>	0.250 <sup>e</sup>

PIANC WG211 Table 5-3 : Characteristic berthing velocity in the absence of site-specific information

### 5. BERTHING ANGLE:

The berthing angle is the angle between the heading of the vessel and the berthing line. Again, PIANC WG211 recommends using site-specific information. However, if it is not available, the PIANC Fender Guidelines provides guidance to determine the berthing angles by considering the method of approach, use of tugs, and the use of thrusters (PIANC WG211 table 5-5).

PIANC WG211 considers two types of berthing angles:

Characteristic berthing energy

Used for determining the berthing energy.

Incidental berthing energy

Used to verify the safe clearance between the vessel hull and the structure.

## 6. ECCENTRICITY FACTOR:

Some of the berthing energy will dissipate due to the vessel's yawing. This is accounted for in the eccentricity factor ( $C_e$ ) in berthing energy calculation. The eccentricity factor ( $C_e$ ) can be determined with the following equation:

$$C_e = \frac{K^2 + r_F^2 \cos^2(\phi)}{K^2 + r_F^2}$$

The point of impact ( $r_F$  in above equation) is critical in determining the  $C_e$  factor. PIANC WG211 provides various methods to determine  $r_F$  and these methods depend on engagement of multiple fenders or single fender contact only and the availability of information on the vessels hull. Furthermore, PIANC WG211 provides basic guidance on the  $C_e$  factor based on fifth point, quarter point, third point, and midship impact.

## 7. ADDED MASS FACTOR:

A vessel in motion is subject to a range of hydrodynamic forces, such as drag forces, due to the mass of the water that “moves” with the vessel. This force is known as added mass and is considered in the berthing energy calculation as the Added Mass Factor ( $C_m$ ). PIANC WG211 considers only one method for alongside berthing to determine the added mass factor, based on the PIANC WG33 method, which considers the under-keel clearance and the vessel's draft. Furthermore, PIANC WG211 provides guidance for determining the added mass factor for end berthings.

## 8. PARTIAL ENERGY FACTOR:

The Partial Energy Factor ( $\gamma_E$ ) accounts for the uncertainty in the berthing energy calculation.

With the Partial Energy Factor, the Design Berthing Energy  $E_{k,D}$  can be determined by applying it on the Characteristic Berthing Energy  $E_{k,C}$ .

Although the Partial Energy Factor could be compared with the “Abnormal Berthing Factor” as per PIANC WG33, the method to determine this factor is very different. While PIANC WG33 considered the type of vessel and vessel size only (PIANC WG33 Table 4.2.5), PIANC WG211 considers multiple factors such as:

- Consequence Class (refer to PIANC WG211 chapter 4)
- Navigation Conditions
- Variations in Displacement
- Single or Multiple Fender Contacts
- Berthing Frequency
- Pilot Assistance
- Site-Specific Information

PIANC WG211 provides direction on determining the Reference Partial Energy Factor  $\gamma_{E,ref}$  (tables of PIANC WG211 5-8 to 5-10) considering a berthing frequency of 100 berthings per year. Factors mentioned above are considered in these tables and corrected as needed, such as in the case of a different berthing frequency.

The Partial Energy Factor is calculated as follows:

$$\gamma_E = \gamma_{E,ref} \gamma_n \gamma_p \gamma_c$$

In simple terms, the Partial Energy Factor is the old “Abnormal Berthing Factor”

Where :

$\gamma_{E,ref}$	Reference Partial Energy Factor for 100 berthing's per year
$\gamma_n$	Correction Factor for alternative annual berthing frequencies
$\gamma_p$	Correction Factor for berthing without pilot assistance
$\gamma_c$	Correction Factor for correlations between design variables

## SHIP-TO-SHIP BERTHING

PIANC WG211 also provides guidance for designing fenders in ship-to-ship applications that are not covered by Oil Companies International Marine Forum (OCIMF) STS Transfer Guidelines.

For ship-to-ship applications where both vessels are free-floating, the berthing energy calculations should account for the mass of both vessels.

Characteristic berthing energy

$$E_{k,c} = E_{sts,c} = \left( \frac{1}{2} \cdot M_{sts,c} V_{sts,c}^2 \right) \cdot C_{sts,e}$$

Characteristic mass

$$M_{sts,c} = \frac{M_1 C_{m1} M_2 C_{m2}}{M_1 C_{m1} + M_2 C_{m2}}$$

Furthermore, PIANC WG211 provides guidance on determining the Characteristic Berthing Velocity the “Relative Approach Velocity” or “Closing Velocity” as well as determining the Eccentricity Factor.



## TRELLEBORG'S COMMITMENT TO EXCELLENCE:

Trelleborg is developing advanced tools for berthing energy calculations. We can assist with calculations in line with the new PIANC WG211 guidelines, supported by our Fender Online Tools. Soon, our Fender Online Tools will be updated to these standards, enabling customers to perform their own berthing energy calculations and fender selections according to the new guidelines. Trelleborg will host educational webinars and lunch-and-learn sessions. Should you be interested in organizing a session for your organization, please reach out to us.

Trelleborg offers technology such as portable piloting units, SmartFender, and docking aid systems to collect site data, enabling customers to optimize fender design for safer ports. Overall, Trelleborg is actively driving advancements in berthing energy calculations and fostering knowledge-sharing and technology development in this domain.



# Chapter Six

## FENDER SYSTEM SELECTION

This chapter outlines the fender selection process, providing background information on all critical elements that should be considered when selecting a fender system. It also clearly outlines the role of the designer in fender selection process.

PIANC WG211 states, "The selection of a fender system deserves as much attention as the design of any other element of the structure of which it is a part."

### FENDER SELECTION OVERVIEW

PIANC WG211 provides a clear overview of the fender selection process in figure 6-1. The key steps in this process are:

1. Requirements	Identify the functional and operational requirements as well as the site conditions and design criteria.
2. Type of Fender	Identify the type of fender that is likely to meet the project requirements.
3. Base Performance	Identify the catalog performance of the fender under specific testing conditions, previously referred as CV performance (PIANC WG33).
4. Characteristic Performance	Identify the performance of the fender in actual site conditions, including all performance correction factors.
5. Design Performance	Identify the performance by applying the Partial Safety Factors which covers the manufacturing tolerances.
6. Verification	Verify that Design performance meets the Design Energy and all other project requirements.

PIANC WG211 also introduces Pre-Set Design Criteria that present fender performance under specific design conditions, which are closer to site conditions than base performance but not as specific as characteristic performance. It allows the designer to quickly select a preliminary fender based on the pre-set design criteria published in the fender supplier's catalog. However, this is not intended to be used for the final design, the characteristic and the design performance should be used.

### FENDER SYSTEM SELECTION

PIANC WG211 offers guidance on the application of fender systems related to various types of vessels and marine applications. For example, it recommends specific types of fenders that can be used in conjunction with belted vessels, in ice zones, for lock entries, and various other scenarios.

PIANC WG211 provides guidance on various key factors to consider when selecting a fender system.

The factors are:

■ Bow Radius	■ Fender System Elevation
■ Bow Flare	■ Pneumatic and Foam Fenders
■ Fender System Pitch	■ Number and Size of Fenders
■ Single Fender Contact	■ Shear of Fenders
■ Multiple Fender Contact	■ Submerged Fenders
■ Vessel Hull Structure	■ Fender Orientation
■ Vessel Belting	■ Aging Effects on Fenders
■ Double Hull Contact	■ Non-Marking Fenders
■ Type of Support Structure	■ Mooring Analysis
■ Flexible Dolphins	■ Permanent Mooring

PIANC WG211 provides detailed guidance on each of these factors.

### BASE FENDER PERFORMANCE:

The base fender performance is the fender performance at standard testing conditions at slow Constant Velocity (CV) compression testing method (reference is made to PIANC WG211 chapter 10). This is the fender performance as tested and prior to applying any Correction Factors.

### CORRECTION FACTORS & CHARACTERISTIC PERFORMANCE

The base performance is the performance of the fender under testing conditions. However, it must be adjusted to reflect the site's actual conditions. This is addressed by the Correction Factors. PIANC WG211 takes into account the following Correction Factors:

- Velocity Factor ( $C_v$ )
- Temperature Factor ( $C_t$ )
- Angular Factor ( $C_{ang}$ )
- Multiple Fender Contact Factor ( $C_{mult}$ )

Applying the Correction Factors to the fender base performance results in the fender characteristic performance.

### Determining Fender Design Performance

The fender design performance ( $E_{f,d}$ ) is derived by applying Partial Resistance Factors of safety to the characteristic performance values.

$$E_{f,d} = \frac{E_{f,c}}{\gamma_m} = \frac{E_{f,c}}{\gamma_f \gamma_{mult}}$$

The Partial Resistance Factors  $\gamma_m$  covers:

- The single fender Partial Resistance Factor  $\gamma_f$
- The multiple fender Partial Resistance Factor  $\gamma_{mult}$

In this section, PIANC WG211 explains how to determine these factors and how they should be considered for buckling and side-loaded fenders. It also explains how the Fender Design Performance should be considered for the fender component design, the hull structure verification, and the supporting structure.

The below table 6-3 from PIANC WG211 provides guidance for determining the single fender Partial Resistance Factor  $\gamma_f$ .

Performance tolerance	$\gamma_f$ factor for all consequence classes	Typical example types of fender system
+/- 10%	1.10	Cone, cell, arch, element and cylindrical (wrapped) fenders
+/- 15%	1.15	Foam fenders
+/- 20%	1.20	Cylindrical (extruded), extruded, composite and shear fenders, wheel and roller fenders
Reference ISO17357-1	1.00	Pneumatic fenders <sup>a)</sup>
<sup>a)</sup> $\gamma_f = 1.0$ for the calculation of the Design Berthing Energy according to ISO 17357-1. Pneumatic fender performance is given as a guaranteed value, hence no material factor needed.		

PIANC WG211 Table 6-3 : Partial Resistance Factor  $\gamma_f$  related to the performance of a single fender

## HULL PRESSURE

While absorbing the berthing energy of a vessel, the fender will exert a reaction force on the vessel (as well as the supporting structure). This force should not exceed the vessel hull structural capacity.

PIANC WG211 provides guidance on the vessel hull structure, and table 6-6 considers the maximum ultimate hull pressure as well as the maximum ultimate fender reaction force on the hull.

Type of vessel	Maximum ultimate hull pressure ( $P_{hull,d}$ ) <sup>(1)</sup> (kN/m <sup>2</sup> )	Maximum ultimate fender reaction force ( $R_{f,lim}$ ) (kN)
<b>General Cargo</b>		
≤ 20,000 DWT	500	NK <sup>(6)</sup>
> 20,000 DWT	400	NK <sup>(6)</sup>
<b>Bulk Carriers</b>		
≤ 60,000 DWT	200	2,200 <sup>(7)</sup>
> 60,000 DWT	320	3,800 <sup>(7)</sup>
<b>Container</b>		
Panamax and smaller	400	1,500 <sup>(7)</sup>
Neo/post Panamax and larger	200	5,600 <sup>(7)</sup>
<b>Tankers (see WG 153)</b>		
≤ 60,000 DWT	300	1,800 <sup>(7)</sup>
> 60,000 DWT	200	NK <sup>(6)</sup>
Gas carriers (LPG & LNG)	200	NK <sup>(6)</sup>
<b>Cruise</b>		
≤ 20,000 DWT	400	NK <sup>(6)</sup>
< 60,000 DWT	300	NK <sup>(6)</sup>
100,000 DWT	200	NK <sup>(6)</sup>
<b>Passenger Ferries and RoRo</b>		
RoRo (belting)	Refer Notes 3, 4 and 5 below	NK <sup>(6)</sup>
RoRo (no belting)	Refer to equivalent size of Cruise Vessel	NK <sup>(6)</sup>
Passenger (belting)	Refer Notes 3, 4 and 5 below	NK <sup>(6)</sup>
Passenger (no belting)	Refer to equivalent size of Cruise Vessel	NK <sup>(6)</sup>
SWATH (double hull vessels)	Refer Note 5 below	NK <sup>(6)</sup>

PIANC WG211 Table 6-6 : Typical values of hull pressure capacity

## SHIP-TO-SHIP FENDERING

The OCIMF MEG4 covers the fender selection for offshore fendering for ship-to-ship transfers. PIANC WG211 covers nearshore transfers and FSRU's.

Table 6-7 of the PIANC WG211 provides recommendations on the fender arrangement for various types based on combined mass coefficient ( $M_{cv}$ ).



## TRELLEBORG'S COMMITMENT TO EXCELLENCE:

To align with the latest guidelines, Trelleborg is in the process of updating important resources such as brochures and improving the Fender Application Design Manual (FADM) and other online tools. We recognize the complexities involving multiple fender contacts and are developing tools to support a more efficient assessment process. Additionally, Trelleborg is dedicated to promoting the use of performance correction factors in fender design and selection and is committed to educating and raising awareness in the industry.



# Chapter seven

## FENDER RESPONSE UNDER MOORED CONDITIONS

This chapter outlines the design considerations applicable for fender systems that accommodate moored vessels. It's important to address these considerations because, although berthing maneuvers can be controlled, mooring conditions can transmit greater forces on the fender system.

While berthing can be controlled, the mooring conditions may transmit higher loads into the fender system.

PIANC WG211 suggests that the suitability for moored vessels, particularly, the 'lean-on' mooring loads need to be assessed for fender systems. This assessment includes factors like waves, wind, currents, and loads from passing vessels, as well as extreme conditions like hurricanes and squalls and the impact of pre-tensioned mooring lines.

PIANC WG211 SUGGESTS FOUR CRITICAL ELEMENTS TO BE CONSIDERED IN MOORED CONDITIONS:

### I. FENDER DESIGN FOR MOORED VESSELS

This section explains that selecting a fender requires consideration of the berthing energy and a range of conditions acting on the vessel.

### II. CHARACTERIZATIONS OF VESSEL AND BERTH CONFIGURATION

PIANC suggests that when evaluating a fender system's performance for a moored vessel, it is crucial to understand the specific characteristics of the vessel and berth, as well as the probable mooring configurations. This evaluation should consider the parameters for fender contact, such as the size and position of the vessel's parallel mid-body, the exact layout of the terminal geometry, all potential mooring positions and configurations, and any potential interferences with the fender system.

### III. MOORING ANALYSIS

A mooring analysis involves assessing how a moored vessel reacts to environmental forces like winds and waves at a berth. PIANC WG211 details how mooring assessment can aid in evaluating fender systems.

### IV. CREEP AND FATIGUE ASSESSMENT FOR DYNAMIC MOORING SITUATIONS

Fender fatigue analysis is typically not required in protected ports. However, in exposed locations, the effects of constant swells or frequent and strong gusty wind should be carefully considered.

\* These conditions are substantially different from the fender testing conditions.

\* The effect of fatigue and creep on fenders must be assessed. When identified that the local conditions at the berth may be of relevance for fatigue fenders, an assessment must be performed.

PIANC WG211 suggests that when selecting fenders for dynamic mooring situations, the following factors should be carefully considered.

- Fatigue in fenders - Fatigue in fenders refers to the progressive damage in the fender body material caused by cyclic loading, potentially leading to fender failure.
- Fatigue life - Fatigue life is the maximum number of loading cycles a fender element can withstand before it fails.
- Creep in fenders - Creep in fenders is the permanent deformation that occurs after loading. In rubber and foam-filled fenders, creep results from different phenomena, with foam-filled fenders needing more time to recover after each load cycle. For all types of fenders, there is a significant relationship between creep and fatigue damage, as creep amplifies the effects of cyclic loading.

PIANC WG211 states that the impact of fatigue on fenders varies based on their type and material. It offers guidance on fatigue damage for rubber, foam, and pneumatic fenders.

PIANC WG211 explains that durability tests for fenders usually involve repeated compressions with a cycle duration of 150 seconds. However, environmental loads can cause compressions at a much shorter cycle period, leading to a higher rate of heat transfer within the fender. This increased heat can soften the rubber, resulting in larger deflections and reducing the ability of the fender to rebound between cycles.

Designers must consider fatigue effects and consult manufacturers when assessing fatigue. Manufacturers are responsible for defining fatigue limits when no published data is available.

In the absence of project-specific limits from manufacturers or other reliable sources, PIANC WG211 recommends the following limits for buckling fenders:

1. Buckling fenders should be chosen with care to ensure they don't buckle due to creep after prolonged static loads from continuous wind or currents. They should also withstand repetitive ship motions without exceeding the peak of the reaction force.
2. Creep limit: Under design conditions, the continuous load should not surpass 40% to 50% of the design load, equivalent to 5% - 10% deflection.
3. Fatigue limit: The maximum cyclic deflections under design conditions should not exceed the buckling limit, which is the peak of the performance curve.



## **TRELLEBORG'S COMMITMENT TO EXCELLENCE:**

Trelleborg's focus on innovative product design and high-quality compound materials significantly enhances the fatigue performance of fenders. We are committed to creating awareness in the industry by developing technical papers, providing both internal and external training, offering supporting tools, and facilitating data requests. Trelleborg fenders have passed rigorous durability tests (110K cycles at 35% and 50K at 50%) for SCN, and similar tests have also been conducted for PNE fenders, demonstrating our commitment to producing highly durable products.

Trelleborg is actively engaged in further research, recognizing the need for more testing data to support fatigue design and fender selection.

# Chapter eight

## FENDER SYSTEM COMPONENT DESIGN

PIANC WG211 states that when designing fender systems, it's crucial to pay attention to the details of the fender panel, chains, UHMW-PE pads, and fixings to ensure both efficiency and robustness. These components must be integrated into the overall berth design, as the berth structure must be capable of accommodating the fender system and all related elements like chains and anchors. PIANC WG211 outlines various factors to consider in the design process for fender system components, including:


- Fender Panel Design
- Accessories Design
- Whole Life Considerations
- Special Design Considerations

### FENDER PANEL DESIGN

PIANC WG211 discusses the importance of the fender panel and its design, highlighting how factors such as maximum hull pressure, hull curvature, and vessel projections (belting) influence the fender panel design.

#### Load cases and structural analysis

PIANC WG211 highlights typical design cases of fender contact with the vessel hull profile in figure 8-1. It states that the longevity and effectiveness of a fender panel design largely depend on accurately identifying and defining all potential load cases that could occur throughout the system's life cycle. Additionally, the document emphasizes the importance of design calculations that should consider bending, shear, local buckling, and crushing effects on the steel panels and fender frames, to ensure robust and reliable fender systems.




PIANC WG211 Figure 8-1: Typical design cases of fender contact with vessel hull profile

#### Fender panel internal structure

PIANC WG211 outlines the typical range of panel weights and intended uses. It talks about the two types of fender panel structural forms of construction the 'closed' and 'open' box. In figure 8-2, it also provides recommended minimum thickness for steel section in fender panels.

- Plates exposed on two surfaces:  
≥ 12 mm (A)
- Plates exposed on one surface:  
≥ 9-10 mm (B)
- Internal members (not exposed):  
≥ 8 mm (C)



PIANC WG211 Figure 8-2: Recommended minimum thicknesses for steel in fender panels

#### Chamfers

PIANC WG211 outlines factors that lead to the direct application of vertical or horizontal loads to the perimeter of the panel, potentially compromising the durability of the fender system by introducing destructive shear forces to the rubber unit, which it is not designed to resist. To minimize potential damage, it further states that fender panel design should include edge chamfers or bevels around the panel edges.



Panel size and position

PIANC WG211 outlines the requirements for determining the appropriate width, height, thickness, and position of the fender on a panel, critical for ensuring vessel safety and operational efficiency. Additionally, PIANC WG211 emphasizes the importance of considering factors such as tidal range, wind force, and tidal currents, which influence the dimensions and positioning of the fender system.

ACCESSORIES DESIGN

Chain system design

PIANC WG211 addresses the design of chain systems, which play a crucial role in maintaining panel alignment and ensuring that fenders compress optimally at nearly zero degrees to maximize energy absorption. This section covers various types and positions of chains—weight, shear, and tension—and their design parameter. It also discusses design considerations when choosing chains for cylindrical, foam, and pneumatic fenders.

Weight chains	support the fender system and prevent excessive drooping of the system caused by self-weight forces. They may also resist vertical downwards shear forces caused by vessel movements or changing draught.
Tension chains	Restrict tension forces in on the fender rubber. Correct location can optimise the deflection geometry.
Shear chains	Resist horizontal forces caused during longitudinal approaches or warping operations.
Uplift chains (not indicated in Figure 8-3)	Prevent vertical shear uplift forces in conjunction with the weight chains. These are often specified for exposed offshore berths with large wave induced vessel movements. This type of chain is however typically used in special cases and is not very common. The use of this type of chain should be verified with the fender supplier.  If uplift is expected, this chain can be used on side loaded fenders as well to limit lift movement.
Rope guard chains	Prevent mooring lines from getting caught behind fender panels, particularly on panels with no top tension chains.
Keep chains	Used to moor floating or to prevent loss of fixed fenders in the event of accidents.
Supporting chains	Floating fenders (i.e. foam, pneumatic) and cylindrical fenders require supporting chains, see below Section 8.2.2.

PIANC WG211 Table 8-1: Types of chains

Anchor design and fixing

PIANC WG211 emphasizes that a crucial aspect of anchor design is understanding and identifying the various forces the anchor will have to withstand, which must be taken into account during the design process. It highlights these forces and also the types of anchors used for fender installation.

Low friction facing design

PIANC WG211 discusses that the design of low friction facings should consider the type and size of fixings, and include a wear allowance. The document includes a friction coefficient table. It also outlines the key factors to be considered in designing low friction facings.

SPECIAL DESIGN CONSIDERATIONS

PIANC WG211 also discusses some of the special design considerations for:

- Parallel Motion Fender System
- Fender Interfaces with Mooring Lines
- Whole-life Consideration
- Corrosion of Fender Components
- Marine Growth
- Design of Fender Components in Icy Conditions



TRELLEBORG'S COMMITMENT TO EXCELLENCE:

For many years, Trelleborg has embraced the design principles advocated by the new PIANC WG211, as they represent foundational standards essential for creating durable and well-designed fender panels. With our global approach and local presence, Trelleborg successfully integrates both international and local design standards.

Trelleborg's sales offices and Design Center in India employ a team of over 60 engineers, each a specialist in their field. This team includes panel engineers, FEA engineers, application engineers, Parallel Motion Fender specialists, and materials specialists, ensuring that we deliver the highest quality designs that meet all project requirements and adhere to both local and international design standards. Our engineers can assist our clients in managing complex design projects and finding the most economical solutions for complex design scenarios.

# Chapter nine


## MANUFACTURING OF FENDER SYSTEMS

Fender systems usually consist of several key components: a rubber or foam element for energy absorption, a steel frontal panel for load distribution and hull pressure (if applicable), low friction facing pads to minimize friction and abrasion, and accessories such as chains and anchors. This chapter delves into the general manufacturing process of these components detailing the qualifications required for manufacturers and their workforce, facility standards, requirements for quality control and storage conditions necessary to ensure quality and reliability of the fender systems.

### FABRICATION OF RUBBER FENDERS

PIANC WG211 discusses the rubber compounds utilized in fender systems, detailing various materials for rubber compounding. It also provides insights into the materials used, such as natural and synthetic rubber, recycled rubber, fillers, and antioxidants, highlighting their impact on fender performance.

The chapter describes the general process of manufacturing rubber fenders, which includes mixing, molding, extrusion, wrapping, and curing, offering valuable information on each step of the process.



PIANC WG211 Figure 9-1: Manufacturing of rubber fender

### **FABRICATION OF STEEL PANELS:**

PIANC WG211 covers the fabrication of steel panels, addressing material selection, design, and corrosion protection.

### **FABRICATION OF UHMW-PE:**

This section offers an insightful overview of the manufacturing of ultra-high molecular weight polyethylene face pads.

### **FABRICATION OF ACCESSORIES:**

This section of PIANC WG211 touches on the fabrication of accessories like chains and anchors, focusing on corrosion protection.

### **FABRICATION OF PNEUMATIC AND FOAM FENDERS:**

It briefly mentions the manufacturing processes for pneumatic and foam fenders, providing a foundational understanding of how these fenders are manufactured.

Overall, the chapter serves as a comprehensive guide for designers and specifiers who document the specification, focusing on manufacturer and workforce qualifications, manufacturing processes, material selection, and quality control.



### **TRELLEBORG'S COMMITMENT TO EXCELLENCE:**

Trelleborg's in-house manufacturing facilities meet industry standards. We use high-quality materials to ensure our fenders fulfill all project requirements. Our manufacturing facilities are equipped with cutting-edge test presses, allowing us to perform extensive tests on a wide range of fenders. We also conduct independent quality and performance verification on fender system components to ensure optimum performance.

# Chapter ten

## TEST PROCEDURES OF MARINE FENDERS

This chapter is important as it outlines recommended testing protocols for evaluating and ensuring the quality of various types of marine fenders. It focuses on standardized testing methodologies that are widely recognized in the industry. These procedures aim to ensure that the engineering data provided in manufacturers' catalogs is accurate and reliable, and guide customers on how to verify the performance of the fenders they purchase. By following these common testing methods, manufacturers can offer dependable and comparable data, assisting customers in making informed decisions when selecting marine fenders for specific applications.

PIANC WG211 elaborates on the different types of tests which are classified into:

- Fundamental Testing (catalog data)
- Type Approval Testing (3rd party verified catalog data) including protocols for VF, TF and AF
- Verification Testing (project-specific testing)

### FUNDAMENTAL TESTING (CATALOG DATA)

Engineers depend on published data for designing fender systems. It is the manufacturer's responsibility to generate and publish data about fenders and materials, derived from fundamental tests. PIANC WG211 lists the minimum fundamental testing required for marine fender systems that manufacturers must perform and document.

### TYPE APPROVAL TESTING

An independent and qualified third party, as defined in WG211, must observe and/or confirm fundamental testing to acquire a type approval certificate, ensuring the reliability of the data. PIANC WG211 specifies the essential type approval testing data that must be included.

### VERIFICATION TESTING

Verification testing for fenders is conducted to ensure that the fenders purchased by consultants, designers, contractors, or port owners meet the designed performance specifications for their projects. PIANC WG211 outlines mandatory tests, highly recommended tests, optional tests required based on the application needs and the physical properties of the materials. These tests are structured to confirm that the fenders will perform as expected in the actual scenario, matching the conditions they were designed for.

#### MANDATORY TESTS:

- Verification of base performance
- Physical properties of rubber compound

#### HIGHLY RECOMMENDED TESTS:

- Performance and physical properties testing witnessed by a third party, using a third-party testing jig, or in a third-party testing facility
- Chemical composition or Thermogravimetric Analysis of rubber compound used for production
- TGA Analysis of samples from rubber fenders

#### OPTIONAL TESTS:

- Verification of factors
- Verification of durability tests
- Shear compression tests
- Fatigue test



THIRD-PARTY QUALIFICATION

This section provides guidance on the process of qualifying a third-party for verification testing, ensuring only qualified entities conduct fender testing.

BREAK-IN COMPRESSION

- Uncompressed fenders may exhibit a 30%-40% higher reaction force on the first compression, potentially exceeding the structural limits or pressure tolerances of vessels.
- A "Break-in" compression is compulsory for buckling-type rubber elements in fender systems that have a reaction force exceeding 1000 kN or are for use on load-sensitive structures like dolphins.

THERMAL STABILIZATION BEFORE TESTING

After vulcanization, fenders retain residual heat, which, along with environmental temperature, can affect their performance. Therefore, PIANC WG211 states that it's essential to stabilize their temperature before performance tests. This stabilization is done in a conditioning room set at 23 ± 5°C for a period determined by PIANC WG211 in the below equation 10-1. Prior to testing, fenders should undergo conditioning to ensure accurate results, without the application of correction factors.

PIANC WG211 Equation 10-1

$$t(days) = (12.675 LN(\Delta T) - 2.0352) (maximum\ rubber\ thickness)^2$$

PASS / FAIL CRITERIA

PIANC WG211 states that a fender performs satisfactorily if it achieves the required base (CV) energy value (minus the manufacturing tolerance) without exceeding the reaction value (plus the manufacturing tolerance) at any deflection up to the maximum designed deflection point. If a fender from a 10% sample of the order fails the test, then a larger sample of 20% must be tested. If any fender from this larger sample fails, then the entire batch of fenders (100%) must be tested.

DURABILITY TESTING

WG33 and WG211 outline testing criteria for fender durability. WG33 calls for 3,000 cycles of compression to rated deflection in 150 seconds per cycle, while WG211 suggests a minimum of 3,000 cycles to design deflection, and can increase depending on the specific project. PIANC WG211 provides guidance on fender selection and scaled model testing. It introduces combined shear and compression testing. Samples for chemical composition or Thermogravimetric Analysis (TGA) must be taken from the specimen before and after the durability test. The TGA results should match those of the fender body made for the project.

COMPOUND PHYSICAL PROPERTIES TABLE

PIANC WG211 document contains extensive information, including a table detailing the physical properties of the compound including specified properties, testing conditions, and methods. Rubber samples are taken from the production floor and verified through TGA (Thermogravimetric Analysis). For third-party testing, two samples of uncured rubber are provided. Testing also includes tensile properties. While some properties in the testing process are optional, those relevant to high and low temperature applications are incorporated.

TGA TESTING AS A TRACEABILITY TESTING

The chemical composition of fenders can be analyzed using Thermogravimetric Analysis (TGA). PIANC WG211 suggests the following procedure as traceability test:

- A minimum of 10% of the fenders should be selected at random for this testing.
- The TGA values for the cured rubber compound, samples prepared for physical property testing, and actual samples taken from the fender body must match.
- TGA tests should be conducted alongside performance and durability tests to evaluate a fender's quality, with an acceptable variance of ±5% from the established value.

**TEST PROTOCOL FOR PERFORMANCE CORRECTION FACTORS**

The PIANC WG211 guidelines stipulate detailed testing protocols for the performance correction factors:

- Velocity factors
- Temperature factors
- Angle factor

Samples of fenders taken for the type approval testing of the performance correction factors for TGA testing. The TGA results should match the results of the commercial fenders.

**TESTING OF PNEUMATIC FENDERS**

WG33 includes guidelines for the performance testing of pneumatic fenders in Appendix B. WG211 will no longer cover pneumatic fenders and will refer to the requirements of ISO 17357-2014. Designers and testers should therefore refer directly to ISO 17357 for testing pneumatic fenders, streamlining the process by using one primary source.

**TESTING OF FOAM FENDERS**

WG211 offers recommendations that include a test protocol for determining performance, alongside material and verification testing. It provides a clear classification of testing requirements for foam fenders, including tables for the physical properties of foam, polyurethane (PU), and nylon materials that are used in manufacturing. It also includes velocity factors, angular factors, and temperature factors. The document also outlines a procedure for fender pull-through tests and provides calculations for creating scaled-down models that are suitable for testing. Lastly, recommendations for testing of skin thickness and foam density are made using samples extracted from fenders of actual size.



**TESTING OF ACCESSORIES:**

This section expands its focus beyond rubber and foam testing to include the fabrication of steel accessories such as fender panels. It outlines the test procedure for the air leakage test for fender panels, and specifies that accessories should undergo Non Destructive Testing (NDT).

**UHMWPE PROPERTIES TABLE**

The material properties for Ultra High Molecular Weight Poly Ethylene (UHMWPE) is clearly defined in Table 10-12 of PIANC WG211 and includes several characteristics that are important during the design phase or when selecting UHMWPE for fender applications. However, for testing purposes, specific properties are emphasized. These essential properties—such as density, double notch Charpy impact strength, abrasion resistance, and mass melt flow rate—must be rigorously tested to authenticate whether the material in question is truly UHMWPE.



**TRELLEBORG'S COMMITMENT TO EXCELLENCE:**

Trelleborg recently added a state-of-the-art marine fender test facility to its Qingdao manufacturing site in China, setting new benchmarks in fender manufacturing in alignment with PIANC WG211 guidelines. This facility is equipped with advanced test presses for comprehensive evaluations of marine fenders under real-world conditions, shear, fatigue, high-speed, and shear-compression, all within a climate-controlled environment. Trelleborg is currently the only manufacturer that integrates a test facility within its foam fender factory in Berryville, USA ensuring unparalleled quality control. All Trelleborg fenders are produced in-house at facilities wholly owned by Trelleborg, guaranteeing that every product meets our stringent standards.

Trelleborg supplies all its fenders, adhering to the highest industry standards. Through these rigorous practices, Trelleborg is committed to leading the industry toward reliable and consistent fender performance.

# Chapter eleven

## INSTALLATION, INSPECTION, AND MAINTENANCE

The performance of a fender system over its design life relies on proper installation and maintenance as specified by fender system designers & manufacturers. Under the guidance of the fender manufacturer, port owners & end users must ensure the provided installation & maintenance guidelines are followed. As fender systems are required to operate under heavy loads, harsh environments and challenging conditions, fender systems will always require a periodic maintenance plan. Most facilities that have fender systems installed often overlook the maintenance plan requirement. Therefore, it is always important to consider a periodic maintenance plan during the design phase.

Proper installation and maintenance are critical for the fender systems' service life and to ensure safe port operations.

### HANDLING AND INSTALLATION

PIANC WG211 emphasizes the importance of correct handling and installation of fender systems to avoid any damage that could affect the performance. Suppliers must provide detailed guidelines for handling and installation, allowing installation contractors to prepare appropriate method statements.

### SPARES

PIANC WG211 advises on the importance of planning for spare parts for fender systems, focusing on items prone to wear and tear or accidental damage, such as facing pads, their fixings, chains, and chain weak links. It recommends that end users collaborate with the fender system designer and supplier to conduct a risk assessment and identify necessary spare parts, which should be included in the purchase order for the complete system.

However, ordering spare rubber fenders is not recommended due to aging concerns. In facilities with many fender systems, like continuous quays, damaged units could be replaced with end units.

### STORAGE

PIANC WG211 states that fender manufacturers should provide detailed packing and storage guidelines to prevent changes in properties or surface deterioration of the products. These guidelines, including recommended storage durations, should align with ISO 2230 or a similar standard. PIANC WG211 also highlights the natural hardening process of fender rubber during delayed use, which typically results in temporary hardening.



### INSPECTION AND MAINTENANCE

PIANC WG211 states that regular inspections are essential for identifying early signs of degradation and deteriorations in fender systems, which helps prevent failures and operational disruptions. The ideal frequency and extent of maintenance and inspection (I&M) are hard to standardize due to variations from one site to another. But at a minimum, annual inspections are advised for all fender systems. At the very least, inspections should specifically check for any major or minor cracks, signs of over-compression, drooping of the units, panels that are not vertical, as well as any loose or broken chains, and missing fixings or facing pads. After extreme events like hard berthing, storms, earthquakes, or tsunamis, a thorough inspection of the fender systems is strongly recommended.

Key maintenance areas include inspecting steel panels for coating damage and conducting pressure tests if significant corrosion is present. UHMWPE elements may need to be replaced or checked for thickness reduction. Chains should be replaced if they are corroded or have a reduced diameter. Fixings and fittings need to be checked for looseness or absence, and tightened or replaced as necessary.

Pneumatic fender systems require air pressure checks, replacement of loose or worn rubber sleeves, greasing of swivels, and safety valve inspections. For foam fenders, any cuts or cracks in the skin require immediate repair, and regular removal of marine growth is necessary.

### EMERGING TECHNOLOGY

Traditionally, fender system inspections are performed through visual assessments by maintenance crews. However, operators can now leverage emerging technologies that capture real-time and historical data on various parameters such as berthing speed, compression percentage, over-compression, and the number of compressions. This data can be collected and uploaded to the cloud for further analysis. Utilizing this technological advancement can aid operators and end users in enhancing berth utilization, prolonging the lifespan of fender systems, and reducing overall lifecycle costs.

Regular inspections are crucial for extending the service life of fender systems and ensuring warranty validity.



### TRELLEBORG'S COMMITMENT TO EXCELLENCE:

Trelleborg provides world-class fender inspection services to port and terminal operators worldwide by providing a standardized method for documenting inspections, raising user awareness of fender condition, and enabling managers to review inspection results in real-time for greater insight. The inspections performed by Trelleborg are carried out by trained and qualified experts in accordance with international standards. In this process, a comprehensive assessment report is produced, enabling operators to optimize efficiency, and increase fender durability.

Trelleborg's cutting-edge SmartPort technology allows for seamless wireless transmission of data generated by our smart fenders. You will receive real-time notifications of any abnormal fender behavior with the option to instantly access the fender status updates on your smartphone or tablet.

**FOR MORE INFORMATION ON OUR FENDER INSPECTION PROCESS DOWNLOAD THE INFOGRAPHIC**





# Chapter twelve

## SUSTAINABILITY OF FENDERS

In 2015, the United Nations established the Sustainable Development Goals (SDGs) to create a more sustainable future, addressing global challenges through 17 goals including those relevant to industry and infrastructure, reducing inequality, and promoting responsible consumption and production. PIANC places a strong emphasis on sustainability, acknowledging the climate change challenge in its "Declaration on Climate Change" and advocating for the waterborne industry's sustainable advancement. PIANC's Report EnviCom WG 150 underscores the benefits of adopting a green port philosophy, providing tools and guidance for environmental strategies that support port growth and proactive measures that are ahead of legislation. Many ports now implement sustainability programs, reinforcing that investments such as fender systems be sustainable, considering the entire lifecycle and recyclability, aligning with the SDGs and national standards.



Some of the UN SDG's relevant for fenders include:

- 9 Industry Innovation and Infrastructure
- 10 Reduced Inequalities
- 12 Responsible Consumption and Production
- 14 Life Below Water



PIANC WG211 serves as a guide highlighting the industry's need for sustainable fendering solutions, focusing on reducing carbon footprints and addressing rubber sourcing issues. It covers fender design, fabrication, and material selection. The report also examines the sustainability of different fender designs, including pneumatic, cone, and foam fenders, comparing their energy absorption capabilities and overall sustainability.

### CARBON FOOTPRINT

PIANC WG211 highlights the importance of assessing the carbon footprint as a major factor in global warming. To address this, it suggests employing Life Cycle Analysis (LCA) and Environment Performance Declarations (EPD).



### RUBBER SOURCING


PIANC WG211 states that the production of natural rubber is sometimes associated with unsustainable practices, including irresponsible farming, deforestation, and human rights violations. Efforts are underway to develop sustainable natural rubber fenders. Styrene-butadiene rubber (SBR), being petroleum-based, is not deemed sustainable. Fender products, which extend beyond just rubber, are incorporating more sustainable components, such as recycled carbon black and eco-friendly oils, as part of a broader push for sustainability.

## FENDER DESIGN & MATERIALS SELECTION

The document states that end-users, designers, and manufacturers can enhance sustainability in fender systems through thoughtful design and material selection. PIANC WG211 highlights key aspects that need to be considered.

## RECYCLING

PIANC WG211 recommends conducting visual inspections and tests for the potential reuse of fenders. The recycling efforts should extend to fender components constructed from a variety of materials, including rubber, foam, polyurethane (PU), steel, and ultra-high-molecular-weight polyethylene (UHMWPE). The document also details current practices of fender recycling, as well as, rubber, foam, steel and Ultra-High Molecular Weight Polyethylene (UHMWPE) recycling.




Successful refurbishment of a foam fender, restored to near-new condition: Ideal form of recycling.

## RECOMMENDATIONS & CONCLUSIONS FROM PIANC WG211


The global emphasis on sustainability is impacting ports and the manufacturing sector, with challenges like recycling and carbon footprint management, particularly in rubber and fender production. The fender industry, along with end-users, designers, and other stakeholders, are encouraged to lead the way in finding and implementing the most sustainable practices for their projects, including the disposal of fenders. When a project prioritizes the sustainability of fender systems, all parties involved should actively participate to create the most sustainable fender systems possible. Despite current limitations, stakeholders can proactively take meaningful steps to reduce environmental impact and enhance sustainability through intelligent material choices and engineering solutions.



## TRELLEBORG'S COMMITMENT TO EXCELLENCE:



At Trelleborg, sustainability is at the core of everything we do. From using sustainable and biodegradable materials in our Fender solutions, to implementing meticulous refurbishment processes in our manufacturing facilities, we take every possible step to reduce our environmental impact while improving the efficiency of port operations. Our sustainability initiatives are not just an afterthought, but the very foundation on which we build our success.



# Chapter thirteen

## SPECIFICATION WRITING

PIANC WG211 Chapter 13 serves as a valuable resource for designers and authorities, offering detailed guidance on what to consider in a specification. In short, it is a comprehensive checklist to ensure all necessary aspects are considered and includes a table (refer to the document) indicating where to find the relevant information.

PIANC WG211 outlines that a good specification should cover:

- ✓ Qualifications of Supplier
- ✓ Standards and Code of Practice
- ✓ Quality Control
- ✓ Submittal Requirements
- ✓ Project Records Requirements
- ✓ Warranty, Product Liability and Compliance
- ✓ Vessel, Berthing, and Quay Considerations
- ✓ Manufacturing, Testing, and Quality Requirements
- ✓ Delivery, Installation, and Storage
- ✓ Sustainability

PIANC WG211 states:  
"Accurate and complete specifications are important to achieve an economical and durable fender system complying with the required performance."



### TRELLEBORG'S COMMITMENT TO EXCELLENCE:

Trelleborg is set to launch online tools to aid in generating specifications. The Trelleborg team is available to help with specification development and provide user-friendly templates. Committed to meet the specifications outlined in the latest PIANC WG211 document, Trelleborg recommends involving third parties at all critical stages to ensure utmost integrity. Furthermore, Trelleborg recommends conducting fender testing by a third party or use third-party verified equipment instead of mere third-party witnessing, to ensure the highest levels of reliability and performance.

Trelleborg recommends specifying that the rubber fender units should be tested by a third party at a third-party press or with a third-party verification jig that works independently from the manufacturer's test equipment. A third party witness is not sufficient.



# Trelleborg's contributions to the PIANC Fender Guidelines 2024

For several years, Trelleborg has actively collaborated with PIANC, its association members and other industry experts, contributing significantly to the newly released PIANC Fender Guidelines 2024. Our experts, Marco Gaal and Mishra Kumar, served as lead authors for this comprehensive guide. Marco Gaal spearheaded Chapter 12 on fender sustainability, while Mishra Kumar led the effort on Chapter 10 covering marine fender test procedures.

Initially intended as an update to the WG33 guideline, this document has evolved into a comprehensive new guide on fender design best practices. We recommend purchasing the document for a complete understanding of the guidelines. If you have any questions, please do not hesitate to contact us.

We remain committed to elevating industry standards and driving excellence in the industry.



**MISHRA KOUSHIK KUMAR**  
BUSINESS UNIT DIRECTOR -  
INNOVATION & TECHNOLOGY  
LEAD FOR CHAPTER 10 OF THE  
PIANC FENDER GUIDELINES 2024



**MARCO GAAL**  
TECHNICAL DIRECTOR -  
MARINE FENDERS  
LEAD FOR CHAPTER 12 OF THE  
PIANC FENDER GUIDELINES 2024



## GET IN TOUCH

**Website | [trelleborg.com/marineandinfrastructure](https://trelleborg.com/marineandinfrastructure)**

**Email | [marine\\_infra@trelleborg.com](mailto:marine_infra@trelleborg.com)**

**SCAN TO  
CONTACT US**







Trelleborg is a world leader in engineered polymer solutions that seal, damp, and protect critical applications in demanding environments. Its innovative solutions accelerate performance for customers in a sustainable way.

Trelleborg Marine and Infrastructure is a leading provider of premium solutions for critical marine, port, and built infrastructure applications. Its innovative polymer and smart technology solutions enhance operational efficiency, safety, and sustainability.

[WWW.TRELLEBORG.COM/MARINEANDINFRASTRUCTURE](http://WWW.TRELLEBORG.COM/MARINEANDINFRASTRUCTURE)



LinkedIn: [Linkedin.com/company/trelleborg-marine-and-infrastructure](https://www.linkedin.com/company/trelleborg-marine-and-infrastructure)

YouTube: [Youtube.com/c/TrelleborgMarineInfrastructure](https://www.youtube.com/c/TrelleborgMarineInfrastructure)

Facebook: [TrelleborgMarineandInfrastructure](https://www.facebook.com/TrelleborgMarineandInfrastructure)

Twitter: [@TrelleborgMI](https://twitter.com/TrelleborgMI)

**Trelleborg Marine and Infrastructure**

Email: [marine\\_infra@trelleborg.com](mailto:marine_infra@trelleborg.com)