

ATTENTION INSTALLER



IMPORTANT: Please read instructions thoroughly before beginning. The following instructions are designed to be used for the installation of our outdoor fitness products into a concrete surface.

WARNING: Always wear appropriate safety gear when using power tools to prevent personal injury.

REQUIRED TOOLS



Rubber hammer



Concrete drill + 1/2" carbide-tipped drill bit



Angle grinder



Compressor



Torque wrench + 3/4" socket



Measuring tape



Stainless Steel Throughbolt (included)



INSTALLATION

- 1** To ensure proper alignment with the holes, place the unit on the concrete pad and mark all of the holes.
- 2** Use the concrete drill and 1/2" carbide-tipped drill bit to drill all marked points on concrete pads.
- 3** Remove any drilling dust and debris from the hole by using a blow pump or any similar method.
- 4** Lightly tap the through bolt through the fixture into hole with a hammer, until fixing depth is reached.
- 5** Tighten anchors until snug, specifically 36.88 ft-lb.
- 6** Cut off the remaining extra bolt length if any.

